
# **Operator's Manual**

# AMAZONE

## On-board computer **AMATRON** <sup>+</sup> For use in conjunction with pneumatic seed

**AD-P** and **AVANT** 



MG3252 BAG0072.0 11.08 Printed in Germany



Before starting to operate the machine, please carefully read and adhere to this instruction manual and safety advice!





# Reading the instruction

Manual and following it should seem to be inconvenient and superfluous as it is not enough to hear from others and to realize that a machine is good, to buy it and to believe that now everything should work by itself. The person in question would not only harm himself but also make the mistake of blaming the machine for possible failures instead of himself. In order to ensure success one should enter the mind of a thing, make himself familiar with every part of the machine and get acquainted with how it's handled. Only in this way could you be satisfied both with the machine and with yourself. This goal is the purpose of this instruction manual.

Leipzig-Plagwitz 1872. Rub. Sark!

Identification data									
		e machine identification da on the type plate.	ta here. You will find the identifica-						
	Machine (ten-digit	identification number: )							
	Туре:		Amatron+						
	Year of n	nanufacture:							
	Basic we	ight (kg):	cation number:       Amatron+         eture:						
	Approved	d total weight (kg):							
	Maximun	n load (kg):							
Manufacturaria address									
Manufacturer's - address									
	AMAZON	NEN-WERKE							
	H. DREY	'ER GmbH & Co. KG							
	Postfach	51							
	D-49202	Hasbergen							
	Tel.:	+ 49 (0) 5405 50 1-0							
	Fax.:	+ 49 (0) 5405 501-234							
	E-mail:	amazone@amazone.de							
Spare part orders									
	AMAZON	NEN-WERKE							
	H. DREY	'ER GmbH & Co. KG							
	Postfach	51							
	D-49202	Hasbergen							
	Tel.:	+ 49 (0) 5405 501-290							
	Fax.:	+ 49 (0) 5405 501-106							
	E-mail:	et@amazone.de							
	Online sp	pare parts catalogue: www	v.amazone.de						
	When or		specify the (ten-digit) machine						

#### Formalities of the operating manual

Document number:	MG3252
Compilation date:	11.08
© Copyright AMAZONEN-WERKE H. I	DREYER GmbH & Co. KG, 2008
All rights reserved.	
Reprinting, even of sections, only pos	sible with the approval of

AMAZONEN-WERKE H. DREYER GmbH & Co. KG.





Dear Customer,

	Dear Customer,								
	You have chosen one of the quality products from the wide product range of AMAZONEN-WERKE, H. DREYER GmbH & Co. KG. We thank you for your confidence in our products.								
	On receiving the machine, check to see if it was damaged during transport or if parts are missing. Using the delivery note, check that the machine was delivered in full including the ordered special equip- ment. Damage can only be rectified if problems are signalled immedi- ately!								
	Before first commissioning, read and understand this operating man- ual, and particularly the safety information. Only after careful reading will you be able to benefit from the full scope of your newly purchased machine.								
	Please ensure that all the machine operators have read this operating manual before commissioning the machine.								
	Should you have problems or queries, please consult this operating manual or give us a call.								
	Regular maintenance and timely replacement of worn or damaged parts increases the lifespan of your machine.								
User evaluation									
User evaluation	Dear Reader,								
User evaluation									
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send								
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send us your suggestions by fax.								
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send us your suggestions by fax. AMAZONEN-WERKE								
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send us your suggestions by fax. AMAZONEN-WERKE H. DREYER GmbH & Co. KG								
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send us your suggestions by fax. AMAZONEN-WERKE H. DREYER GmbH & Co. KG Postfach 51								
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send us your suggestions by fax. AMAZONEN-WERKE H. DREYER GmbH & Co. KG Postfach 51 D-49202 Hasbergen Tel.: + 49 (0) 5405 50 1-0 Fax.: + 49 (0) 5405 501-234								
User evaluation	Dear Reader, We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly manuals. Send us your suggestions by fax. AMAZONEN-WERKE H. DREYER GmbH & Co. KG Postfach 51 D-49202 Hasbergen Tel.: + 49 (0) 5405 50 1-0								

1999 B
AMAZONE

1	User Information	7
1.1	Purpose of the document	7
1.2	Locations in the operating manual	7
1.3	Diagrams used	
2	General safety instructions	8
2.1	Representation of safety symbols	
3	Installation instructions	9
3.1	Mounting of the terminal	
3.2	Battery cable	
4	Product description	11
4.1 4.1.1	Keys and function fields Shift key	12
4.2	Entries on AMATRON <sup>+</sup>	14
4.3 4.3.1	Entering text and numbers	
4.3.2	Toggle function	15
4.4	Software version	
4.5	Hierarchy of the <b>AMATRON<sup>+</sup></b>	16
5	Operation	17
5.1	Start screen	17
5.2	Main menu	17
5.3	Machine data menu	18
5.3.1 5.3.2	Tramline rhythm (machine data 📴 🗤 ) Input of the sown and unsown distances (m) for the intermittent tramline (Machine data 🗐 ⴰⴰⴰⴰч)	
500	Calibration of forward speed sensor (Machine data 🔲 🗐 01.04)	21
5.3.3 5.3.4	Seed rate reduction during tramline creation	22
5.4	Starting a job	
5.4.1	External job	
5.5	Calibration	27
5.5.1	Calibration of the drill with remote seed rate control	
5.5.2	Calibration of the drill with full electric metering system	
5.6 5.7	Service Setup Terminal set-up	
-		
6	Use on the field	
6.1 6.2	Specified quantity adjustment	
6.2 6.3	Preselection for hydraulic functions	
6.4	Work menu display Functions in work menu	
6.4.1	Tramline control	
6.4.2	Track marker (Avant)	
6.4.3	Blocking the star wheel	41
6.4.4	Switching part widths (Avant with electric full dosing)	
6.4.5 6.4.6	Electric full dosing Coulter pressure and harrow pressure	
6.4.7	Folding the machine (Avant 03-2)	
6.4.8	Rotary cultivator working depth	45
6.4.9	Coulter lift	45
6.4.10	Front tank lighting (Avant)	45



#### Contents

6.5 6.5.1 6.5.2 6.5.3 6.5.4 6.5.5	Advice on field operation Key assignment in work menu <b>AD-P</b> with gearbox Key assignment in work menu <b>AD-P</b> with full dosing Layout menu - joystick <b>AD-P</b> Key assignment in work menu <b>Avant</b> with gearbox Key assignment in work menu <b>Avant</b> with full dosing	
7	Joystick	51
7.1	Fitting	51
7.2	Function	
7.3	Key layout:	
8	Maintenance	53
8.1	Calibration of gearbox	53
9	Helpmenu	54
10	Malfunction	54
10.1	Alarm	54
10.2	Failure of the forward speed sensor	



#### 1 User Information

The User Information section supplies information on use of the operating manual.

#### 1.1 Purpose of the document

This operating manual

- Describes the operation and maintenance of the machine.
- Provides important information on safe and efficient handling of the machine.
- Is a component part of the machine and should always be kept with the machine or the traction vehicle.
- Keep it in a safe place for future use.

#### 1.2 Locations in the operating manual

All the directions specified in the operating manual are always seen from the direction of travel.

#### 1.3 Diagrams used

#### Handling instructions and reactions

Activities to be carried out by the user are given as numbered instructions. Always keep to the order of the handling instructions. The reaction to the handling instructions is given by an arrow.

#### Example:

- 1. Handling instruction 1
- $\rightarrow$  Reaction of the machine to handling instruction 1
- 2. Handling instruction 2

Lists

Lists without an essential order are shown as a list with bullets.

Example:

- Point 1
- Point 2

#### Number items in diagrams

Numbers in round brackets refer to the item numbers in the diagrams. The first number refers to the diagram and the second number to the item in the figure.

Example: (Fig. 3/6)

- Figure 3
- Item 6



## 2 General safety instructions

Knowledge of the basic safety information and safety regulations is a basic requirement for safe handling and fault-free machine operation.

The	operation manual
•••••••••••••••••••••••••••••••••••••••	Must always be kept at the place at which the machine is oper- ated.
•	Must always be easily accessible for the user and maintenance personnel.

#### 2.1 Representation of safety symbols


Safety instructions are indicated by the triangular safety symbol and the highlighted signal word. The signal word (DANGER, WARNING, CAUTION) describes the gravity of the risk and has the following significance:



#### DANGER

Indicates an immediate high risk which will result in death or serious physical injury (loss of body parts or long term damage) if not avoided.

If the instructions are not followed, then this will result in immediate death or serious physical injury.





#### CAUTION

Indicates a low risk which could incur minor or medium level physical injury or damage to property if not avoided.

#### IMPORTANT

Indicates an obligation to special behaviour or an activity required for proper machine handling.

Non-compliance with these instructions can cause faults on the machine or in the environment.



#### NOTE


Indicates handling tips and particularly useful information.


These instructions will help you to use all the functions of your machine to the optimum.



## 3 Installation instructions

#### 3.1 Mounting of the terminal








#### Connections to tractor's basic equipment:

- The battery cable (Fig. 1/5).
- Signal cable from the tractor signal socket or distance sensor (Fig. 1/4).
- Connecting cable to **AMATRON**<sup>+</sup> (Fig. 1/6).

#### To operate

- Plug the **AMATRON**<sup>+</sup> (Fig. 1/2) into the tractor's basic equipment.
- Insert the connector of the connecting cable (Fig. 1/6) into the middle 9-pin Sub-D bushing (Fig. 2/1).
- Connect the machine via the connector (Fig. 1/3) to the AMATRON<sup>+</sup>.
  - The multifunction stick (Fig. 1/7) is connected using a Y-cable (Fig. 1/8).
- The serial interface (Fig. 2/2) allows a PDA to be connected.







#### 3.2 Battery cable


The required operating voltage is 12 V and must taken directly from the battery.




Before connecting the

**AMATRON**<sup>+</sup> to a tractor with several batteries, you need to clarify which battery the computer should be connected to by referring to the tractor operating instructions or by asking the tractor manufacturer!

- 1. Install and secure the battery cable from the tractor cab to the tractor battery. When installing the battery cable, make sure there are no kinks.
- 2. Shorten the battery cable to the appropriate length.
- 3. Strip the cable end (Fig. 3) approx. 250 to 300 mm.
- → Strip the cable ends (Fig. 3) individually 5 mm.
- 4. Insert the blue cable core (earth) into loose ring lug (Fig. 4/1).
- 5. Pass pinch through with pliers.
- 6. Insert brown cable core (+ 12 volts) into free end of connector (Fig. 4/2).
- 7. Pass pinch through with pliers.
- 8. Shrink-fit connector (Fig. 4/2) with heat source (lighter or hairdryer) until the adhesive emerges.
- 9. Connect the battery cable to the tractor battery:
  - o Brown cable core to +.
  - o Blue cable core to -.











#### 4 Product description

**AMATRON<sup>+</sup>** makes it easy to control, operate and monitor **AMAZONE** machines.

The **AMATRON**<sup>+</sup> can be used for various machine types and equipment.

This operating manual shows operation of the **AD-P** and **AVANT** seed drills with the **AMATRON**<sup>+</sup>.

Operation of the seed drill with the **AMATRON**<sup>+</sup> differs according to the type and equipment of the machine.

The **AMATRON**<sup>+</sup> controls a machine computer, providing it with all the necessary information and taking charge of the area-based regulation of the spray rate, depending on the current operational speed.

Once a job has been started, the **AMATRON<sup>+</sup>** stores the data.

The **AMATRON<sup>+</sup>** consists of the main menu and the work menu.

#### Main menu (Fig. 5)

The main menu consists of several submenus in which, before work:

- data must be entered
- settings are determined or must be entered


machine	ype:	AD-P	Order					
order No	.:	6	drill calibr.					
tramline	tramline rhythm No.: 15							
working (	vidth:	2.5m	machine					
pre-sel.: calibrat	speed: ion fac.:	5 km/h 1.05						
	working menu	aid	- Setup					

Fig. 5

ſ

Work menu (Fig. 6)

- During operation, the work menu indicates all necessary work data.
- The machine is operated via the work menu during use.








#### 4.1 Keys and function fields

The functions indicated at the right display edge by a function field (box or diagonally divided box) are controlled via the two rows of keys to the right of the display.

- If boxes appear on the display, only the right key (Fig. 7/1) is assigned to the function field (Fig. 7/A).
- If the boxes are diagonally divided:
  - o the left key (Fig. 7/2) is assigned to the top left function field (Fig. 7/B).
  - o the right key (Fig. 7/3) is assigned to the bottom right function field (Fig. 7/C).



	On/Off (Always switch off the <b>AMATRON<sup>+</sup></b> when driving on public roads).
EFF	<ul> <li>Return to last menu</li> <li>Switch between work menu - main menu</li> <li>Cancel entry</li> <li>To work menu (hold down key at least 1 second)</li> </ul>
Þ	<ul> <li>Scroll to other menu pages (only possible if (Fig. 7/4) appears in display)</li> <li>Multi-function stick learning menu (see page 54)</li> </ul>
	Move cursor left in display
	Move cursor right in display
	<ul> <li>Take over selected numbers and letters</li> <li>Confirm critical alarm</li> <li>100% quantity in work menu</li> </ul>
	<ul> <li>Move cursor up in display</li> <li>Increase specified quantity during work by percentage application rate increase (e.g.:+10%) (Adjusting percentage application rate increase, see page 19)</li> </ul>
	<ul> <li>Move cursor down in display</li> <li>Reduce specified quantity during work by percentage application rate increase (e.g.:-10%) (Adjusting percentage application rate increase, see page 19)</li> </ul>




#### 4.1.1 Shift key

The shift key is located on the back of the

unit (Fig. 8/1).

- When the Shift-key is activated, this is indicated on the display (Fig. 9/1).
- When the Shift-key is actuated, further function fields appear (Fig. 10) and the assignment of the function keys is altered accordingly.



#### Fig. 8

]]])→ 8.5 km/h 	Shift 1	
--------------------	------------	--




Fig. 10



#### 4.2 Entries on **AMATRON**<sup>+</sup>




For operation of the **AMATRON**<sup>+</sup>, the function fields appear in this operating manual in order to make clear that the key for the respective function field must be pressed.

Example:



Description in the operating manual:



#### Action:

~

The operator uses the key (Fig. 11/1) assigned to the function field to perform function A.

#### 4.3 Entering text and numbers

If it is necessary to enter texts or numbers on the AMATRON<sup>+</sup>, the input menu (Fig. 12) appears.


In the lower part of the display, a selection field (Fig. 12/1) appears with letters, numbers and arrows which can be used to compose the input line (Fig. 12/2).


numbers in the selection field (Fig. 12/3).

- Confirm the selection (Fig. 12/3).
- Œ Delete the input line.
  - A↔a Switch between upper and lower case.
  - Confirm the text entered.

The arrows  $\leftrightarrow$  in the selection field (Fig. 12/4) allow movement in the text line.

The arrow  $\blacktriangleleft$  in the selection field (Fig. 12/4) deletes the last entry.











#### 4.3.1 Selection of options








#### 4.3.2 Toggle function

Switching functions on/off:

- Press function key (Fig. 14/2) once
- $\rightarrow$  Function **on** (Fig. 14/1).
- Again press function key
- → Function off.





#### 4.4 Software version

This operating manual is valid from software version::


Machine:

Terminal:

MHX-version: 2.17.01 IOP-version: 6.2.22 BIN-version: 3.22.0 IOP-version: 3.4.1



#### 4.5 Hierarchy of the **AMATRON**<sup>+</sup>



#### 5 Operation

#### 5.1 Start screen

Having switched on the terminal, with the machine connected, the start menu will appear. It shows the terminal software version. After approx. 2 seconds **AMATRON**<sup>+</sup> automatically jumps into the main menu.

After switching on the terminal **AMATRON**<sup>+</sup> may load data from the machine's job computer after, for example

- installation of a new job computer,
- installation of a new AMATRON<sup>+</sup> terminals,
- a RESET of the **AMATRON<sup>+</sup>** terminal

the start screen will show this message.

#### 5.2 Main menu

- order Job menu (see page 26)
- o Data entry for new job.
- o Start job before beginning spreading.
- o The data for up to 20 jobs are stored

#### drill calibr

- (see page 27)
- o always carry out a calibration test prior to any sowing operation.



(see page 18)

o Input of machine-specific or individual data.

Setup

**Setup** menu (page 31)

o Input of basic settings





Fig. 15


machine type	2:	AD-P	Order		
order No.:		6	drill calibr.		
tramline rhy	thm No.:	15			
working widt	h:	2.5m	machine		
pre-sel.spee calibration	d: fac.:	5 km/h 1.05	-		
ω	orking menu	aid	- Setup		




#### 5.3 Machine data menu



 I./100m Maschine (see chapter 5.3.3).





 $\rightarrow$  standard value: 1



- Schlerper Tractor equipped with distance sensor (yes/no).
- → Impulses via tractor signal socket.





# 5.3.1 Tramline rhythm (machine data

Tramline					_		_							
rhythm	1	2	3	4	5	6	7	8	9	10	11	12	13	14
	0	0	0	0	0	0	0	0	0	1	1	0	0	0
	1	0	1	1	1	1	1	1	1	2	0	1	1	1
		1	2	2	2	2	2	2	2	3	3	2	2	2
		2		3	3	3	3	3	3	0	4	3	3	3
er					4	4	4	4	4	5	5	4	4	4
unt						5	5	5	5	6	6	5	5	5
Tramline counter							6	6	6	0	7	6	6	6
line								7	7	8	8	7	7	7
ram									8	9	0	8	8	8
F										10	10	9	9	9
												10	10	10
												11	11	11
													12	12
														13
Tramline rhythm	15	16	17	20	21	22	23	26	32					
	1	0	0	0	0	0	0	0	0					
		1	1	1	0	0	0	1	0					
	ல்	2	2	2	1	1	1	2	1					
		3	3	3	2	2	2	3	2					
	line	4	4	4	3	3	3	4	3					
	'am	5	5	5	4	4	4	5	4					
ъ	ly ti	6	6	6		5	5	6	5					
Tramline counter	s not create any tramlines.	7	7	7		6	6	7	6					
CO	eat.	8	8	8			7	8	7					
line	ot cr	9	9	9			8	9	8					
ram	s nc	10	10					10	9					
<b>F</b>	loe	11	11						10					
	Rhythm 15 doe	12	12											
	ш	13	13											
	hyt	14	14											
	Ř	15	15											
			16											

#### Refer to the following tables for the number of the tramline rhythm.



	Double tramline control																			
Fahras- senrhythmus	18 left hand	18 right hand	19 left hand	19 right hand	24 left hand	24 right hand	25 left hand	25 right hand	27 left hand	27 right hand	28 left hand	28 right hand	29 left hand	29 right hand	30 left hand	30 right hand	31 left hand	31 right hand	33 left hand	33 right hand
	1	1	1	1	1	1	1	1	1	1	1	0	1	1	1	1	1	1	1	1
	2	2	2	2	2	0	2	0	2	0	2	2	2	0	0	2	2	2	2	2
	0	3	3	0	3	3	3	3	3	3	0	3			3	3	0	3	3	3
	4	4	4	4	0	4	4	4	4	4	0	4			4	4	4	4	4	4
	5	5	5	5	5	5	5	5	0	5	5	5			5	0			0	5
	6	6	6	6	6	6	0	6	0	6	6	0			6	6			6	6
Fahrgassenzähler	7	0	0	7	0	7	7	7	7	7									7	7
zäh	8	8	8	8	8	8	8	8	8	8									8	8
sen	9	9	9	9	9	0	0	9	9	0									9	9
ase	10	10	10	10	10	10	10	10	10	10									10	10
hrg	11	11	11	11			11	11												
Fa	12	0	0	12			12	12												
	13	13	13	13			13	0												
	14	14	14	14			14	14												
	15	15	15	15																
	0	16	16	0																
	17	17	17	17																

# 5.3.2 Input of the sown and unsown distances (m) for the intermittent tramline (Machine data

11111
NAU

.

18

18

WIND Setting the sowing distance (m) when the intermittent tramline function is switched on.

Setting the non-sowing distance (m) when the intermittent tramline function is switched on.

18 18

m	
m	
	m





#### 5.3.3 Calibration of forward speed sensor (Machine data

The adjustment of seed rate, the acccumulation of the worked area or an indication of forward speed, **AMATRON**<sup>+</sup> requires the impulses of the seed drill drive wheel over a measured distance of 100 m.

The value 'Imp./100m' is the number of impulses, that **AMATRON**<sup>+</sup> receives during the calibration distance from the seed drill drive wheel.

Slip on the seed drill drive wheel may vary in changeable soil types (e.g. from heavy to light land) resulting in a change of the value Imp./100m.

It is necessary to determine the 'Imp./100m' value:

- prior to the initial operation
- in changeable soils (wheel slip)
- in cases of a deviation between the seed rate determined by the calibration test and the quantity of seed applied in the field
- in case of deviation between the displayed and the actual area drilled.

For a manual input of that value for a subsequent operation in the same field the 'Imp./100 m' calibrated value can be entered into the table (Fig. 23).



The calibration figure "Imp./100m" may never be smaller than "250", as otherwise **AMATRON**<sup>+</sup> does not operate properly.

There are two protential possibilities to enter the Imp/100m:

- manual Entry
- The value is known and is entered manually on the **AMATRON**<sup>+</sup> termina (see Fig. 23).

Start

• The value is unknown and will have to be determined by driving down a measured calibration distance of 100 m.

enter value for impulses/100m or calibrate automatically.	manual Entry
	Start
actual 1107 Imp/100m	



Calibration travel by driving down a test distance:

- 1. Carefully measure the test distance of 100 m in the field..
- 2. Mark beginning and end of the test distance (Fig. 19).

- 3. Start calibration.
- 4. Carefully drive test distance from the beginning to the end mark.

when driving off the counter jumps back to 0.

- → The determined impulses are continuously shown on the display.
- 5. Stop after 100 m.
- → The display now shows the final determined number of impulses.
- 6. Input the value 'Imp./100m'.
- or

Reject the new value 'Imp./100m'..



If an all-wheel drive is used on the field, it must also be switched on during distance sensor calibration.




Fig. 22



#### Operation

		A	)-P						
The "Imp./100m" calibration value depends on both	AD-I Sup	AD-I Spe since 0	cial	AD-P02 Profi		RP-AD- PO2 Profi			
the seed drill model and the soil type!	without	with	without	with			Pneumatic tyre packer Pack Top seed drills		
	full electric	full electric metering		full electric metering					
		Cal	ibration v	alue "Im	pulse/100	)m"			
Theoretical value	1575	1623	1409	1623	10	52	11	75	
Field 1									
Field 2									
		AV	ANT	ı					
The "Imp./100m" calibration value	FPS PSK PSF	<b>W</b> /	FRS PSH PSI	<b>(W</b> /	FPS Ava since 0	ant	FRS 03 Avant since 01.200		
depends on both the seed drill	since 08	8.2006	since 0						
model and the	without	with	without	with	without	with	without	with	
soil type!!	full electric	full electric metering			full electric metering		full electric metering		
		Calibration value "Impulse/100m"							
Theoretical value	1409	1623	1409	1623	1502	1623	1558	1623	
Field 1									
Field 2									




#### 5.3.4 Seed rate reduction during tramline creation

Refer to the following tables for the ecommended % of the seed rate reduction of the table.

Working width	Number of seed coulters	Number of tramline coulters	Recommended % seed rate reduction during tramline creation
	24	4	17%
3,0 m	30	4	13%
5,0 11	24	6	25%
	30	6	20%
	32	4	12%
4,0 m	40	4	10%
4,0 11	32	6	19%
	40	6	15%
	36	4	11%
4,5 m	44	4	9%
<del>4</del> ,5 m	36	6	17%
	44	6	14%
6,0 m	48	4	8%
0,0 11	48	6	12%



#### 5.4 Starting a job



When the Job menu is opened, the most recently started (most recently processed) job appears.

Information on max. 20 jobs can be stored (job numbers 1 to 20).

Ъ To create a new job, select a job number (Fig. 25/1).

Enter name

Han


- Hote Enter note
- all data in this existing job is deleted
- $\Box$  Starting the job so that data for this <u>start</u> job can be accumulated.


ka/h K/na

- Enter desired application rate.
- Enter the kind of seed, the 1000grain weight and the seed count.

Delete the data of day Delete daily data

- Worked area (ha/day) 0
- Quantity applied (amount/day) 0
- Working hours (hours/day) 0













Fig. 26

#### 5.4.1 External job

Via a PDA computer an external job can be transferred into **AMATRON**<sup>+</sup> and started.

This order always takes job number 21.

The data transfer takes place via the serial interface



Ruftrags-Nr.: Sollmenge:	21 25.00	3	externen Auftrag beenden
_		nereien	
1000-Korn-Gewicht:	100.0	9	Sorte
CalFaktor:	1.00	3	
fertige ha: Stunden:	0.00 0.0		kg/ha () K/m <sup>2</sup>
ausgeb.Menge:	Ø	kg	

Fig. 27

#### 5.5 Calibration

The calibration test is carried out to ensure that, during the sowing operation the desired seed rate is maintained.

Always carry out a calibration test

- when changing the seed type
- in cases with the same seed type, however, with a different grain size, grain shape, bulk density or different dressing
- when changing from the main seed wheel to the fine seed wheel and vice versa
- in case of a deviation between the calibration test and the actual seed rate.



For carrying out the calibration test, see also the seed drill operating manual.



#### Operation

#### 5.5.1 Calibration of the drill with remote seed rate control

- 1. Fill the seed hopper with sufficient seed.
- As described in the operator's manual for the seed drill, place the collecting tray underneath the metering unit(s) and open the injector sluice(s).
- Kg/ha K/m<sup>2</sup>

Check/enter the desired seed rate


-Sollmenge eingeben -Getriebeposition vorwählen -Abdrehen starten -Kurbel mindesten bis Signalton drehen -abgedrehte Menge in kg eingeben	kg/ha K/m <sup>2</sup>
aktuell eingestellt: Arbeitsbreite: 2.5 m Sollmenge: 15.00kg/ha Getriebeposition: 62.5	Abdreh. starten
	29c020





This figure can also be entered via the job menu (see page 26).

- 4. Press the or keys to set the gearbox lever to an estimated position
  - o Gearbox position 50: Sowing with the main metering wheels
  - o Gearbox position 15: Sowing with the fine seed wheels



- 5. Close the inspection window on the metering wheel.
- As described in the operator's manual of the seed drill turn the star wheel clockwise with the aid of the calibration crank until all chambers of the metering wheels are filled with seed and an even seed flow is delivered into the collecting tray(s).
- 7. Empty the collecting tray(s).



start calibr.

- 8. Press and follow the advice on the display:
- As described in the operator's manual of the seed drill turn the drive wheel with the aid of the crank until the horn sounds.
   AMATRON<sup>+</sup> registers any additional

turns after the horn sounds in its calculation.

10. To accept the calibration procedure after

the horn sounds, press the key.

11. Weigh the amount of seed collected in the collecting tray(s) (bear in mind the weight of the tray) and enter the weight (kg) into the terminal.



Any balance used should weigh accurately as inaccuracy will cause deviations within the seed rate actually applied!

**AMATRON**<sup>+</sup> auomatically then calculates and sets the required gearbox position based on the calibration test data entered.

Repeat the calibration procedure to ensure the correct setting.



#### 5.5.2 Calibration of the drill with full electric metering system

- 1. Fill the seed hopper with sufficient seed.
- As described in the operator's manual for the seed drill, place the collecting tray underneath the metering unit(s) and open the injector sluice(s).



Check/enter the desired seed rate.

This figure can also be entered via the job menu (see page 26).

km∕h
start calibr
Cal. Fac.




4. enter the proposed operational speed (km/h).



5. V prior to the initial calibration set the Cal. Fac. (calibration factor) to 1.00 or a pre-calculated known value.

#### Operation





- wheels once. The priming time can be adjusted and corresponds to the running time of the pre-charger system.
- 7. Check whether the correct seed type has ben selected.
- 8. Close the inspection window on the metering wheel.
- 9. Empty the collecting trays.

start alibr

10. Press and follow the advice on the display:

- 11. Press after the horn sounds to accept the calibration procedure
- 12. Weigh the amount of seed collected in the collecting tray(s) (bear in mind the weight of the tray) and enter the weight (kg) into the terminal.

Any balance used should weigh accurately as inaccuracy will cause deviations within the seed rate actually applied!


**AMATRON**<sup>+</sup> automatically then calculates and sets the required gearbox position based on the calibration test data entered.


Repeat the calibration procedure to ensure the correct setting.





#### 5.6 **Service Setup**







- Diagnosis computer input (only for customer service).
- Diagnosis computer output (only for customer service).
- kn∕h sim. Enter simulated speed (allows continued spreading despite faulty distance sensor, see page 54).





Fig. 30


- 5=100
- Terminal setup (see page 36).
- Enter basic data (see page 32).



- RESET job computer
- Reset the machine computer to factory settings. All entered and generated data (jobs, machine data, calibration values, set-up data) will be lost.










Calibrate gearbox (see page 53)







Fig. 33





- o 1
- o 2
- o no




Fig. 34



(14)

32)



- Ĩ
- Input of the delay time for metering wheel alarm



Input of the delay time for tramline sytem alarm




+ Alarm Input of the delay time of tramline lay shaft alarm (only possible on gravity seed drills).




Input of the running time (in seconds) of the pre-charging system



- HTTTTT m Input of the working width (m)
  - ? Pre-emergence markers:
    - 0 none
    - hydr. actuated 0
    - elektr. actuated 0










Alarm trigger limit when the fan speed deviates from the desired value (in %).








Scharaushub :	nein	<u>14620</u>
Tiefenverstellung:	nein	<u>Oți</u>
	65/05	




## 5.7 Terminal set-up



Terminal Set-up is used to change display settings.

- Setup Change display settings.








Con. Set the contrast via the function fields Contrast: 60% Con or ( Set the brightness via the function fields Brightness: 60% O Ó or Tastenklick: 0n 0ff Inverting: Invert. Invert the display black  $\leftarrow \rightarrow$  white  $\angle_{\text{Invert.}}$ Reset Language: Deutsch Langua. Key for sound on/off Fig. 39 Delete the stored data via the function field Reset Con. . (see page 2 in Set-up menu, page Contrast: 61% Ćon 31). Set the language of the user interface via Are you sure that you wish to reset all data Br to the factory setting? the function field NO with ESC YES with enter key Ir Esc Exit Terminal set-up menu.. Invert. Reset The Terminal reset function resets all terminal data to the factory settings. No machine data are lost. Lansua Fig. 40



# Page 2 Page 2 of Terminal set-up



R5232 Entry of data transfer speed

		K3232
R5232 :	57600 Baud (nicht ProgModus)	₽0₽ R5232
Date:	04.01.2006	1 2 3 4 5 6 7 8 9 40 14 42 43 44 45 16 47 48 49 29 24 22 23 24 25 26 27 28 29 39
Time	10 : 12 : 53	$( \mathbf{b} )$

Fig. 41



• Delete program:



Please select the "up" and "d	he program via own" keys	delete
Program:	SPR36DE	
Size:	78kByte	
Empty memory:	448kByte	
Fig. 42	<b>1</b> 03/03	

Fig. 42



# 6 Use on the field

Ŵ	CAUTION During travel to the field and on public roads, the <b>AMATRON</b> <sup>+</sup> should always be switched off! → Incorrect use leads to the risk of accidents!
•	<ul> <li>Before seeding is started, the following information must be entered:</li> <li>Machine data (see page 18)</li> </ul>

- Job data (see page 26)
- Calibration test data (see page 27).

# 6.1 Specified quantity adjustment

### The sowing rate can be changed at will during the work at the press of a key




Each press of the key increases the sowing rate on both sides by the rate increase (page 19) (e.g. +10%).



Reset sowing rate to 100% on both sides.



Each press of the key reduces the sowing rate on both sides by the rate increase (page 19) (e.g. -10%).








The changed specified value is indicated in the work menu in kg/ha and per cent (Fig. 43).

# 6.2 Preselection for hydraulic functions

- 1. Preselect a hydraulic function via a function key.
- 2. Operate tractor control unit.
- $\rightarrow$  The preselected hydraulic function is carried out.

The hydraulic preselection functions (Fig. 44/1) are displayed in the work menu.






Options which
are switched off in the Set-up menu
do not belong to the machine equipment (options) are not indicated in the work menu (function fields are not assigned).




# 6.3 Work menu display





# 6.4 Functions in work menu

# 6.4.1 Tramline control



The tramline counter switches when the machine is raised.

Fig. 45/...

- (1) Display, tramline system switched on
- (2) Display, current tramline number
- (3) Display, tramline counter shift suppressed
- (4) Display, interval tramline control switched on




Fig. 45



Suppress shift on of tramline counter.



- 1. Stop tramline counter.
- → When the machine is raised, the tramline counter does not shift on.



----- Cancel tramline counter stop.


→ The tramline counter switches when the machine is raised.




Activating and deactivating interval tramline control



# 6.4.2 Track marker (Avant)






Select track marker function


Active track marker automatically changes at headlands.

• Display, left track marker in use, right track marker not in use (Fig. 46)





# 6.4.3 Blocking the star wheel



Block star wheel lowering

- Only soil working, no sowing.
- Machines without full dosing: For machine calibration.



- When the machine is lowered, the star wheel is kept raised.
- 2. Cancel preselection.





Fig. 47

# 6.4.4 Switching part widths (Avant with electric full dosing)



For sowing on half a working width, one part width can be switched off.

Fig. 48: Display: left part width switched off





Fig. 48



# 6.4.5 Electric full dosing



- At the start of sowing: When starting from standstill, activate full dosing in order to ensure sufficient seed discharge over the first metres.
- To fill the seed wheels before calibration.






Fig. 49

 → The predosing provides the coulter with seed for a specified running period (Fig. 49).




Electric full dosing: Switch dosing unit

In order to prevent unintended starting of the dosing unit, it can be switched off.


This may be useful, as even just minor rotations of the star wheel may cause the dosing unit to start.

Display: Dosing unit switched off (Fig. 50).






# 6.4.6 Coulter pressure and harrow pressure



The hydraulic connection for this function is marked yellow on the Avant and green on the AD-P.


- 1. Preselect coulter/harrow pressure (Fig. 51).
- 2. Operate tractor control unit.
- $\rightarrow$  Set increased pressure.
- $\rightarrow$  Set reduced pressure.







# 6.4.7 Folding the machine (Avant 03-2)



The hydraulic connection for this function is marked green.

### Fold in the machine:

1. Raise the machine.



- 2. Preselect Folding the machine.
- 3. Operate tractor control unit.
- $\rightarrow$  The machine folds in.
- $\rightarrow$  The transportation lock must engage on both sides.

### Fold the machine out:

1. Raise the machine.



- 2. Preselect Folding the machine.
- 3. Pull the cables of the transportation lock.
- $\rightarrow$  The Transportation lock is released
- 4. Operate tractor control unit.
- $\rightarrow$  The machine folds out.
- 5. When using, hold the control unit in float position.




### WARNING

To move the machine from the transport position to the working position and vice versa, it is essential to refer to the machine operating manual!



# 6.4.8 Rotary cultivator working depth




Adjusting the rotary cultivator working depth

The hydraulic connection for this function is marked yellow.


The machine is in operational position:

- Preselect rotary cultivator working depth.
- 2. Operate tractor control unit.
- $\rightarrow$  Set desired working depth.





# 6.4.9 Coulter lift



The hydraulic connection for this function is marked green.

The machine is in operational position:

- 1. Preselect coulter lift.
- 2. Operate tractor control unit.
- $\rightarrow$  Raise / lower the coulter.





Fig. 53


# 6.4.10 Front tank lighting (Avant)





# 6.5 Advice on field operation

- 1. switch **AMATRON**<sup>+</sup> on.
- 2. Select the desired job from the main menu and re-check settings.
- 3. starten start job
- 4. select operational menu.
- 5. set the bout marker to the first run in the field.
- 6. set tramline bout counter for the first run in the field.



- Start the sowing operation. During the sowing operation AMATRON<sup>+</sup> displays the operation menu. From here the sowing operation can be controlled.
- 8. The determined data will be stored in the started job.

After finishing operation:


- 1. Check job data (if required).
- 2. Move the machine to the transport position.
- 3. **AMATRON<sup>+</sup>** ausschalten.



#### 6.5.1 Key assignment in work menu **AD-P** with gearbox




# Description of the function fields:




#### 6.5.2 Key assignment in work menu AD-P with full dosing

### Page 1:



Shift key pressed:




# Description of the function fields:

Description of the function fields:






# 6.5.3 Layout menu - joystick **AD-P**





# 6.5.4 Key assignment in work menu **Avant** with gearbox




page 1:


ф




# 6.5.5 Key assignment in work menu **Avant** with full dosing



Description of the function fields:







# 7 Joystick

# 7.1 Fitting

Attach the joystick (Fig. 54/1) by using 4 bolts within convenient reach in the tractor cab.

Insert the plug of the basic equipment into the 9pin Sub-D socket of the joystick (Fig. 54/2).

Insert the plug (Fig. 54/3) of the joystick into the mid Sub-D socket of **AMATRON**<sup>+</sup>.




Fig. 54

# 7.2 Function

The joystick only functions in the operational menu of **AMATRON**<sup>+</sup> It allows the blind actuation of **AMATRON**<sup>+</sup> during operation in the field.


For the actuation of **AMATRON**<sup>+</sup> the joystick (Fig. 55) provides 8 keys (1 - 8). In addition the coverage of the keys can be changed 3 times by the switch (Fig. 56/2).

As standard the switch is in the


- Imposition (Fig. 56/A) and can be moved
- IP upwards (Fig. 56/B) or
- Indownwards (Fig. 56/C).

The position of the switch is indicated by a LED light (Fig. 56/1).

- IED- indication yellow
- 🕨 indication red
- LED- indication green









# 7.3 Key layout:

Vario gearbox     with full electric metering     Vario gearbox     with full electric metering       1		AD-P	AD-P	AVANT	AVANT	
2       Switching on the left hand part width shut-off         3       Switching of the left hand part width shut-off         4       Switching of the left hand part width shut-off         5       Switching of the left hand part width shut-off         6       Switching on or off intermittent tramline control         7       Switching on or off intermittent tramline control         8       Switching on or off intermittent tramline control         2       Start the pre-charger         3       Switching the tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (-1)         7       - Amount 100%         5       - Amount 1%         4       - Amount 1%         5       - Amount 1%         4       - Switching on and off the hopper fill light         3       Switching on and off the hopper fill light         5       - Amount 1%         4       Switching on / off the right hand part width shut-off						
3       Switching on the left hand part width shut-off         4       Switching off the left hand part width shut-off         5       Switching on the right hand part width shut-off         6       Switching on the right hand part width shut-off         8       Switching on or off intermittent tramline control         1       Switching on or off intermittent tramline control         2       Switching on or off intermittent tramline control         2       Start the pre-charger         3       Switching the tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (Intermittent tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (-1)         7       - Amount [%]         3       - Amount [%]         4       - Amount [%]         5       - Amount [%]         5       - Switching on and off the hopper fill light         3       - Switching on indice value to actuate the bout markers         5       - Switching on and off the opper fill light         3       - Switching on indice value to actuate the bout markers	1 🔛					
3       hand part width shut-off         4       Switching off the left hand part width shut-off         5       Switching on the right hand part width shut-off         6       Switching on or off intermittent tramline con- trol         1       Switching on or off intermittent tramline con- trol         2       start the pre-charger (key)         3       Over-riding the tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (-1)         6       Advancing the tramline bout counter (-1)         7       - Amount 100%         5       - Amount [%]         1       - Switching on and off the hopper fill light         3       Switching on and off the hopper fill light         3       Switching on and off the hopper fill light         3       Switching on and off the hopper fill light         3       Switching on and off the hopper fill light         3       Switching the hydraulic valve to actuate the bout markers         5       -         6       -         7       -         7       -	2					
4       hand part width shut-off         5       Switching on the right hand part width shut-off         6       Switching off the right hand part width shut-off         7       Switching on or off intermittent tramline con- trol         2       Switching on or off intermittent tramline con- trol         3       Over-riding the tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (+1)         6       Advancing the tramline bout counter (-1)         7       - Amount 100%         5       Advancing the tramline bout counter (-1)         7       - Amount 1%         4       Switching on and off the hopper fill light         3       Switching on or off the right hand part width shut-off         4       Switching on or off intermittent transine bout counter (-1)         7       - Amount 1%         4       Switching on and off the hopper fill light         3       Switching on or off the right hand part width shut-off	3 🄛				hand part width	
5       right hand part width shut-off         6       Switching off the right hand part width shut-off         7       Switching on or off intermittent tramline con- trol         1       Switching on or off intermittent tramline con- trol         2       start the pre-charger         3       Over-riding the tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (+1)         6       Retarding the tramline bout counter (-1)         7       - Amount [%]         3       - Amount [%]         4       - Amount [%]         5       - Switching on / off the right hand part width shut-off         5       - Switching on and off the hopper fill light         5       - Switching on / off the right hand part width shut-off	4 🔛					
6       right hand part width shut-off         7       right hand part width shut-off         8       start the pre-charger         1       Switching on or off intermittent tramline control         2       start the pre-charger         3       Over-riding the tramline bout counter (Stop key)         4       Amount 100%         5       Advancing the tramline bout counter (+1)         6       Retarding the tramline bout counter (-1)         7       - Amount [%]         8       + Amount [%]         1       - Amount [%]         8       + Amount [%]         1       Switching on and off the hopper fill light         3       Switching on / off the right hand part width shut-off         4       Switching on / off the right hand part width shut-off	5 🎞				right hand part width	
8       Switching on or off intermittent tramline control       Switching on or off intermittent tramline control         2       start the pre-charger	6 🄛				right hand part width	
1       Switching on or off intermittent tramline control       Switching on or off intermittent tramline control         2       start the pre-charger       —       start the pre-charger         3       Over-riding the tramline bout counter (Stop key)       Over-riding the tramline bout counter (Stop key)         4       Amount 100%       Amount 100%         5       Advancing the tramline bout counter (+1)       Advancing the tramline bout counter (+1)         6       Retarding the tramline bout counter (-1)       Retarding the tramline bout counter (-1)         7       - Amount [%]       + Amount [%]         1       Switching on and off the hopper fill light         3       Switching on / off the right hand part width shut-off         5       -       -         6       -       -         7       -       -	7 🔛					
trol       trol       trol         2       start the pre-charger	8					
3       Over-riding the tramline bout counter (Stop key)       Over-riding the tramline bout counter (Stop key)         4       Amount 100%       Amount 100%         5       Advancing the tramline bout counter (+1)       Advancing the tramline bout counter (+1)         6       Retarding the tramline bout counter (-1)       Retarding the tramline bout counter (-1)         7       - Amount [%]       - Amount [%]         1       - Amount [%]       + Amount [%]         2       Switching on and off the hopper fill light         3       Switching on / off the right hand part width shut-off         4       Switching the hydraulic valve to actuate the bout markers         5       -         7       -	1 🖿	•		-		
3       key)       key)         4       Amount 100%       Amount 100%         5       Advancing the tramline bout counter (+1)       Advancing the tramline bout counter (+1)         6       Retarding the tramline bout counter (-1)       Retarding the tramline bout counter (-1)         7       - Amount [%]       - Amount [%]         8       + Amount [%]       + Amount [%]         1       -       Switching on and off the hopper fill light         3       Switching on / off the right hand part width shut-off         4       Switching the hydraulic valve to actuate the bout markers         5       -         7       -	2 🗁		start the pre-charger	—	start the pre-charger	
5       Advancing the tramline bout counter (+1)         6       Retarding the tramline bout counter (-1)         7       - Amount [%]         8       + Amount [%]         1       - Amount [%]         2       Switching on and off the hopper fill light         3       Switching on / off the right hand part width shut-off         4       Switching the hydraulic valve to actuate the bout markers         5       -         7       -	3 🗁	-	•		•	
6     Retarding the tramline bout counter (-1)     Retarding the tramline bout counter (-1)       7     - Amount [%]     - Amount [%]       8     + Amount [%]     + Amount [%]       1     -     -       2     Switching on and off the hopper fill light       3     Switching on / off the right hand part width shut-off       4     Switching the hydraulic valve to actuate the bout markers       5     -       7     -	4 🗁	Amount 100%		Amount 100%		
7     - Amount [%]     - Amount [%]       8     + Amount [%]     + Amount [%]       1     -     -       2     Switching on and off the hopper fill light       3     Switching on / off the right hand part width shut-off       4     Switching the hydraulic valve to actuate the bout markers       5     -       7     -	5 🖿	Advancing the tramline bout counter (+1)		Advancing the tramline bout counter (+1)		
8     + Amount [%]     + Amount [%]       1     -     -       2     -     Switching on and off the hopper fill light       3     -     Switching on / off the right hand part width shut-off       4     -     Switching the hydraulic valve to actuate the bout markers       5     -     -       6     -     -	6 🗁	Retarding the tramline bout counter (-1)		Retarding the tramline bout counter (-1)		
1     Switching on and off the hopper fill light       2     Switching on / off the right hand part width shut-off       4     Switching the hydraulic value to actuate the bout markers       5     Switching the hydraulic value to actuate the bout markers       7     Switching the hydraulic value to actuate the bout markers	7 🖿	- Amount [%]		- Amount [%]		
2       Switching on and off the hopper fill light         3       Switching on / off the right hand part width shut-off         4       Switching the hydraulic valve to actuate the bout markers         5       Switching the hydraulic valve to actuate the bout markers         7       Switching the hydraulic valve to actuate the bout markers	8 🗁	+ Amount [%]		+ Amount [%]		
3     Switching on / off the right hand part width shut-off       4     Switching the hydraulic valve to actuate the bout markers       5     Switching the hydraulic valve to actuate the bout markers       7     Switching the hydraulic valve to actuate the bout markers	1					
3 In Section 1     Switching the hydraulic value to actuate the bout markers       5 In Section 2     Switching the hydraulic value to actuate the bout markers       6 In Section 2     Section 2       7 In Section 2     Section 2	2			Switching on and of	f the hopper fill light	
4 H         bout markers           5 H	3 🏷					
	4 🏧					
	5					
	6 🗖					
8	7 🏷					
	8 🗁					




# 8 Maintenance

# 8.1 Calibration of gearbox

### Not required for machines with full dosing!

Calibrating seed drills which are equipped with the Vario gearbox,


- prior to initial operation if AMATRON<sup>+</sup> has not been factory fitted to the machine, but has been retrofitted.
- in case of a deviation between the display on the terminal and the gearbox scale.



Calibration of gearbox:



the gearbox lever back to zero until the LED on the electric seed rate control motor lights up





# ∽

o a figure larger than 80 on the scale



Confirm the setting and enter the figure that is indicated, on the scale, by the gearbox setting lever in the now open input block.



0

Read the figure off the scale only when directly in front in order to avoid any reading errors!


 After the calibration procedure move the gearbox setting lever to another figure. The indicated value should correspond to the scale value.



# 9 Helpmenu

The help menu (Fig. 58) is opened from the main menu:

Help menu:



aid 1.aid for actuation	1
2.aid for fault messages	2
3.tramline rhythms	3

Fig. 58

# 10 Malfunction

# 10.1 Alarm

## Warning message:


A warning message (Fig. 59) appears at the bottom of the display and the audible alarm sounds three times. Remedy fault as soon as possible.

Example:

- Warning: Seed hopper contents low.
- $\rightarrow$  Remedy: Refill seed hopper.


machine type:	AD-P	Order
order No.:	6	drill calibr.
tramline rhythm No.: working width:	15 2.5m	machine
pre-sel.speed: calibration fac.: level to low	5 km/h 1.05	Setup

# Fig. 59



The error message (Fig. 60) appears in the middle of the display and the audible alarm sounds.

1. Read alarm message on the display.






Fig. 60



# **10.2** Failure of the forward speed sensor

With the failure of the forward speed sensor (Imp./100m), which is attached to the gearbox or with the electric drive option on the land wheel, operation can be continued after the input of a simulated forward speed.

The failure of the forward speed sensor is indicated by the "seed drill lifted" mode on the display ("Drille angehoben").

In order to avoid possible sowing errors, exchange the defective sensor as soon as possible.

However, if a new sensor is not available in the short term, the sowing operation can continue as follows:

- 1. Remove the signal cable from the tractor basic equipment.
- 2. Actuate from the main menu.
- 3. Confirm change of menu.
- 4. Enter a simulated speed.
- 5. Maintain the simulated speed as you continue spreading.

total data since starting oper.: tot.area: 59874ha tot.drill.time: 123h simulated km/h: 0.0km/h MHX-Version: 2.09 IDP-Version: 5.0.2 AW -Gaste/AG-429



As soon as impulses are sensed from the forward speed sensor the computer automatically changes over to the actual speed from the forward speed sensor..



# **AMAZONEN-WERKE**

H. DREYER GmbH & Co. KG

P. O. Box 51 Germany

Tel.: + 49 (0) 5405 501-0 D-49202 Hasbergen-Gaste Telefax: + 49 (0) 5405 501-234 e-mail: amazone@amazone.de www.amazone.de http://

> Branch factories: D-27794 Hude • D-04249 Leipzig • F-57602 Forbach Subsidiaries: in England and France

Factories for mineral fertiliser spreaders, field sprayers, seed drills, soil cultivation equipment, multi purpose storage halls and groundcare municipal machinery