

**AMACO** Brief instructions

<b>Code</b>	<b>D8 SPECIAL</b>	
	Tyres 5.00-16	
<b>F. 1</b>	2.5 m	Working width
<b>F. 2</b>	3.0 m	
	<b>D8 SPECIAL D8 SUPER MD 8</b>	
	Tyres 6.00-16	
<b>F. 3</b>	2.5 m	Working width
<b>F. 4</b>	3.0 m	
	<b>D8 SUPER MD 8</b>	
	Tyres 10.0/75-15	
<b>F. 5</b>	3.0 m	Working width
<b>F. 6</b>	4.0 m	
	<b>D8 SUPER MD 8</b>	
	Tyres 31x15.50-15	
<b>F. 7</b>	3.0 m	Working width
<b>F. 8</b>	4.0 m	
<b>F. 9</b>	6.0 m	
	<b>D8 SUPER</b>	
	Tyres 11.5/80-15	
<b>F. 10</b>	4.5 m	Working width
<b>F. 11</b>	6.0 m	
	<b>AD 02 AD-P 02</b>	
	With star wheel diameter 1.18m	
<b>F. 12</b>	2.5 m	Working width
<b>F. 13</b>	3.0 m	
<b>F. 14</b>	4.0 m	
<b>F. 15</b>	4.5 m	
	<b>RP-AD 02 RP-AD-P 02</b>	
<b>F. 16</b>	2.5 m	Working width
<b>F. 17</b>	3.0 m	
<b>F. 18</b>	4.0 m	
<b>F. 19</b>	4.5 m	
<b>F. 20</b>	6.0 m	
	<b>ED 01/02, RP-ED 01/02</b>	
<b>F. 21</b>	2.7 m	Working width
<b>F. 22</b>	3.0 m	
<b>F. 23</b>	3.2 m	
<b>F. 24</b>	3.6 m	
<b>F. 25</b>	4.0 m	
<b>F. 26</b>	4.2 m	
<b>F. 27</b>	4.5 m	
<b>F. 28</b>	4.8 m	
<b>F. 29</b>	5.4 m	
<b>F. 30</b>	6.0 m	
<b>F. 31</b>	6.4 m	

**Programming the code**

1. Press **F key** for 2 seconds until coding flashes.
2. Press **ha key** repeatedly until correct coding appears.
3. Press **F key** for 2 seconds until flashing stops.

**Indicating surface**

1. Press **ha key**, e.g. **12.73** = 12.73 ha = 127300 m<sup>2</sup>.

**Deleting memory**

1. Press **ha key** for approx. 2 seconds until display shows **0.000**.

**Switching off computer**

1. Press **ha key** and **F key** until display **STOP** appears.

**AMACO** Brief instructions

<b>Factor</b>	<b>D9</b>
<b>216.3</b>	Tyres 6.00
<b>225.0</b>	Tyres 10.0/75
<b>231.4</b>	Tyres 31x15.50
	<b>AD 03</b>
<b>399.2</b>	Star wheel with chain wheel 26
	<b>AD 03</b>
	Variant 3-1500 / 4-2100
<b>259.5</b>	Star wheel with chain wheel 40
	<b>RP-AD 03</b>
<b>238.3</b>	With tyre packer roller RP
	<b>AD-P Special</b>
<b>113.5</b>	With star wheel
	<b>AD-P Super</b>
<b>101.4</b>	With star wheel
	<b>C-Drill</b>
<b>306.5</b>	With star wheel

**Programming the factor and the working width under coding **F. 0******Programming the factor**

1. Press **F** key for 2 seconds (display: coding flashing).
2. Press **ha** key until display **F.0** (flashing) appears.
3. Press **F** key until the brief display of the symbol **□** and automatic display of the factor (e.g. [168.1]) which must be changed to the required value.
  - 3.1 Press **ha** key repeatedly until the decimal point is in the right place.
  - 3.2 Press **F** key: 1st figure flashes.
  - 3.3 Press **ha** key repeatedly until the 1st figure is correct.
  - 3.4 Press **F** key: 2nd figure flashes.
  - 3.5 Press **ha** key until the 2nd figure is correct.

Set the required factor in accordance with this procedure.

**Programming the working width**

4. Press **F** key until brief display of the symbol **| - - - |** and display of the working width (e.g. [12.00]), which must be changed to the required value.
    - 4.1 Press **F** key: 1st figure flashes.
    - 4.2 Press **ha** key repeatedly until the 1st figure is correct.
    - 4.3 Press **F** key: 2nd figure flashes.
    - 4.4 Press **ha** key repeatedly until the 2nd figure is correct.
- Set the required working width in accordance with this procedure.
5. Press **F** key until coding **F.0** appears.