


# Operating manual

## **AMAZONE**

### **UX 7601 Super UX 8601 Super**

Trailed field sprayer with Comfort Package CP



MG7490  
BAG0231.6 01.24  
Printed in Germany

SmartLearning



Please read this operating  
manual before initial operation.  
Keep it in a safe place for future  
use!

**en**



# READING THE INSTRUCTION

*manual and to adhere to it should not appear to be inconvenient and superfluous as it is not enough to hear from others and to realise that a machine is good, to buy it and to believe that now everything would work by itself. The person concerned would not only harm himself but also make the mistake of blaming the machine for the reason of a possible failure instead of himself. In order to ensure a good success one should go into the mind of a thing or make himself familiar with every part of the machine and to get acquainted with its handling. Only this way, you would be satisfied both with the machine as also with yourself. To achieve this is the purpose of this instruction manual.*

---

*Leipzig-Plagwitz 1872. Rud. Sark.*

---

**Identification data**

---

Manufacturer: AMAZONEN-WERKE  
H. DREYER SE & Co. KG

Implement ID No.

Type:

Permissible system pressure (bar):

Year of manufacture:

Factory:

Basic weight (kg):

Permissible total weight (kg):

Maximum load (kg):

---

**Manufacturer's address**

---

AMAZONEN-WERKE  
H. DREYER SE & Co. KG  
Postfach 51  
D-49202 Hasbergen, Germany  
Tel.: + 49 (0) 5405 50 1-0  
E-mail: [amazone@amazone.de](mailto:amazone@amazone.de)

---

**Spare part orders**

---

Spare parts lists are freely accessible in the spare parts portal at [www.amazone.de](http://www.amazone.de).  
Please send orders to your AMAZONE dealer.

## Formalities of the operating manual

---

Document number: **MG7490**  
Compilation date: 01.24

© Copyright AMAZONEN-WERKE H. DREYER SE & Co. KG, 2022

All rights reserved.

Reprinting, even of sections, only possible with the approval of AMAZONEN-WERKE H. DREYER SE & Co. KG.

**This operating manual is valid for all versions of the implement.**

**All of the equipment is described without indicating it as special optional equipment.**

A description may be provided for equipment that is not fitted on the implement or is only available in certain markets. The sales documents provide information on the equipment of your implement or consult your dealer for more detailed information.

**All information in this operating manual corresponds to the state of knowledge at the time of publication. Due to ongoing development of the implement, deviations are possible between the implement and the information in this operating manual.**

**No claims can be made based on differences in the specifications, figures or descriptions.**

Figures serve as a reference and are to be understood as representations of the principle.

If you want to sell the implement, ensure that the operating manual is supplied with the implement.



---

## Foreword

---

Dear Customer,

You have chosen one of the quality products from the wide product range of AMAZONEN-WERKE, H. DREYER SE & Co. KG. We thank you for your trust in our products

On receiving the implement, check to see if it has been damaged during transport or if parts are missing. Using the delivery note, check that the implement has been delivered in full, including any special equipment ordered. Damage can only be rectified if problems are claimed immediately.

Before initial operation, read and observe this operating manual, and particularly the safety information. Only after careful reading will you be able to benefit from the full scope of your newly purchased implement.

Please ensure that all the implement operators have read this operating manual before they put the implement into operation.

Should you have any questions or problems, please consult this operating manual or contact your local service partner.

Regular maintenance and timely replacement of worn or damaged parts increases the lifespan of your implement.

---

## User evaluation

---

Dear Reader,

We update our operating manuals regularly. Your suggestions for improvement help us to create ever more user-friendly operating manuals.

AMAZONEN-WERKE

H. DREYER SE & Co. KG

Postfach 51

D-49202 Hasbergen, Germany

Tel.: + 49 (0) 5405 50 1-0

E-mail: [amazone@amazone.de](mailto:amazone@amazone.de)

<b>1</b>	<b>User information.....</b>	<b>11</b>
1.1	Purpose of the document .....	11
1.2	Locations in the operating manual .....	11
1.3	Diagrams .....	11
<b>2</b>	<b>General safety instructions .....</b>	<b>12</b>
2.1	Obligations and liability .....	12
2.2	Representation of safety symbols .....	14
2.3	Organisational measures .....	15
2.4	Safety and protective equipment.....	15
2.5	Informal safety measures .....	15
2.6	User training .....	16
2.7	Safety measures in normal operation .....	17
2.8	Danger from residual energy.....	17
2.9	Maintenance and repair work, fault elimination.....	17
2.10	Design changes.....	17
2.10.1	Spare and wear parts and aids .....	18
2.11	Cleaning and disposal .....	18
2.12	User workstation.....	18
2.13	Warning symbols and other markings on the machine .....	19
2.13.1	Positions of warning symbols and other labels .....	20
2.14	Dangers in case of non-observance of the safety instructions .....	29
2.15	Safety-conscious working .....	29
2.16	Safety information for users .....	30
2.16.1	General safety instructions and accident prevention instructions.....	30
2.16.2	Hydraulic system .....	33
2.16.3	Electrical system .....	34
2.16.4	PTO shaft operation .....	34
2.16.5	Attached implements.....	36
2.16.6	Brake system.....	36
2.16.7	Tyres .....	37
2.16.8	Field sprayer operation .....	38
2.16.9	Cleaning, maintenance and repair .....	40
<b>3</b>	<b>Loading and unloading.....</b>	<b>41</b>
<b>4</b>	<b>Product description .....</b>	<b>42</b>
4.1	Overview of assembly groups .....	42
4.2	Safety and protection equipment .....	44
4.3	Supply lines between the tractor and the implement .....	45
4.4	Transportation equipment .....	45
4.5	Intended use.....	46
4.6	Implement inspection .....	47
4.7	Consequences of using certain crop protection agents.....	47
4.8	Danger areas and danger points.....	48
4.9	Rating plate .....	49
4.10	Conformity .....	49
4.11	Technically possible maximum application rate .....	49
4.12	Maximum permissible application rate .....	50
4.13	Technical data .....	51
4.13.1	Total dimensions .....	51
4.13.2	Basic implement.....	51
4.13.3	Spraying technology.....	52
4.13.4	residual amounts .....	53
4.13.1	Payload .....	54

4.14	Noise production data .....	55
4.15	Necessary tractor equipment.....	56
<b>5</b>	<b>Layout and function of the basic implement.....</b>	<b>57</b>
5.1	Method of operation .....	57
5.2	Control panel.....	58
5.3	Induction bowl .....	63
5.3.1	Switch taps on the induction bowl.....	64
5.4	Universal joint shaft.....	65
5.4.1	Coupling the universal joint shaft.....	67
5.4.2	Uncoupling the universal joint shaft .....	68
5.5	Hydraulic connections.....	69
5.5.1	Coupling the hydraulic hose lines .....	71
5.5.2	Uncoupling the hydraulic hose lines .....	71
5.6	Pneumatic brake system.....	72
5.6.1	Coupling the brake system .....	74
5.6.2	Uncoupling the brake system.....	75
5.7	Hydraulic operating brake system .....	76
5.7.1	Coupling the hydraulic service brake system .....	76
5.7.2	Uncoupling the hydraulic service brake system.....	76
5.7.3	Emergency brake .....	76
5.8	Parking brake .....	78
5.9	Foldable wheel chocks.....	79
5.10	Safety chain between tractor and implements.....	80
5.11	AutoTrail steering axle .....	81
5.12	Hydraulic jack.....	82
5.13	Spray liquid tank .....	83
5.13.1	Agitators .....	84
5.13.2	Maintenance platform with ladder .....	85
5.14	Flushing water tank.....	86
5.15	Hand wash unit .....	87
5.16	Pump equipment.....	88
5.17	Filter equipment .....	89
5.17.1	Suction filter .....	89
5.17.2	Self-cleaning pressure filter .....	90
5.17.3	Nozzle filters.....	90
5.18	Application rate increase with HighFlow .....	91
5.19	Towing device (optional).....	92
5.20	Safety device against unauthorised use .....	93
5.21	Underbody panelling .....	93
5.22	Drag hose pre-equipment .....	93
5.23	Exterior wash down kit (optional).....	94
5.24	Camera system .....	95
5.25	Work lights (optional) .....	96
5.26	Control terminal.....	97
5.27	Personal protective equipment Safety Kit.....	97
<b>6</b>	<b>Layout and function of the sprayer boom .....</b>	<b>98</b>
6.1	Super-L boom .....	101
6.2	Reduction joint on the outer boom (optional).....	104
6.3	Boom width reduction (option) .....	105
6.4	Boom extension (option).....	106
6.5	Hydraulic tilt adjustment (optional).....	107
6.6	DistanceControl (optional) .....	107
6.7	Spray lines .....	108

## Table of Contents

6.8	Nozzles.....	110
6.8.1	Multiple nozzles.....	110
6.8.2	Edge nozzles.....	113
6.9	Automatic single nozzle control (optional) .....	114
6.9.1	Single nozzle control AmaSwitch.....	114
6.9.2	4-way AmaSelect single nozzle control .....	114
6.10	Special optional equipment for liquid fertiliser.....	116
6.10.1	Three-ray nozzles (optional) .....	116
6.10.2	7-hole nozzles / FD nozzles (optional).....	117
6.10.3	Drag hose equipment for Super-L boom (optional).....	118
<b>7</b>	<b>Start-up .....</b>	<b>119</b>
7.1	Antifreeze in the spray liquid tank .....	119
7.2	Checking the suitability of the tractor .....	120
7.2.1	Calculating the actual values for the total tractor weight, tractor axle loads and load capacities, as well as the minimum ballast .....	120
7.2.2	Requirements for tractor operation with attached implements .....	124
7.3	Adjusting the length of the PTO shaft to the tractor.....	128
7.4	Securing the tractor / implement against unintentional start-up and rolling away .....	130
7.5	Installing the wheels.....	131
7.6	Initial operation of service brake system.....	132
7.7	Adjusting the hydraulic system.....	133
7.8	Installing the sensor for the steering axle .....	135
<b>8</b>	<b>Coupling and uncoupling the implement.....</b>	<b>136</b>
8.1	Coupling the implement .....	136
8.2	Uncoupling the implement.....	138
8.2.1	Manoeuvring the uncoupled implement .....	139
<b>9</b>	<b>Road transport.....</b>	<b>140</b>
<b>10</b>	<b>TwinTerminal for Comfort Package on the control panel.....</b>	<b>142</b>
<b>11</b>	<b>Use of the implement.....</b>	<b>145</b>
11.1	Preparing for spraying operation.....	148
11.2	Preparing the spray liquid .....	149
11.2.1	Calculating the filling and re-fill quantity.....	153
11.2.2	Filling table for remaining spray area.....	154
11.2.3	TwinTerminal filling diagram .....	155
11.2.4	Filling the spray liquid tank and flushing water tank through the suction connection .....	156
11.2.5	Filling the spray liquid tank and flushing water tank through the pressure connection.....	159
11.2.6	Adjusting the agitator .....	160
11.2.7	Flushing agents via the induction bowl .....	161
11.2.8	Spray agent suction from containers (closed transfer system).....	164
11.3	Spraying operation .....	165
11.3.1	Applying the spray liquid .....	168
11.3.2	Drift reduction measures .....	169
11.3.3	Diluting the spray liquid with flushing water .....	169
11.3.4	Residual amounts.....	170
11.3.5	Diluting the excess residue in the spray liquid tank and spraying out the diluted residue remaining at the end of spraying operations.....	171
11.3.6	Emptying the spray liquid tank using the pump .....	171
<b>12</b>	<b>Cleaning the implement after operation.....</b>	<b>172</b>
12.1	Quick cleaning of the empty field sprayer .....	173
12.2	Intensive cleaning of the empty field sprayer.....	174
12.3	Draining the final residues.....	175
12.4	XtremeClean high-pressure cleaning.....	176
12.5	Performing chemical cleaning .....	178

12.6	Cleaning the suction filter and pressure filter.....	179
12.7	Flushing the sprayer boom when the spray liquid tank is full .....	181
12.8	External cleaning .....	182
<b>13</b>	<b>Faults .....</b>	<b>183</b>
13.1	Boom too low in transport position.....	185
<b>14</b>	<b>Cleaning, maintenance and repairs.....</b>	<b>186</b>
14.1	Cleaning .....	188
14.2	Winter storage and long periods out of operation.....	189
14.3	Lubrication specifications .....	193
14.3.1	Lubrication point overview .....	194
14.4	Maintenance schedule – overview.....	198
14.5	Axle and brake .....	201
14.5.1	Cleaning the compressed air line filter on the coupling head .....	205
14.5.2	Cleaning the compressed air line filter in the brake line .....	206
14.5.3	Automatic load-dependent braking force regulator (ALB) .....	208
14.5.4	Hydraulic brakes .....	208
14.6	Parking brake .....	209
14.7	Axle fastening.....	210
14.7.1	Tyres / wheels .....	210
14.7.2	Mounting tyres (workshop work).....	211
14.8	Check the coupling device .....	212
14.9	Towing device .....	213
14.10	Hydraulic system.....	214
14.10.1	Labelling of hydraulic hose lines .....	215
14.10.2	Maintenance intervals .....	215
14.10.3	Inspection criteria for hydraulic hose lines .....	215
14.10.4	Installation and removal of hydraulic hose lines .....	216
14.10.5	Oil filter .....	217
14.10.6	Adjusting the hydraulic throttle valve .....	217
14.11	Hydro-pneumatic pressure reservoir .....	218
14.12	Settings on the unfolded sprayer boom .....	218
14.13	Electro hydraulic boom .....	219
14.14	Pump.....	220
14.14.1	Check the oil level.....	220
14.14.2	Changing the oil .....	221
14.14.3	Cleaning.....	221
14.14.4	Checking and replacing the suction and pressure-side valves (workshop work) .....	222
14.14.5	Checking and replacing the piston diaphragm (workshop work).....	223
14.15	Calibrate the flow meter .....	224
14.16	Eliminating limescale in the system .....	225
14.17	Metering the field sprayer .....	227
14.18	Nozzles .....	229
14.19	Line filter.....	230
14.20	Instructions on testing the field sprayer .....	231
14.21	Bolt tightening torques .....	234
14.22	Disposing of the field sprayer.....	235
<b>15</b>	<b>Diagrams and overviews.....</b>	<b>236</b>
15.1	Liquid circuit .....	236
15.2	Liquid circuit Part-width section control: .....	237
15.3	Liquid circuit AmaSelect single nozzle control / HighFlow+ / XTremeClean .....	238
15.4	Liquid circuit Part-width section control AmaSwitch .....	239
15.5	Actuators and sensors .....	240
15.6	Hydraulic diagram .....	241

## Table of Contents

---

15.7	Fuses and relays .....	243
15.7.1	Fuses for the boom functions .....	244
15.7.2	AmaSelect fuses on the boom .....	245
<b>16</b>	<b>Spray table .....</b>	<b>246</b>
16.1	Spray tables for flat-fan, anti-drift, injector and airmix nozzles, spraying height 50 cm.....	246
16.2	Spraying nozzles for liquid fertiliser.....	250
16.2.1	Spray table for three-ray nozzles, spraying height 120 cm.....	250
16.2.2	Spray table for 7-hole nozzles.....	251
16.2.3	Spray table for FD- nozzles.....	253
16.2.4	Spray table for drag hose unit .....	254
16.3	Conversion table for spraying ammonium nitrate / urea solution (AUS) liquid fertiliser.....	257

---

# 1 User information

---

The User Information section provides information on use of the operating manual.

## 1.1 Purpose of the document

---

This operating manual

- describes the operation and maintenance of the implement.
- provides important information on safe and efficient handling of the implement.
- is a component part of the implement and should always be kept with the implement or the towing vehicle.
- must be kept in a safe place for future use.

## 1.2 Locations in the operating manual

---

All the directions specified in the operating manual are always seen in the direction of travel.

## 1.3 Diagrams

---

### Instructions and responses

---

Activities to be carried out by the user are given as numbered instructions. Always keep to the order of the instructions. The reaction to the handling instructions is given by an arrow. Example:

1. Instruction 1  
→ Implement response to instruction 1
2. Instruction 2

### Lists

---

Lists without an essential order are shown as a list with bullets. Example:

- Point 1
- Point 2

### Item numbers in diagrams

---

Numbers in round brackets refer to the item numbers in the diagrams.

Example: (6) = Position 6

## 2 General safety instructions

---

This section contains important information on safe operation of the implement.

### 2.1 Obligations and liability

---

#### Comply with the instructions in the operating manual

---

Knowledge of the basic safety information and safety regulations is a basic requirement for safe handling and fault-free implement operation.

#### Obligations of the operator

---

The operator is obliged only to let those people work with/on the implement who

- are aware of the basic workplace safety information and accident prevention regulations.
- Have been introduced to working with/on the implement.
- have read and understood this operating manual.

The operator is obliged

- to keep all the warning symbols on the implement in a legible state.
- to replace damaged warning symbols.

#### Obligations of the user

---

Before starting work, anyone charged with working with/on the implement is obliged

- to comply with the basic workplace safety instructions and accident prevention regulations.
- To read and observe the section "General safety information" of this operating manual.
- To read the section "Warning symbols and other labels on the implement" (page 19) of this operating manual and to follow the safety instructions represented by the warning symbols when operating the implement.
- to get to know the implement.
- to read the sections of this operating manual, important for carrying out your work.

If the user discovers that a function is not working properly, then they must eliminate this fault immediately. If this is not the task of the user or if the user does not possess the appropriate technical knowledge, then they should report this fault to their superior (operator).



## Risks in handling the implement

---

The implement has been constructed to the state-of-the art and the recognised rules of safety. However, operating the implement may cause risks and restrictions

- the health and safety of the user or third parties,
- the implement,
- other property.

Only use the implement

- for the purpose for which it was intended.
- in a perfect state of repair.

Eliminate any faults immediately which could impair safety.

## Guarantee and liability

---

Our "General conditions of sales and delivery" are always applicable. These shall be available to the operator, at the latest on conclusion of the contract. Guarantee and liability claims for damage to people or property will be excluded if they can be traced back to one or more of the following causes:

- Improper use of the implement.
- Improper installation, commissioning, operation and maintenance of the implement.
- Operation of the implement with defective safety equipment or improperly attached or non-functioning safety equipment.
- Non-compliance with the instructions in the operating manual regarding commissioning, operation and maintenance.
- Unauthorised design changes to the implement.
- Insufficient monitoring of implement parts which are subject to wear.
- Improperly executed repairs.
- Disasters due to the effects of foreign objects and force majeure.

## 2.2 Representation of safety symbols

Safety instructions are indicated by the triangular safety symbol and the highlighted signal word. The signal word (danger, warning, caution) describes the severity of the risk and has the following significance:

**DANGER**

Indicates a direct threat at high risk which will result in death or most serious bodily harm (loss of limbs or long-term harm), should it not be prevented.

If the instructions are not followed, then this will result in immediate death or serious physical injury.

**WARNING**

Indicates a medium risk, which could result in death or (serious) physical injury if not avoided.

If the instructions are not followed, then this may result in death or serious physical injury.

**CAUTION**

Indicates a low risk which could cause minor or medium level physical injury or damage to property if not avoided.

**IMPORTANT**

Indicates an obligation to special behaviour or an activity required for proper machine handling.

Non-compliance with these instructions can cause faults on the machine or disturbance to the environment.

**NOTE**

Indicates handling tips and particularly useful information.

These instructions will help you to use all the functions of your machine in the best way possible.

## 2.3 Organisational measures

The operating company must provide the necessary personal protective equipment as per the information provided by the manufacturer of the crop protection agent to be used, such as:

- Chemical-resistant gloves,
- Chemical-resistant overalls,
- Water-resistant footwear,
- Face mask,
- Breathing protection,
- Protective goggles,
- Skin protection agents etc.



The operating manual

- must always be kept at the place at which the implement is operated.
- must always be easily accessible for the user and maintenance personnel.

Check all the available safety equipment regularly.

## 2.4 Safety and protective equipment

Before starting up the implement each time, all the safety and protection equipment must be properly attached and fully functional. Check all safety and protection equipment regularly.

### Faulty safety equipment

Faulty or disassembled safety and protection equipment can lead to dangerous situations.

## 2.5 Informal safety measures

As well as all the safety information in this operating manual, comply with the general, national regulations pertaining to accident prevention and environmental protection.

When driving on public roads and routes you should comply with the statutory road traffic regulations.

## 2.6 User training

Only trained and instructed persons should be allowed to work with/on the implement. The responsibilities of the operating and maintenance personnel must be clearly defined.

People being trained may only work with/on the implement under the supervision of an experienced person.

Job \ Person	Person specially trained for the activity <sup>1)</sup>	Instructed operator <sup>2)</sup>	Persons with specialist training (specialist workshop) <sup>3)</sup>
Loading/Transport	X	X	X
Start-up	--	X	--
Set-up, tool installation	--	--	X
Operation	--	X	--
Maintenance	--	--	X
Troubleshooting and fault elimination	X	--	X
Disposal	X	--	--

Key: X..permitted --..not permitted

<sup>1)</sup>A person who can assume a specific task and who can carry out this task for an appropriately qualified company.

<sup>2)</sup> Instructed persons are those who have been instructed in their assigned tasks and in the possible risks in the case of improper behaviour, have been trained if necessary, and have been informed about the necessary protective equipment and measures.

<sup>3)</sup> Persons with specialised technical training shall be considered as a specialist. Due to their specialist training and their knowledge of the appropriate regulations, they can evaluate the work with which they have been charged and detect possible dangers.

Comment:

A qualification equivalent to specialist training can be obtained from several years' experience in the relevant field.



If maintenance and repair work on the implement is additionally marked "Workshop work", only a specialist workshop may carry out such work. The personnel of a specialist workshop shall possess the appropriate knowledge and suitable aids (tools, lifting and support equipment) for carrying out the maintenance and repair work on the implement in a way which is both appropriate and safe.

## 2.7 Safety measures in normal operation

Only operate the implement if all the safety and protection equipment is fully functional.

Check the implement at least once a day for visible damage and check the function of the safety and protection equipment.

## 2.8 Danger from residual energy

Note that there may be residual mechanical, hydraulic, pneumatic and electrical/electronic energy on the implement.

Use appropriate measures to inform the operating personnel. You can find detailed information in the relevant sections of this operating manual.

## 2.9 Maintenance and repair work, fault elimination

Carry out prescribed setting, maintenance and inspection work in good time.

Secure all media such as compressed air and the hydraulic system against unintentional start-up.

Carefully fix and secure larger assembly groups to lifting gear when carrying out replacement work.

Regularly check that bolted connections are firmly secured and tightened if necessary.

When the maintenance work is completed, check the function of the safety devices.

## 2.10 Design changes

You may make no changes, expansions or modifications to the implement without the authorisation of AMAZONEN-WERKE. This also applies when welding support parts.

Any expansion or conversion work shall require the written approval of AMAZONEN-WERKE. Only use modification and accessory parts approved by AMAZONEN-WERKE so that the type approval, for example, remains valid in accordance with national and international regulations.

Vehicles with an official type approval or with equipment connected to a vehicle with a valid type approval or approval for road transport according to the German road traffic regulations must be in the state specified by the approval.



### WARNING

**Risk of crushing, cutting, being trapped or drawn in, or impact through the failure of support parts.**

It is strictly forbidden to

- drill holes in the frame or on the running gear.
- increase the size of existing holes on the frame or the running gear.
- weld on load-bearing parts.



### **2.10.1 Spare and wear parts and aids**

---

Immediately replace any implement parts which are not in a perfect state.

Only use genuine AMAZONE spare and wear parts, or those approved by AMAZONEN-WERKE, so that the operating permit remains valid according to the national and international regulations. If you use wear and spare parts from third parties, there is no guarantee that they have been designed and manufactured in such a way as to meet the requirements placed on them.

AMAZONEN-WERKE shall accept no liability for damage caused by the use of non-approved spare and wear parts or aids.

## **2.11 Cleaning and disposal**

---

Handle and dispose of any materials used carefully, in particular

- when carrying out work on lubrication systems and equipment and
- when cleaning using solvents.

## **2.12 User workstation**

---

The implement may be operated by only one person sitting in the driver's seat of the tractor.

## 2.13 Warning symbols and other markings on the machine



Always keep all the warning symbols of the machine clean and in a legible state. Replace illegible warning symbols. You can obtain the warning symbols from your dealer using the order number (e.g. MD 075).

### Warning symbols – structure

Warning pictograms indicate danger areas on the implement and warn of residual dangers. Permanent or unexpected dangers exist in these areas.

A warning symbol consists of two fields:



#### Field 1

is a symbol describing the danger, surrounded by triangular safety symbol.

#### Field 2

is a symbol showing how to avoid the danger.

### Warning symbols – explanation

The column **Order number and explanation** provides an explanation of the neighbouring warning symbol. The description of the warning symbols is always the same and specifies, in the following order:

1. A description of the danger.

For example: risk of cutting

2. The consequence of non-compliance with the risk avoidance instructions.

For example: causes serious injuries to fingers or hands.



3. The risk avoidance instructions.

For example: only touch implement parts when they have come to a complete standstill.



## 2.13.1 Positions of warning symbols and other labels

### Warning symbols

The following diagrams show the arrangement of the warning symbols on the implement.







## Order number and explanation

## Warning symbols


### MD 076

**Risk of hands or arms being drawn in or entrapped by driven, unprotected chain or belt drives!**

This danger causes serious injuries, including loss of body parts such as hand or arm.

Never open or remove protective equipment on chain or belt drives,

- while the tractor engine is running and the universal joint shaft is connected / hydraulic drive is engaged
- if the ground wheel drive is moving



### MD 078

**Risk of crushing fingers or hands by accessible moving machine parts.**

This danger causes serious injuries, including loss of body parts such as fingers or hand.

Never reach into the danger area while the tractor engine is running and the universal joint shaft / hydraulic system is connected.




### MD 082

**Danger of falling from treads and platforms when riding on the machine.**

This danger causes serious or potentially fatal injuries anywhere on the body.

It is forbidden to ride on the implement and/or climb the implement while it is running. This prohibition also applies to implements with step surfaces or platforms.

Make sure that nobody is riding on the implement.



### MD 084

**Risk of crushing the entire body due to standing in the swivel range when implement parts are being lowered.**

Causes serious, potentially fatal injuries anywhere on the body.

- It is forbidden to stand in the swivel range of the implement when implement parts are being lowered.
- Instruct personnel to leave the swivel range of any implement parts which can be lowered before you lower the parts.




### MD 089

**Risk of crushing the entire body due to standing under suspended loads or raised implement parts.**

Causes serious, potentially fatal injuries anywhere on the body.

- It is forbidden to stand under suspended loads or raised implement parts.
- Maintain an adequate safety distance from any suspended loads or raised implement parts.
- Ensure that all personnel maintain an adequate safety distance from suspended loads or raised implement parts.




### MD 094

**Risk of electric shock or burns from accidentally touching overhead power lines or by coming within the prohibited distance of high voltage overhead power lines!**

This danger causes serious or potentially fatal injuries anywhere on the body.

Keep a safe distance to the electric overhead power lines when swinging machine parts in and out.




Rated voltage	Safety distance from transmission lines
up to 1 kV	1 m
over 1 up to 110 kV	2 m
over 110 up to 220 kV	3 m
over 220 up to 380 kV	4 m

Rated voltage	Safety distance from transmission lines
up to 1 kV	1 m
over 1 up to 110 kV	2 m
over 110 up to 220 kV	3 m
over 220 up to 380 kV	4 m

## General safety instructions

### MD 095

Before commissioning the implement read and observe the operating manual and the safety instructions carefully!




### MD 096

#### **Danger from escaping high-pressure hydraulic fluid due to leaking hydraulic hose lines.**

This danger may cause serious injuries, perhaps even resulting in death, if escaping high-pressure hydraulic fluid passes through the skin and into the body.

- Never attempt to plug leaks in hydraulic hose lines with your hand or fingers.
- Read and observe the information in the operating manual before carrying out maintenance work on the hydraulic hose lines.
- If you are injured by hydraulic fluid, contact a doctor immediately.



### MD 097

#### **Risk of crushing and contusions between the rear of the tractor and the implement when coupling and uncoupling the implement!**

These dangers can cause extremely serious and potentially fatal injuries.

- It is forbidden to actuate the three-point hydraulic system of the tractor as long as persons are standing between the rear of the tractor and the machine.
- Actuate the operating controls for the tractor's three-point hydraulic system
  - Only from the intended workstation alongside the tractor.
  - Only when you are outside the danger area between the tractor and the implement.




### MD 099

#### **Risk of contact with hazardous materials due to improper handling.**

Causes serious, potentially fatal injuries anywhere on the body.


Put on the personal protective equipment.

Before coming into contact with hazardous materials, put on protective clothing. Follow the manufacturer's safety instructions for the materials to be processed




### MD 100

This symbol indicates the lifting gear attachment points used for loading of the implement.



### MD101

This symbol indicates application points for using lifting gear (jack).




### MD 102

#### **Danger from intervention in the implement, e.g. installation, adjusting, troubleshooting, cleaning, maintaining and repairing, due to the tractor and the implement being started unintentionally and rolling.**

These dangers can cause extremely serious and potentially fatal injuries.

- Secure the tractor and the implement against unintentional start-up and rolling before any intervention in the implement.
- Depending on the type of intervention, read and understand the information in the relevant sections of the operating manual.




## General safety instructions

### MD 108

**Risk of explosion, or danger from hydraulic fluid escaping under high pressure, caused by the pressure accumulator which is under pressure from gas and oil.**


These dangers can cause serious and potentially fatal injuries if highly pressurised, escaping hydraulic fluid penetrates the skin and passes into the body.

- Read and observe the instructions in the operating manual before carrying out any maintenance or repair work.
- If you are injured by hydraulic fluid, contact a doctor immediately.




### MD 114

This symbol indicates a lubrication point




### MD 118

This symbol indicates the maximum drive speed (540 rpm) and direction of rotation of the drive shaft on the machine side.




### MD 153

This pictogram indicates a hydraulic oil filter.




### MD 155

This icon designates the restraint points for tying the implement to a transport vehicle allowing the implement to be transported in a safe manner.



### MD 172

Swing the ladder to the operation platform upwards into transport position when driving!




### MD 173

**Danger from breathing in hazardous substances due to toxic vapours in the spray liquid tank!**

Causes serious, potentially fatal injuries anywhere on the body.

Never climb into the spray liquid tank.




### MD 174

Danger from unintended continued movement of the implement!

Will cause serious injuries anywhere on the body or death.

Secure the implement against moving away unintentionally before uncoupling the implement from the tractor. To do this, use the parking brake and/or the wheel chock(s).




### MD 175

The torque for the bolt connection is 510 Nm.



### MD 199

The maximum operating pressure of the hydraulic system is 210 bar.



## MD 224

**Risk of contact with hazardous materials due to improper use of clear fresh water from the hand wash tank.**

This danger can cause extremely serious and potentially fatal injuries.

Never use the clear water from the hand wash tank as drinking water.




## MD 225

**Risk of crushing of the entire body due to standing in the swivel range of the drawbar between the tractor and the attached implement!**

Causes serious, potentially fatal injuries anywhere on the body.

- Standing or walking in the danger area between the tractor and implement is prohibited whenever the tractor engine is running and the tractor is not secured against unintentional rolling.
- Instruct people to leave the danger area between the tractor and the implement whenever the engine of the tractor is running and the tractor is not secured against unintentional rolling.





## **2.14 Dangers in case of non-observance of the safety instructions**

---

Non-compliance with the safety information

- can pose both a danger to people and also to the environment and machine.
- can lead to the loss of all warranty claims.

In particular, non-compliance with the safety information could pose the following risks:

- Danger to people through non-secured working areas.
- Failure of important machine functions.
- Failure of prescribed methods of maintenance and repair.
- Danger to people through mechanical and chemical impacts.
- Risk to the environment through leakage of hydraulic fluid.

## **2.15 Safety-conscious working**

---

Besides the safety information in this operating manual, the generally applicable national workplace safety and accident prevention regulations are binding.

Comply with the accident prevention instructions on the warning symbols.

When driving on public roads and routes, comply with the appropriate statutory road traffic regulations.

## 2.16 Safety information for users



### WARNING

**Risk of crushing, cutting, being trapped or drawn in, or impact through inadequate roadworthiness and operational safety.**

Before starting up the implement and the tractor, always check their traffic and operational safety.

### 2.16.1 General safety instructions and accident prevention instructions

- In addition to these instructions, also comply with the generally valid national and safety and accident prevention regulations!
- The warning symbols attached on the implement provide important instructions for safe operation of the machine. Compliance with these instructions is essential for your safety!
- Before moving off and starting up the implement, check the immediate area of the implement (children). Ensure that you can see clearly.
- It is forbidden to ride on the implement or use it as a means of transport!
- Drive in such a way that you always have full control over the tractor with the attached implement.

In so doing, take your personal abilities into account, as well as the road, traffic, visibility and weather conditions, the driving characteristics of the tractor and the connected or coupled implement.

### Coupling and uncoupling the implement

- Only connect and transport the implement with tractors suitable for the task.
- When coupling implements to the tractor's three-point hydraulic system, the attachment categories of the tractor and the implement must always be the same!
- Connect the implement to the prescribed equipment in accordance with the specifications.
- When coupling implements to the front or the rear of the tractor, the following may not be exceeded:
  - The permissible total tractor weight
  - The permissible tractor axle loads
  - The permissible load capacities of the tractor tyres
- Secure the tractor and the implement against unintentional rolling before coupling or uncoupling the implement.
- It is forbidden for people to stand between the implement to be coupled and the tractor while the tractor is approaching the implement.
 

Any helpers may only act as guides standing next to the vehicles, and may only move between the vehicles when both are at a standstill.
- Before connecting the implement to or disconnecting the implement from the tractor's three-point hydraulic system, secure the operating lever of the tractor hydraulic system so that unintentional raising or lowering is prevented.

- When coupling and uncoupling implements, move the support equipment (if available) to the appropriate position (stability).
- When actuating the support equipment, there is a danger of injury from contusion and cutting points!
- Be particularly careful when coupling the implement to the tractor or uncoupling it from the tractor! There are nip and shear points in the area of the coupling point between the tractor and the implement.
- It is forbidden to stand between the tractor and the implement when actuating the three-point hydraulic system.
- Coupled supply lines:
  - must give without tension, bending or rubbing on all movements when travelling round corners.
  - must not chafe against other parts.
- The release ropes for quick action couplings must hang loosely and may not release themselves when lowered.
- Also ensure that uncoupled implements are stable!

---

### **Use of the implement**

---

- Before starting work, ensure that you understand all the equipment and actuation elements of the implement and their function. There is no time for this when the machine is already in operation!
- Wear tight-fitting clothing! There is an increased risk of loose clothing getting caught or entangled on drive shafts!
- Only place the implement in service after all protective devices have been attached and are in protective position!
- Comply with the maximum load of the connected implement and the permissible axle and drawbar loads of the tractor. If necessary, drive only with a partially filled tank.
- It is forbidden to stand in the working area of the implement.
- It is forbidden to stand in the turning and swivel range of the implement.
- There are crushing and shearing hazards on implement parts actuated by external force (e.g. hydraulically)!
- Only actuate implement parts actuated by external force if personal are maintaining an adequate safety distance to the implement!
- Secure the tractor against unintentional start-up and rolling, before you leave the tractor.  
For this:
  - Lower the implement onto the ground.
  - Apply the parking brake.
  - Switch off the tractor engine.
  - Remove the ignition key.

### Implement transportation

---

- When using public roads, national road traffic regulations must be observed.
- Before moving off, check:
  - the correct connection of the supply lines,
  - the lighting system for damage, function and cleanliness,
  - that the brake and hydraulic system shows no visible signs of defect,
  - that the parking brake is completely released,
  - the functioning of the brake system.
- Ensure that the tractor has sufficient steering and braking power. Any implements and front/rear weights connected to the tractor influence the driving behaviour and the steering and braking power of the tractor.
- If necessary, use front weights.

The tractor front axle must always be loaded with at least 20 % of the empty tractor weight, in order to ensure sufficient steering power.
- Always fix the front or rear weights to the intended fixing points according to regulations.
- Comply with the maximum payload of the connected implement and the permissible axle and drawbar loads of the tractor.
- The tractor must guarantee the prescribed brake delay for the loaded vehicle combination (tractor plus connected implement).
- Check the brake power before moving off.
- When turning corners with the implement coupled, take the wide sweep and centrifugal mass of the implement into account.
- Before moving off, ensure sufficient side locking of the tractor lower links, when the implement is fixed to the three-point hydraulic system or lower links of the tractor.
- Before road transport, move all the swivel implement parts to the transport position.
- Before road transport, secure all the swivel implement parts in the transport position against risky position changes. Use the transport locks intended for this.
- Before road transport, secure the operating lever of the three-point hydraulic system against unintentional raising or lowering of the coupled implement.
- Check that the transport equipment, e.g. lighting, warning equipment and protective equipment, is correctly installed on the implement.
- Before road transport, carry out a visual check that the top and lower link pins are firmly fixed with the linch pin against unintentional release.
- Adjust your forward speed to the prevailing conditions.
- Before driving downhill, switch to a low gear.
- Before road transport, always switch off the independent wheel braking (lock the pedals).

## 2.16.2 Hydraulic system

- The hydraulic system is under a high pressure.
- Ensure that the hydraulic hose lines are connected correctly.
- When connecting the hydraulic hose lines, ensure that the hydraulic system is depressurised on both the implement and tractor.
- It is forbidden to block the operator controls on the tractor which are used for hydraulic and electrical movements of components, e.g. folding, swivelling and pushing movements. The movement must stop automatically when you release the appropriate control. This does not apply to equipment movements that:
  - are continuous or
  - are automatically locked or
  - require a float position or pressure position due to their function.
- Before working on the hydraulic system,
  - Lower the implement.
  - Depressurise the hydraulic system.
  - Switch off the tractor engine.
  - Apply the parking brake.
  - Remove the ignition key.
- Have the hydraulic hose lines checked at least once a year by a specialist for proper functioning.
- Replace the hydraulic hose lines if they are damaged or worn. Only use genuine AMAZONE hydraulic hose lines!
- The hydraulic hose lines should not be used for longer than six years, including any storage time of maximum two years. Even with proper storage and approved use, hoses and hose connections are subject to natural aging, thus limiting the length of use. However, it may be possible to specify the length of use from experience values, in particular when taking the risk potential into account. In the case of hoses and hose lines made of thermoplastics, other guide values may be decisive.
- Never attempt to plug leaks in hydraulic hose lines using your hand or fingers.

Escaping high pressure fluid (hydraulic fluid) may pass through the skin and ingress into the body, causing serious injuries!

If you are injured by hydraulic fluid, contact a doctor immediately. Risk of infection.
- When searching for leakage points, use suitable aids, to avoid the serious risk of infection.

### **2.16.3 Electrical system**

---

- When working on the electrical system, always disconnect the battery (negative terminal).
- Only use the prescribed fuses. If fuses are used that are too highly rated, the electrical system will be destroyed – risk of fire.
- Ensure that the battery is connected correctly – firstly connect the positive terminal and then connect the negative terminal. When disconnecting the battery, disconnect the negative terminal first, followed by the positive terminal.
- Always place the appropriate cover over the positive battery terminal. If there is accidental earth contact, there is a danger of explosion!
- Risk of explosion. Avoid sparking and naked flames in the area of the battery.
- The implement may be equipped with electronic components whose function is influenced by electromagnetic interference from other units. Such interference can pose risks to people, if the following safety information is not observed.
  - In the case of retrofitting electrical units and/or components on the implement, with a connection to the on-board power supply, the operator is responsible for checking whether the installation might cause faults on the vehicle electronics or other components.
  - Ensure that the retrofitted electrical and electronic components comply with the EMC directive 2004/108/EEC in the appropriate version and carry the CE mark.

### **2.16.4 PTO shaft operation**

---

- Use only the universal joint shafts prescribed by the AMAZONEN-WERKE factories, equipped with the proper safety devices.
- Also read and follow the operating manual from the universal joint shaft manufacturer.
- The protective tube and universal joint shaft guard must be undamaged, and the shield of the tractor and implement PTO shaft must be attached and be in proper working condition.
- Work is prohibited while the safety devices are damaged.
- You can attach and detach the universal joint shaft only when
  - the PTO shaft is switched off.
  - the tractor engine is switched off.
  - the parking brake has been applied.
  - the ignition key has been removed.
- Always ensure that the universal joint shaft is installed and secured correctly.
- When using wide-angle universal joint shafts, always install the wide angle joint at the pivot point between the tractor and implement.

- Secure the universal joint shaft guard by attaching the chain(s) to prevent movement.
- Observe the prescribed pipe overlaps for universal joint shafts in transport and working positions. (Read and follow the operating manual from the universal joint shaft manufacturer.)
- When turning corners, observe the permitted bending and displacement of the universal joint shaft.
- Before switching on the PTO shaft, check that the selected PTO shaft speed of the tractor matches the permitted drive speed of the implement.
- Instruct everyone to leave the danger area of the implement before switching on the PTO shaft.
- While work is being carried out with the PTO shaft, there must be no one in the area of the PTO or universal joint shaft while it is turning.
- Never switch on the PTO shaft while the tractor engine is turned off.
- Always switch off the PTO shaft whenever excessive bending occurs or it is not needed.
- **WARNING!** After the PTO shaft is switched off, there is a danger of injury from the continued rotation of freewheeling implement parts.  
Do not approach the implement too closely during this time. You must only start work on the implement once all implement parts are at a complete standstill!
- Secure the tractor and implement against unintentional starting and unintentional rolling away before you perform any cleaning, servicing or maintenance work on PTO shaft-driven implements or universal joint shafts.
- After uncoupling the universal joint shaft, place it on the holder provided.
- After removing the universal joint shaft, attach the protective sleeve to the PTO shaft stub.
- When using the travel-dependent PTO shaft, note that the PTO shaft speed depends on the drive speed, and that the direction of rotation reverses when you drive in reverse.

### 2.16.5 Attached implements

---

- Comply with the approved combination options for the attachment equipment on the tractor and the implement drawbar.  
Only couple approved combinations of vehicles (tractor and attached implement).
- In the case of single axle implements, observe the maximum permitted drawbar load of the tractor on the attachment equipment.
- Always ensure that the tractor has sufficient steering and braking capacity!  
Implements connected to a tractor can influence your driving behaviour, as well as the steering and braking power of the tractor, in particular in the case of single axle implements with the drawbar load on the tractor.
- Only a specialist workshop may adjust the height of the drawbar on straight drawbars with a drawbar load.
- Implements without brake system:  
Observe the national regulations for implements without a brake system.

### 2.16.6 Brake system

---

- Only specialist workshops or recognised brake services can carry out adjustment and repair work on the brake system.
- Have the brake system thoroughly checked regularly.
- If there are any functional faults in the brake system, stop the tractor immediately. Have the malfunction rectified immediately.
- Before performing any work on the brake system, park the implement safely and secure the implement against unintentional lowering and rolling away (wheel chocks)!
- Be particularly careful when carrying out any welding, torch cutting or drilling work in the area of the brake lines.
- Always carry out a braking test after any adjusting or repair work on the braking system.



**Pneumatic braking system**

---

- Before coupling the implement, clean any dirt on the sealing rings on the coupling heads of the supply and brake lines.
- Only move off with the implement connected when the pressure gauge on the tractor shows 5.0 bar.
- Drain the air reservoir every day!
- Before driving without the implement, seal the coupling heads on the tractor.
- Hang the coupling heads of the implement supply and brake lines in the appropriate idle couplings.
- When filling up or replacing the brake fluid, use the prescribed fluid. When replacing the brake fluid, comply with the appropriate regulations.
- Do not make any changes to the specified settings on the brake valves!
- Replace the air reservoir if:
  - The air reservoir can be moved in the tensioning belts.
  - The air reservoir is damaged.
  - The rating plate on the air reservoir is rusty, loose or missing

**Hydraulic brake system for export implements**

---

- Hydraulic brake systems are not approved in Germany.
- When filling up or replacing the brake fluid, use the prescribed hydraulic fluids. When replacing the hydraulic fluids, comply with the appropriate regulations.

**2.16.7 Tyres**

---

- Repair work on tyres and wheels may only be carried out by specialists with suitable installation tools.
- Check the air pressure at regular intervals.
- Inflate tyres to the specified air pressure! If the air pressure in the tyres is too high, then there is a risk of explosions.
- Park the implement in a safe place and lock the implement against unintentional falling and rolling (parking brake, wheel chocks), before carrying out work on the tyres!
- Tighten or retighten all the fixing screws and nuts in accordance with the specifications of AMAZONEN-WERKE.



### 2.16.8 Field sprayer operation

---

- Comply with the recommendations provided by the manufacturer of the crop protection product with regard to
  - personal protective equipment
  - warnings concerning the handling of crop protection products
  - regulations on dosing, applications and cleaning
- Pay attention to crop protection legislation regulations!
- It is forbidden to store contaminated protective equipment, spray agent canisters and used filters in the tractor cab.
- Take off protective equipment before entering the tractor cab.
- Never open lines which are under pressure.
- The nominal volume of the spray liquid tank may never be exceeded when filling!



- When handling crop protection products, observe the requirements of the safety data sheet for the substances used as well as the guidelines for personal protective equipment. Depending on the requirement of the safety data sheet of the substances used, the following components belong to your personal protective equipment:
  - protective clothing according to DIN 32781
  - rubber apron according to EN 14605
  - eye protection according to EN 166
  - breathing mask according to DIN EN 143/149/405/14387, at least a half-mask with combined particle filter and gas filter A1-P2 (Colour code: brown-white)
  - protective gloves with cuffs according to DIN 347/388/420
  - foot protection
- Use personal protective equipment if you could come into contact with crop protection products or fertiliser during one of the following activities:
  - filling of the spray liquid tank and addition of chemicals
  - spraying
  - settings on the implement
  - emptying and cleaning the tank
  - using different chemicals
  - maintenance
- Depending on the requirements of the safety data sheet of the active substances used, wear personal protective equipment in the tractor cab.
- Tractors with Category 4 cabs are prescribed when applying certain spray agents.
- Observe the information on the compatibility of crop protection agents and substances for the field sprayer.
- Do not spray any crop protection agents which have a tendency to stick together or set.
- Do not fill field sprayers with water from bodies of water which are open to the public, for the protection of people, animals and the environment.
- Fill the field sprayer only using original AMAZONE filling devices!

## 2.16.9 Cleaning, maintenance and repair

---

- Due to toxic vapours in the spray liquid tank, it is generally forbidden to climb into the spray liquid tank.

Repair work in the spray liquid tank may only be performed by a specialist workshop!

- Repair-, maintenance- and cleaning operations as well as the remedy of function faults should principally be conducted under the following circumstances:
  - the drive is switched off.
  - the tractor engine is at a standstill.
  - the ignition key has been removed.
  - The implement plug has been disconnected from the on-board computer
- Regularly check the nuts and bolts for a firm seat and retighten them as necessary.
- Secure the raised implement and/or raised implement parts against unintentional lowering before performing any cleaning, maintenance or repair work on the implement!
- When replacing work tools with blades, use suitable tools and gloves.
- Dispose of oils, greases and filters in the appropriate way.
- Disconnect the cable to the tractor generator and battery, before carrying out electrical welding work on the tractor and on attached implements.
- Spare parts must meet at least the specified technical requirements of AMAZONEN-WERKE!  
This is ensured through the use of genuine AMAZONE spare parts!
- When repairing field sprayers which have been used for liquid fertiliser application with ammonium nitrate / urea solution, observe the following points:

Residues of ammonium nitrate / urea solutions may form salts on or in the spray liquid tank by the evaporation of water. This produces pure ammonium nitrate and urea. In its undiluted form, ammonium nitrate is explosive when combined with organic substances, e.g. urea, and subjected to critical temperatures during repair work (e.g. welding, grinding, filing).

This danger can be eliminated by thoroughly washing out the spray liquid tank or the parts intended for repair with water, as the salt of the ammonium nitrate / urea solution is water-soluble. For this reason, clean the field sprayer thoroughly with water before carrying out repair work.

### 3 Loading and unloading

#### Loading and unloading with a tractor



#### WARNING

There is a risk of an accident when the tractor is unsuitable and the implement brake system is not connected to the tractor or is filled.



- Correctly couple the implement to the tractor, before loading the implement onto a transport vehicle or unloading it from a transport vehicle.
- You may only couple and transport the implement with a tractor for loading and unloading, as long as the tractor fulfils the power requirements.

#### Pneumatic brake system:

- Only move off with the implement connected when the pressure gauge on the tractor shows 5.0 bar.

#### Loading using a lifting crane

There are 4 attachment points (1) on the right and on the left of the implement respectively.



#### DANGER

**Danger to life! Machine can drop down!**

**Empty the tank before lifting the machine.**

**Lift the machine only at the points indicated.**



#### DANGER


**The minimum tensile strength per sling must be 2000 kg!**

#### Transport lock for the hydraulic jack



Remove the transport lock for the jack after unloading the implement.

- (1) Lift the implement hydraulically using the jack.
- (2) Remove the transport lock.




## 4 Product description

This section:


- provides a comprehensive overview of the implement layout.
- provides the names of the individual assembly groups and operator controls.

If possible, read this section when actually at the implement. This helps you to understand the implement better.

### 4.1 Overview of assembly groups




- |   |   |
|---|---|
| (1) Spray liquid tank   | (6) Control panel cover and transport box |
| (2) Inspection hatch of the spray liquid tank for visual inspection | (7) Maintenance platform with ladder      |
| (3) Washing water tank  | (8) Drawbar with coupling device          |
| (4) Spraying pump   | (9) Flushing water tank, left             |
| (5) Agitator pump   | (10) Hose cabinet                         |



- (1) Folding sprayer boom with transport locking mechanism
- (2) Boom part width section valves
- (3) Flushing water tank, right
- (4) Storage for extraction hose, spraying agent canisters and used filters
- (5) Wheel chocks
- (6) Hydraulic system / electronics cover hood
- (7) Hydraulic jack

## 4.2 Safety and protection equipment


- Transport locking mechanism to prevent the Super-L boom from folding out unintentionally



- Railing on the maintenance platform



- (1) Universal joint shaft guard with supporting chains
- (2) Implement-side PTO shaft guard






### 4.3 Supply lines between the tractor and the implement

- Hydraulic hose lines (depending on the equipment)
- Electric cable for lighting
- ISOBUS implement cable
- Brake line with coupling head for pneumatic brake / brake line with connection to the hydraulic brake

### 4.4 Transportation equipment


- (1) Rear lights, brake lights, turn indicators
- (2) 2 warning signs (square)
- (3) 2 red reflectors (triangular)
- (4) 1 number plate holder with lighting



Reflector, yellow, on the sides at a distance of max. 3 m



- (1) Super-L boom:  
Additional brake light and position light (not for France)



Connect the lighting system to the 7-pin tractor socket via the pin.

## 4.5 Intended use

The field sprayer

- is intended for the transportation and application of crop protection agents (insecticides, fungicides, herbicides, etc.) in the form of suspensions, emulsions and mixtures, as well as of liquid fertilisers.
- uses state-of-the-art technology to ensure biological success, provided that all the correct adjustments are made and correct doses are applied. Economical use of spraying agents and low rates of pollution are achieved.
- is intended exclusively for agricultural use, for treating field crops.

The pH value of the spray liquid to be applied (particularly liquid fertiliser) must be greater than 1.5.

Restrictions for use on slopes

- (1) Driving on slopes with a full spray liquid tank
- (2) Driving on slopes with a partially filled spray liquid tank
- (3) Application of residual quantities
- (4) Turning
- (5) Folding the sprayer boom

	(1)	(2)	(3)	(4)	(5)
Across a slope	15%	15%	15%	15%	20%
Up/down the slope	15%	30%	15%	15%	20%

**"Intended use" also includes:**

- Compliance with all the instructions in this operating manual.
- Execution of inspection and maintenance work.
- Exclusive use of genuine AMAZONE spare parts.

Other uses to those specified above are forbidden and shall be considered as improper.

For any damage resulting from improper use

- the operator bears the sole responsibility,
- AMAZONEN-WERKE accepts no liability.

## 4.6 Implement inspection

### German inspection plate

The implement is subject to the European Union universally applicable regular implement inspections (Crop Protection Directive 2009/128/EC and EN ISO 16122).

Have the device inspected at regular intervals by a recognised and certified inspection workshop.

The date for performing the next device inspection is written on the inspection plate on the implement.



## 4.7 Consequences of using certain crop protection agents

We would like to draw attention to the fact that extended exposure (20 hours) to crop protection agents with which we are familiar, e.g. Lasso, Betanal and Trammat, Stomp, Iloxan, Mudecan, Elancolan and Teridox, can cause damage to the pump diaphragms, hoses, spray lines and tanks. The examples given are in no way intended to represent a comprehensive list.

In particular, we warn against unauthorised mixtures of two or more different crop protection agents.

Substances which have a tendency to stick together or set must not be applied.

When using such aggressive crop protection agents, it is recommended that the spray liquid be applied immediately after preparation and that the sprayer then be thoroughly cleaned afterwards with water.

Viton membranes are available as replacements for pumps. These are resistant to solvent-containing crop protection agents. However their service life is reduced by use at low temperatures (e.g. AUS in frosty conditions).

The materials and components used for AMAZONE field sprayers are safe for liquid fertiliser.

## 4.8 Danger areas and danger points

---

The danger area is the area around the machine in which people can be caught:

- by work movements made by the implement and its tools.
- by materials or foreign bodies thrown out of the implement.
- by tools rising or falling unintentionally.
- by unintentional rolling of the tractor and the implement.

Within the implement danger area, there are danger points with permanent or unexpected risks. Warning pictograms indicate these danger points and warn against residual dangers, which cannot be eliminated for construction reasons. Here, the special safety regulations of the appropriate section shall be valid.

No-one may stand in the implement danger area:

- as long as the tractor engine is running with a connected universal joint shaft/hydraulic system.
- as long as the tractor and implement are not protected against unintentional start-up and running.

The operating person may only move the implement or switch or drive the tools from the transport position to the working position or vice-versa when there is no-one in the implement danger area.


Danger points exist:

- Between the tractor and field sprayer, particularly when coupling and uncoupling.
- Where there are moving components.
- When the implement is in motion.
- In the swivelling range of the sprayer boom.
- In the spray liquid tank due to toxic vapours.
- Underneath raised, unsecured implements or parts of implements.
- When unfolding/folding the sprayer boom in the area of overhead cables due to contact with overhead cables

## 4.9 Rating plate

### Machine rating plate

- (1) Implement number
- (2) Vehicle identification number
- (3) Product
- (4) Permissible technical implement weight
- (5) Tare weight kg
- (6) Model year
- (7) Year of manufacture



AMAZONE  
AMAZONEN-WERKE H. DREYER SE & Co. KG  
Am Amazonenwerk 9-13 D-49205 Hasbergen

Machine no. **1**

Vehicle ID no. **2**


Product **3**

Permissible techn. implement weight kg **4** Tare weight kg **5** Model Year **6**

CE UK CA Year of construction **7**

### Additional rating plate

- (1) Note for type approval
- (2) Note for type approval
- (3) Vehicle identification number
- (4) Permissible technical total weight
- (5) Permissible technical trailer load for a drawbar trailer vehicle with pneumatic brake
- (A0) Permissible technical drawbar load A-0
- (A1) Permissible technical axle load for axle 1
- (A2) Permissible technical axle load for axle 2



AMAZONEN-WERKE H. DREYER SE & Co. KG

**1** **2**

**3** **4** kg

T-1 T-2 T-3 A-0: kg

B-2 - - - A-1: kg

B-4 **5** - - - A-2: kg

## 4.10 Conformity

	Directives/Standards designation
The implement complies with the	<ul style="list-style-type: none"> <li>Implement directive 2006/42/EC</li> <li>EMC directive 2014/30/EU</li> </ul>

## 4.11 Technically possible maximum application rate



The application rate of the implement is limited by the following factors:

- Maximum flow to the sprayer boom of 200 l/min (HighFlow 400 l/min).
- Maximum flow per part-width section of 25 l/min (with 2 spray lines: 40 l/min per part-width section).
- Maximum flow per nozzle body of 4 l/min.

## 4.12 Maximum permissible application rate



The permissible application rate of the implement is limited by the minimum required agitator capacity.

The agitator capacity per minute should be 5% of the hopper volume.

This is particularly applicable for active substances that are hard to keep in suspension.

With active substances that are dissolved, the agitator capacity can be reduced.

### Determining the permissible application rate depending on the agitator capacity

#### Calculation formula for the application rate in l/min:

(Agitator capacity per minute = 5% of the tank volume)

$$\text{Permissible application rate [l/min]} = \text{Pump capacity [l/min]} - 0.05 \times \text{nominal tank volume [l]}$$

(see technical data)

#### Conversion of the application rate in l/ha:


1. Determine the application rate per nozzle (divide the permissible application rate by the number of nozzles).
2. Read the application rate per hectare depending on the speed from the spray table (See page 249).

#### Example:

UX 8601, Pump BPS 260 / BPS 365, Super L 36 m, 72 nozzles, 10 km/h

$$\text{Permissible application rate} = 245 + 350 \text{ l/min} - 0,05 \times 8600 \text{ l} = 165 \text{ l/min}$$

$$\rightarrow \text{Application rate per nozzle} = 2.3 \text{ l/min}$$




→ Permissible application rate per hectare = 276 l/ha

## 4.13 Technical data

### 4.13.1 Total dimensions

The total heights depend on the implement type, axle, and tyres.



### 4.13.2 Basic implement

Type <b>UX Super</b>	<b>7601</b>	<b>8601</b>
Spray liquid tank		
Actual volume	8000 l	9030 l
Nominal volume	7600 l	8600 l
Flushing water tank	580 l	580 l
Filling height from the maintenance platform	1380 mm	1380 mm
Permissible system pressure	<10 bar	
Working speed	4 – 18 km/h	
Working width	27 - 42 m	
Central switching mechanism	Electric, part width section valve coupling	
Spray pressure adjustment	Electric	
Spray pressure setting range	0.8-10 bar	
Pressure filter	50 (80.100) mesh	
Agitator	Infinitely adjustable	
Spray rate control	Ground speed-related via job computer	
Nozzle height	500 – 2500 mm	

### 4.13.3 Spraying technology

#### Part-width sections depending on the working width

Working width	Number	Number of nozzles per part width sections
21 m	5	8-9-8-9-8
	7	6-6-7-4-7-6-6
	9	6-4-5-4-4-4-5-4-6
24 m	5	9-10-10-10-9
	7	6-6-8-8-8-6-6
	9	6-5-5-5-6-5-5-5-6
27 m	7	8-7-8-8-8-7-8
	9	6-6-6-6-6-6-6-6-6
28 m	7	9-7-8-8-8-7-9
	9	7-6-6-6-6-6-6-6-7
30 m	9	8-7-6-6-6-6-6-7-8
32 m	9	8-6-7-7-8-7-7-6-8
33 m	9	7-8-7-7-8-7-7-8-7
	11	6-6-6-6-6-6-6-6-6-6-6
36 m	7	10-10-10-12-10-10-10
	9	9-9-7-7-8-7-7-9-9
36 m / 24 m	9	6-7-(9+1)-9-10-9-(9+1)-7-6
39 m	9	7-9-9-9-10-9-9-9-7
	13	6-6-6-6-6-6-6-6-6-6-6-6-6
40 m	9	8-9-9-9-10-9-9-9-8

#### Technical data: pump equipment

Pump equipment		Spraying pump /	agitator pump
		Comet BPS 260	Comet BPS 365
Delivery capacity at nominal speed	at 0 bar	245 l/min	350 l/min
	at 10 bar	240 l/min	345 l/min
Power requirement		9,5 [kW]	20,5 [kW]
Design		5-cylinder piston diaphragm pump	6- cylinder piston diaphragm pump

The pumps are driven

- directly by the universal joint shaft.
- Drive speed 540 rpm
- directly by a hydraulic motor.
- Drive speed 540 rpm



#### 4.13.4 residual amounts

##### Technical residue incl. pump

On the level	23 l
Along the contours	
15% direction of travel to the left	23 l
15% direction of travel to the right	23 l
Along the gradient	
15% up the slope	37 l
15% down the slope	30 l

##### Technical boom residues

Work- ing width	No. of part width sec- tions	Part-width section control						Single nozzle control		
		Without DUS			With DUS			With DUS pro		
		A	B	C	A	B	C	A	B	C
21 m	5	4,5 l	9,0 l	13,5 l	14,5 l	1,0 l	15,5 l	18,1 l	1,5 l	19,6 l
	7	5,0 l	10,5 l	15,5 l	17,0 l	1,0 l	18,0 l			
	9	5,5 l	16,0 l	21,5 l	23,0 l	1,5 l	24,5 l			
24 m	5	5,0 l	10,0 l	15,0 l	16,0 l	1,5 l	17,5 l	19,0 l	2,0 l	21,0 l
	7	5,0 l	11,5 l	16,5 l	17,5 l	1,5 l	19,0 l			
	9	5,5 l	17,0 l	22,5 l	23,5 l	2,0 l	25,5 l			
27 m	7	5,0 l	12,5 l	17,5 l	18,5 l	2,0 l	20,5 l	22,4 l	2,0 l	24,4 l
	9	5,5 l	17,5 l	23,0 l	24,0 l	2,0 l	26,0 l			
28 m	7	5,0 l	13,0 l	18,0 l	19,0 l	2,0 l	21,0 l	22,8 l	2,0 l	24,8 l
	9	5,5 l	17,5 l	23,0 l	24,0 l	2,0 l	26,0 l			
30 m	9	5,5 l	18,0 l	23,5 l	24,0 l	2,5 l	26,5 l	24,6 l	2,5 l	27,1 l
32 m	9	5,5 l	18,5 l	24,0 l	24,0 l	2,5 l	27,0 l	27,9 l	2,5 l	30,4 l
33 m	9	5,5 l	19,0 l	24,5 l	25,0 l	2,5 l	27,5 l	27,6 l	2,5 l	30,1 l
	11	6,0 l	23,0 l	29,0 l	29,5 l	2,5 l	32,0 l			
36 m	7	5,0 l	16,0 l	21,0 l	21,5 l	3,0 l	24,5 l	29,3 l	3,0 l	32,3 l
	9	5,5 l	19,5 l	25,0 l	25,5 l	3,0 l	28,5 l			
39 m	9	5,5 l	20,5 l	26,0 l	26,5 l	3,0 l	29,5 l	33,7 l	3,0 l	36,7 l
	13	6,5 l	28,0 l	34,5 l	35,0 l	3,0 l	38,0 l			
40 m	9	5,5 l	21,0 l	26,5 l	27,0 l	3,0 l	30,0 l	34,0 l	3,0 l	37,0 l
42 m	-	-	-	-	-	-	-	35,2 l	3,0 l	38,2 l
45 m	-	-	-	-	-	-	-	39,6 l	3,0 l	42,6 l

**DUS:** Pressure circulating system

**A:** Dilutable

**B:** Not dilutable

**C:** Total

### 4.13.1 Payload

Maximum payload	=	Permissible technical implement weight	-	Tare weight
-----------------	---	--	---	-------------



#### DANGER

**Exceeding the maximum permissible payload is prohibited.**

**Risk of accident due to unstable driving conditions!**

Carefully determine the payload, and therefore the permitted filling amount for your machine. Not all filling media can be used to fill the tank completely.



The permissible technical implement weight and the tare weight are specified on the implement rating plate.



Depending on the tyres, the tyre load capacity of both tyres can be lower than the permissible axle load.

In this case, the tyre load capacity limits the permissible axle load.

#### Tyre load capacity per wheel

- The load index on the tyre indicates the load capacity of the tyre.
- The speed index on the tyre indicates the maximum speed at which the tyre has the tyre load capacity according to the load index.
- The tyre load capacity is only achieved when the tyre inflation pressure matches the nominal pressure.

<b>Load index</b>	<b>140</b>	<b>141</b>	<b>142</b>	<b>143</b>	<b>144</b>	<b>145</b>	<b>146</b>	<b>147</b>
Tyre load capacity (kg)	2500	2575	2650	2725	2800	2900	3000	3075
<b>Load index</b>	<b>148</b>	<b>149</b>	<b>150</b>	<b>151</b>	<b>152</b>	<b>153</b>	<b>154</b>	<b>155</b>
Tyre load capacity (kg)	3150	3250	3350	3450	3550	3650	3750	3850
<b>Load index</b>	<b>156</b>	<b>157</b>	<b>158</b>	<b>159</b>	<b>160</b>	<b>161</b>	<b>162</b>	<b>163</b>
Tyre load capacity (kg)	4000	4125	4250	4375	4500	4625	4750	5000
<b>Load index</b>	<b>164</b>	<b>165</b>	<b>166</b>	<b>167</b>	<b>168</b>	<b>169</b>	<b>170</b>	<b>171</b>
Tyre load capacity (kg)	5000	5150	5300	5450	5600	5800	6000	6150
<b>Load index</b>	<b>172</b>	<b>173</b>	<b>174</b>	<b>175</b>	<b>176</b>	<b>177</b>	<b>178</b>	<b>179</b>
Tyre load capacity (kg)	6300	6500	6700	6900	7100	7300	7500	7750

<b>Speed index</b>	<b>A5</b>	<b>A6</b>	<b>A7</b>	<b>A8</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>
Permissible maximum speed (km/h)	25	30	35	40	50	60	65	70

### Driving with reduced inflation pressure



- When the inflation pressure is lower than the nominal pressure, the tyre load capacity is reduced!  
In that case, observe the reduced payload of the implement.
- Please also follow the specifications of the tyre manufacturer!



#### **WARNING**

##### **Danger of accident!**

**In event of too low inflation pressure, the stability of the vehicle is no longer guaranteed.**

## 4.14 Noise production data

The workplace-related emission value (acoustic pressure level) is 74 dB(A), measured in operating condition at the ear of the tractor driver with the cab closed.

Measuring unit: OPTAC SLM 5.

The noise level is primarily dependent on the vehicle used.

## 4.15 Necessary tractor equipment

To be able to operate the implement, the tractor must fulfil the power requirements and must be equipped with the necessary hydraulic, electric, and brake connections for the brake system.

### Tractor engine power

<b>UX 7601</b>	starting at 118 kW (160 HP)
<b>UX 8601</b>	starting at 132 kW (180 HP)

### Electrical equipment

Battery voltage:	• 12 V (volts)
Lighting socket:	• 7-pin

### Hydraulic system

Maximum operating pressure:	• 210 bar										
Tractor pump capacity:	<table> <tr> <td>Profi boom folding</td><td>25 l/min</td></tr> <tr> <td>Drawbar or stub axle steering</td><td>+ 10 l/min</td></tr> <tr> <td>ContourControl</td><td>+ 10 l/min</td></tr> <tr> <td>Flushing water pump</td><td>+ 35 l/min</td></tr> <tr> <td>Hydraulic spray pump drive</td><td>+ 50 l/min</td></tr> </table>	Profi boom folding	25 l/min	Drawbar or stub axle steering	+ 10 l/min	ContourControl	+ 10 l/min	Flushing water pump	+ 35 l/min	Hydraulic spray pump drive	+ 50 l/min
Profi boom folding	25 l/min										
Drawbar or stub axle steering	+ 10 l/min										
ContourControl	+ 10 l/min										
Flushing water pump	+ 35 l/min										
Hydraulic spray pump drive	+ 50 l/min										
Implement hydraulic fluid:	<ul style="list-style-type: none"> <li>• HLP68 DIN 51524</li> </ul> <p>The implement hydraulic fluid is suitable for the combined hydraulic fluid circuits of all standard tractor brands.</p>										
Tractor control units	• Depending on the equipment, see Seite 69.										

### Brake system (depending on the equipment)

Dual line service brake system:	• 1 coupling head (red) for the supply line
or	• 1 coupling head (yellow) for the brake line
Single line service brake system:	• 1 coupling head for the brake line
or	
Hydraulic brake system:	• 1 hydraulic coupling in accordance with ISO 5676



The hydraulic braking system is not allowed in Germany and several other EU countries!

### PTO shaft (depending on the equipment)

Required speed:	• 540 rpm
Direction of rotation:	• Clockwise, viewed from rear toward the tractor.

## 5 Layout and function of the basic implement

### 5.1 Method of operation

Through the suction valve chest and the suction filter (2), the spraying pump (1) draws

- spray liquid from the spray liquid tank.
- fresh water via the external suction port (3).
- flushing water from the flushing water tank.

Thus, the drawn liquid is conveyed to

- the part-width section valves (5) via the pressure filter (4). The part-width section valves take over the distribution to the spray lines.


Alternatively:

through the pressure filter (4) to the single nozzle control (12).


- to the injector (6) and the induction bowl (7). To prepare the spray liquid, pour the required quantity of agent into the induction bowl and draw into the spray liquid tank.
- directly in the spray liquid tank.
- to the internal (8) or external cleaning switch tap (9).

The agitator pump (10) supplies the main agitator (11) in the spray liquid tank. When switched on, the main agitator ensures that the spray liquid is homogeneous.


#### single nozzle control



#### Part-width section control




## 5.2 Control panel



- |  |  |
|--|--|
| (1) Pressure valve chest switch tap  | (10) Filling connection (suction) for spray liquid tank, flushing water tank                                 |
| (2) Switch tap source for induction bowl (QU)  | (11) Filling connection (pressure) for spray liquid tank / flushing water tank                               |
| (3) Suction valve chest display  | (12) Parking brake   |
| (4) TwinTerminal   | (13) Quick emptying / draining of the suction filter, draining the final residual quantities (with stop tap) |
| (5) Maintenance flap with shelf  | (14) Drip-free plug coupling (closed transfer system) with switch tap  |
| (6) Transport box for separate storage of contaminated and non-contaminated protective equipment | (15) Flushing connection for tank cleaning of the closed transfer system                                     |
| (7) Swivelling cover hood with lighting for the control panel                                    |  |
| (8) Swivelling induction bowl in transport position  |  |
| (9) Washing facility with soap dispenser   |  |








### Under the maintenance flap


- (1) Suction filter
- (2) Pressure filter
- (3) Switch tap for draining the pressure filter






### Switch taps on the control panel

#### SPressure valve chest switch tap (DA)

-  Fill spray liquid tank via suction connection / suction from the induction bowl
-  Supply induction bowl
-  + (  +  ) Switch the functions simultaneously.
-  Sprayers
-  Internal cleaning



Pay particular attention to the corresponding sections of the operating manual when using the functions marked in red!

-  Quick emptying
-  External cleaning
-  Filling the flushing water tank



## WARNING

**Contamination of the soil due to operating errors with the pressure valve chest switch tap.**



Never swivel the pressure valve chest switch tap accidentally to the quick emptying function.

The spray liquid tank is quick-emptied via the pump.

**Contamination of the flushing water tank due to operating errors with the pressure valve chest switch tap.**



Never swivel the pressure valve chest switch tap accidentally to the flushing water tank filling function when the pump is conveying spray liquid.

The spray liquid is pumped into the flushing water tank.

## Operation of the pressure valve chest:


- Liquid circulation switched on the pressure side.



- Switch tap is locked.




- Liquid circulation blocked on the pressure side.

- Switch tap unlocked, selection of the function is possible.






### Suction valve chest display (SA)



-  Suction via suction hose
-  Suction from spray liquid tank
-  Suction from flushing water tank


### TwinTerminal

The suction valve chest is electrically switched via the TwinTerminal






### Switch tap source for induction bowl (QU)

-  Use liquid from the suction valve chest for the induction bowl
-  Use filling water from the pressure connection for the induction bowl




### Switch tap injector (IJ)

-  Suction from induction bowl
-  Increase filling capacity using injector



### Pressure filter switch tap (DE)


-  Drain pressure filter



## Layout and function of the basic implement


### Suction from container switch tap (GA)

- 100% maximum suction capacity




### 5.3 Induction bowl

- (1) Swivelling induction bowl for pouring, dissolving and drawing in crop protection agents and urea.  
Holding capacity of approx. 60 l
- (2) Locking mechanism for folding cover
- (3) Canister flushing push button
- (4) The open folding cover can be used as a shelf
- (5) Switch tap EA
- (6) Handle to swivel the induction bowl into working or transport position
- (7) Switch tap EB
- (8) Spray pistol for cleaning the control panel
- (9) Scale to show the contents
- (10) Cleaning nozzle for canisters with pressure plate
- (11) Induction bowl cleaning nozzle





Water escapes from the canister flushing nozzle if


- the pressure plate is pressed downwards.
- the button presses the canister flushing nozzle downwards when the folding cover is closed.





### 5.3.1 Switch taps on the induction bowl


- **Switch tap (EA)**

- o  External cleaning of induction bowl
- o  Dissolve agent with mixing nozzle




- **Switch tap (EB)**

- o  Clean canister / clean induction bowl
- o  Flushing via ring line



## 5.4 Universal joint shaft

The wide-angle universal joint shaft is responsible for transmitting the force between the tractor and the implement.



### WARNING

#### **Danger of crushing from tractor and implement unintentionally starting up or rolling away!**

Couple or uncouple the wide-angle universal joint shaft to / from the tractor only when tractor and implement have been secured against unintentional starting and unintentional rolling away.



### WARNING

#### **Danger of being entangled and drawn in by a universal joint shaft without guard or damaged protective equipment!**

- Never use the PTO shaft if the safety device is missing or damaged, or without correctly using the supporting chain.
- Before each use, check that
  - all protective devices for the universal joint shaft are installed and fully functional.
  - the clearance around the universal joint shaft is sufficient in all operating positions. Lacking clearance causes damage to the universal joint shaft.
- Attach the supporting chains in such a way as to ensure sufficient swivelling range in all operating positions of the universal joint shaft. Supporting chains must not become caught on machine or tractor parts.
- Have any damaged or missing parts of the universal joint shaft replaced immediately with OEM parts from the universal joint shaft manufacturer.  
Please note that the universal joint shaft can only be repaired by a specialist workshop.
- With the implement uncoupled, place the universal joint shaft in the intended holder. This protects the universal joint shaft from damage and soiling.
  - Never use the supporting chain of the universal joint shaft to suspend the uncoupled universal joint shaft.

**WARNING**

**Danger of being entangled and drawn in by unprotected parts of the universal joint shaft in the force transmission area between the tractor and the driven implement!**

Work only when the drive between the tractor and driven implement is fully guarded.

- The unprotected parts of the universal joint shaft must always be guarded by a shield on the tractor and a universal joint shaft guard on the implement.
- Check that the shield on the tractor or the universal joint shaft guard on the implement and the safety devices and guards of the extended universal joint shaft overlap by at least 50 mm. If not, the implement may not be driven by the universal joint shaft.



- Use only the provided universal joint shaft or the provided universal joint shaft type.
- Read and follow the operating manual provided for the universal joint shaft. Correct use and maintenance of the universal joint shaft prevents serious accidents.
- When coupling the universal joint shaft, observe
  - the operating manual provided for the universal joint shaft.
  - the permitted drive speed of the implement.
  - the correct installation length of the universal joint shaft. Refer to the section "Adjusting the length of the universal joint shaft to the tractor", page 128.
  - the correct installation position of the universal joint shaft. The tractor symbol on the protective tube of the universal joint shaft identifies the tractor-side connection of the universal joint shaft.
- Always mount the overload or freewheel clutch on the implement side if the universal joint shaft has an overload or freewheel clutch.
- Before switching on the PTO shaft, observe the safety instructions for PTO shaft operation in the section "Safety information for the operator", page 34.

### 5.4.1 Coupling the universal joint shaft



#### WARNING

##### **Danger due to crushing and impact due to lacking clearance when coupling the universal joint shaft!**

Couple the universal joint shaft to the tractor before you couple the implement to the tractor. In this way, you have enough clearance to safely couple the universal joint shaft.

1. Drive the tractor up to the implement in such a way that a gap (approx. 25 cm) remains between tractor and implement.
2. Secure the tractor against unintentional starting and unintentional rolling away, refer to the section "Securing the tractor against unintentional starting and rolling away" starting at page 130.
3. Check whether the PTO shaft of the tractor is switched off.
4. Clean and grease the PTO shaft on the tractor.
5. Push the latch of the universal joint shaft onto the tractor PTO shaft until the latch noticeably engages. When coupling the universal joint shaft, observe the supplied operating manual for the universal joint shaft and the permitted PTO shaft speed for the implement.

The tractor symbol on the protective tube of the universal joint shaft identifies the tractor-side connection of the universal joint shaft.

6. Secure the universal joint shaft guard using the supporting chain(s) to prevent movement.
  - 6.1 Fasten the supporting chain(s) as perpendicular to the universal joint shaft as possible.
  - 6.2 Attach the supporting chain(s) in a way that ensures sufficient swivelling range of the universal joint shaft in all operating positions.



#### CAUTION

Supporting chains must not become caught on machine or tractor parts.

7. Check whether the clearance around the universal joint shaft is sufficient in all operating positions. Lacking clearance causes damage to the universal joint shaft.
8. Eliminate lacking clearance (if necessary).

## 5.4.2 Uncoupling the universal joint shaft



### WARNING

**Danger due to crushing and impact due to lacking clearance when uncoupling the universal joint shaft!**

First uncouple the implement from the tractor, before you uncouple the universal joint shaft from the tractor. In this way, you have enough clearance to safely uncouple the universal joint shaft.



### CAUTION

**Danger due to burns on hot components of the universal joint shaft!**


This danger causes light to serious injuries to the hands.

Do not touch any strongly heated components of the universal joint shaft (especially the couplings).



- After uncoupling the universal joint shaft, place it in the holder provided. This protects the universal joint shaft from damage and soiling.  
Never use the supporting chain of the universal joint shaft to suspend the uncoupled universal joint shaft.
- Clean and lubricate the universal joint shaft if it is going to be out of use for a long time.

1. Uncouple the implement from the tractor. For this purpose, see the section "Uncoupling the implement", page 138.
2. Drive the tractor up to the implement in such a way that a gap (approx. 25 cm) remains between tractor and implement.
3. Secure the tractor against unintentional starting and unintentional rolling away, refer to the section "Securing the tractor against unintentional starting and rolling away" starting at page 130.
4. Pull the latch of the universal joint shaft off of the tractor PTO shaft until the latch noticeably engages. When uncoupling the universal joint shaft, observe the operating manual supplied by the universal joint shaft manufacturer.
5. Place the universal joint shaft in the intended holder.
6. Clean and lubricate the universal joint shaft when it is not going to be used for a longer period of time.






## 5.5 Hydraulic connections




- All hydraulic hose lines are equipped with grips.









Coloured markings with a code number or code letter have been applied to the gripping sections in order to assign the respective hydraulic function to the pressure line of a tractor control unit!



Films are stuck on the implement for the markings that illustrate the respective hydraulic function.

- The tractor control unit must be used in different types of activation, depending on the hydraulic function.

Latched, for a permanent oil circulation	
Tentative, activate until the action is executed	
Float position, free oil flow in the control unit	

Labelling		Function			Tractor-control-unit	
blue			Double acting	Lifting	doppelt-wirkend	
				Lowering		
red		Permanent oil circulation			Single-acting	
red		Pressure-free return flow				
red		Load-Sensing-Steuerleitung (Option)				



### WARNING

#### Danger of infection from escaping hydraulic fluid at high pressure!

When coupling and uncoupling the hydraulic hose lines, ensure that the hydraulic system is depressurised on both the implement and tractor sides.

If you are injured by hydraulic fluid, contact a doctor immediately.

### Ölrücklauf

**Maximum permissible pressure in the oil return: 5 bar**

Therefore, do not connect the oil return to the tractor control unit, but rather to a pressure-free oil return with a large plug coupling.



#### **WARNING**

**Only use DN16 lines for the oil return and select short return paths.**

**Only apply pressure to the hydraulic system when the free return line is coupled correctly.**

Install the supplied coupling sleeve to the pressure-free oil return.


### Oil volume flow

Depending on the implement equipment (equipment a, b, c), the implement requires a specific oil volume flow that must be provided by the tractor.

Select the tractor such that it provides the required oil volume flow at operating point X on the field and also on the headlands with a moderate engine speed. You must also consider the tractor's own requirements.



An oil shortage impairs the functioning of the implement and can cause damage to the implement.



### Load sensing operation

For load sensing operation, move the switch tap on the hydraulic block to the corresponding position

### 5.5.1 Coupling the hydraulic hose lines



#### WARNING

**Risk of being crushed, cut, caught, drawn in or struck due to faulty hydraulic functions when the hydraulic hose lines are connected incorrectly!**

When coupling the hydraulic hose lines, observe the coloured markings on the hydraulic connectors.



- Check the compatibility of the hydraulic fluids before connecting the implement to the hydraulic system of the tractor.  
Do not mix any mineral oils with biological oils.
- Observe the maximum approved hydraulic fluid pressure of 210 bar.
- Only couple clean hydraulic connectors.
- Push the hydraulic connector(s) into the hydraulic sleeves until you feel them lock.
- Check the coupling points of the hydraulic hose lines for a correct, tight seat.

1. Swivel the actuation lever on the control valve on the tractor to float position (neutral position).
2. Clean the hydraulic connectors of the hydraulic hose lines before you couple the hydraulic hose lines to the tractor.
3. Connect the hydraulic hose line(s) to the tractor control unit(s).

### 5.5.2 Uncoupling the hydraulic hose lines



Implements with LS or accumulator charging circuit:

- Only uncouple the hydraulic hoses when the tractor is switched off.
- Observe the sequence for uncoupling.
  1. Hydraulic hose P
  2. Hydraulic hose LS
  3. Hydraulic hose T

1. Swivel the actuation lever on the tractor control unit on the tractor to float position (neutral position).
2. Release the hydraulic connectors from the hydraulic sockets.
3. Protect the hydraulic connector and hydraulic connector socket from soiling using the dust protection caps.
4. Place the hydraulic hose lines in the hose cabinet.

## 5.6 Pneumatic brake system



Observing the maintenance intervals is essential for proper functioning of the dual line service brake system.


The brake drums are fitted with self regulating brake levers that make sure that the wear to the brake linings is compensated.

(1) Brake valve

(2) Release valve with actuation button

The actuation button

- must be pushed in up to the stop to release the service brake system, e.g. to manoeuvre the uncoupled trailed sprayer.
- must be pulled out up to the stop and the trailed sprayer is braked again by the supply pressure coming from the air reservoir.




(3) Line filter

(1) Air reservoir

(2) Drainage valve for condensation water.


(3) Test connection



### • Dual-circuit pneumatic braking system

(1) Brake line coupling head (yellow)

(2) Supply line coupling head (red)



---

**Automatic load-dependent braking force regulator (ALB)**


---

**WARNING****Risk of accident due to improper function of the brake system!**

You may not change the adjustment dimension on the automatic load-dependent braking force regulator. The adjustment dimension must correspond to the value specified on the ALB rating plate.

The axles are fitted with an automatic load-dependant braking force regulator (ALB).

The setting data depends on the axle load and is found on the ALB rating plate.



## 5.6.1 Coupling the brake system



### WARNING

**Risk of contusions, cuts, dragging, catching or knocks from incorrectly functioning brake system.**

- When coupling the brake and supply line, ensure that:
  - the sealing rings of the coupling heads are clean.
  - the sealing rings of the coupling heads form a proper seal.
- Always replace damaged seals immediately.
- Drain the air reservoir before the first journey every day.
- Only move off with the implement connected when the pressure gauge on the tractor shows 5.0 bar!



### WARNING

**Risk of crushing, cutting, being caught or drawn in, or impact through the accidentally rolling implement, if the service brake is released.**

#### **Dual-circuit pneumatic braking system:**

- Always couple the hose coupling on the brake line (yellow) first and then the hose coupling on the supply line (red).
- The service brake on the machine is immediately released from the brake setting if the red hose coupling is coupled.

1. Open the cover of the coupling head on the tractor.
2. Pneumatic braking system:
  - **Dual-circuit** pneumatic braking system:
    - 2.1 Properly fasten the coupling head of the brake line (yellow) in the coupling marked in yellow on the tractor.
    - 2.3 Properly fasten the coupling head of the supply line (red) in the coupling marked red on the tractor.

→ When coupling the supply line (red), the supply pressure coming from the tractor automatically pushes out the button for the release valve on the trailer brake valve
  - **Single-circuit** pneumatic braking system:
    - 2.1 Properly fasten the coupling head (black) onto the tractor.
3. Release the parking brake and/or remove the wheel chocks.

### 5.6.2 Uncoupling the brake system



#### WARNING

**Risk of crushing, cutting, being caught or drawn in, or impact through the accidentally rolling implement, if the service brake is released.**

#### Dual-circuit pneumatic braking system:

- Always uncouple the supply line hose coupling (red) first, and then the brake line hose coupling (yellow).
- The service brake of the machine only moves into the brake position when the red hose coupling has been uncoupled.
- Halten Sie diese Reihenfolge unbedingt ein, da sonst die Betriebs-Bremsanlage löst und sich die ungebremste Maschine in Bewegung setzen kann.



When the implement is uncoupled or torn off, the supply line to the trailer brake valve is vented. The trailer brake valve is automatically switched over and actuates the service brake system depending on the automatic load-dependent braking force regulation.

1. Secure the implement against unintentionally rolling away. To do this, use the parking brake and / or the wheel chocks.
2. Pneumatic braking system
  - **Dual-circuit** pneumatic braking system:
    - 2.1 Release the supply line coupling head (red).
    - 2.2 Release the brake line coupling head (yellow).
  - **Single-circuit** pneumatic braking system:
    - 2.1 Release the coupling head (black).
3. Close the covers of the coupling heads on the tractor.

## 5.7 Hydraulic operating brake system

To control the hydraulic service brake system, the tractor requires a hydraulic braking device.

### 5.7.1 Coupling the hydraulic service brake system



Only couple clean hydraulic connectors.

1. Remove the protective caps.
2. If necessary, clean the hydraulic connector and hydraulic socket.
3. Couple the implement's hydraulic socket with the tractor's hydraulic connector.
4. Tighten the threaded hydraulic union hand tight (if present).

### 5.7.2 Uncoupling the hydraulic service brake system

1. Loosen the hydraulic screw connection (if present).
2. Protect the hydraulic connector and hydraulic connector socket from soiling using the dust protection caps.
3. Place the hydraulic hose line in the hose cabinet.

### 5.7.3 Emergency brake


If the implement is disconnected from the tractor while driving, the emergency brake stops the implement.

- (1) Ripcord
- (2) Brake valve with pressure reservoir
- (3) Hand pump to relieve the brake
- (A) Brake released
- (B) Brake actuated



#### **DANGER**

**Before driving off, put the brake into operating position.**





Here's how:

1. Attach the ripcord to a sturdy point on the tractor.
  2. Actuate the tractor brake with the tractor motor running and the hydraulic brake connected.
- Pressure accumulator of the emergency brake will be charged.

**DANGER****Risk of accidents due to disfunctional brakes!**

After pulling out the spring cotter pin (e.g. when triggering the emergency brake), be sure to reinsert the spring cotter pin into the brake valve from the same side. Otherwise, the brakes are without function.

After the spring cotter pin has been reinserted, it is necessary to perform a brake test for the service brake and for the emergency brake.



When the implement is uncoupled, the pressure accumulator presses hydraulic oil:

- into the brake and brakes the implement,
- or
- into the hose line to the tractor and impedes the coupling of the brake line to the tractor.

In these cases, relieve pressure using the hand pump on the brake valve.


## 5.8 Parking brake

The applied parking brake secures the uncoupled implement against accidental rolling away. The parking brake is actuated with the spindle and cable pull when turning the crank.

(1) Crank; locked in resting position


(2) Crank in operating position

new



- Crank position for releasing / applying in the end area.


(the parking brake requires approx. 20 kg manual force to be applied).



- Crank position for quick releasing / applying.

(A) Apply the parking brake.


(B) Release the parking brake.




- Correct the setting of the parking brake if the spindle's tension is no longer sufficient.
- Ensure that the cable pull is not lying or rubbing against other vehicle parts.
- When the parking brake is released, the cable pull must be slightly slack.

## 5.9 Foldable wheel chocks

The wheel chocks are fastened in a swivelling mount under the right flushing water tank.




Put the foldable wheel chocks into operating position by pressing the button and apply directly on the wheels before uncoupling.



## 5.10 Safety chain between tractor and implements

Depending on country-specific regulations, implements are equipped with a safety chain.

The safety chain must be mounted at a suitable point on the tractor as prescribed before travelling.



## 5.11 AutoTrail steering axle

The AutoTrail tracking control serves for precise tracking of the implement behind the tractor.



See operating manual for software ISOBUS.

### Transportation



#### **DANGER**

##### **Risk of accident caused by turning the machine over !**

- For road transport, set the steering axle to transport position!
- It is forbidden to transport the implement with AutoTrail switched on.

On the control terminal, for this purpose:

1. Set the steering axle to centre position

On the control terminal, for this purpose:



- 1.1 Put AutoTrail in manual operation.



- 1.2 Move to the middle position.

- 1.3 Move the machine until the centre position is reached.

AutoTrail stops automatically when it reaches the centre position.

2. Switch off the control terminal.
  3. Actuate tractor control unit *red*.
- Switch off oil circulation.

## 5.12 Hydraulic jack

The hydraulically actuated jack supports the uncoupled trailed sprayer. It is actuated using a double-acting control valve.

### Blue tractor control unit



#### DANGER

When parking the implement on the hydraulic jack, it may only be slanted by max. 30° from the vertical plane.



- When actuating the jack, step on the tractor clutch to relieve the pin of the trailer coupling / hitch.




Before starting off, check the raised position of the jack!

### 5.13 Spray liquid tank

The spray liquid tank is filled via

- the filling opening,
- the suction hose (optional) on the suction port,
- the pressure filling connection (optional)



- (1) Spray liquid tank
- (2) Internal cleaning
- (3) Folding screw lid for the filling opening
- (4) External filling
- (5) Filling sieve
- (6) Ventilation
- (7) Float for determining the fill level
- (8) Agitator
- (9) Secondary agitator
- (10) Drain
- (11) XtremeClean high-pressure cleaning, only for Comfort Package / Comfort Package Plus

#### Folding screw lid for the filling opening

- To open the lid, rotate to the left and swing open.
- To close the lid, fold down and rotate to the right until tight.

### 5.13.1 Agitators

---

The field sprayer has a main agitator and an additional agitator. Both agitators are designed as hydraulic agitators. The additional agitator is also combined with pressure filter rinsing for the self cleaning pressure filter.

The main agitator has its own agitator pump. The additional agitator is supplied by the operation pump.

When the agitators are switched on, they mix the spray liquid in the spray liquid tank and therefore ensure that the spray liquid is homogeneous.

The main agitator can be adjusted at 4 levels. In doing so, the intensity is regulated according to the fill level.


The additional agitator is switched off

- when the tank fill level is low,
- to achieve high application rates.



### 5.13.2 Maintenance platform with ladder

Maintenance platform with ladder to reach the inspection hatch.




#### **DANGER**

- **Risk of injury from toxic vapours!**  
Never climb into the spray liquid tank.
- **Risk of falling when riding on the implement!**  
It is strictly forbidden to ride on the field sprayer!



Ensure that the ladder is locked in transport position.

- (1) Ladder locked in transport position.
- (2) Automatic locking mechanism with unlocking using the hand lever



## 5.14 Flushing water tank

Clear fresh water is carried in the flushing water tank. This water is used to

- dilute the residual quantity in the spray liquid tank when finishing spraying operation.
- clean (flush) the whole field sprayer in the field.
- clean the suction chest and the spray lines when the tank is full.




Fill only clear fresh water in the flushing water tank.

Each side of the two-part flushing water tank has its own filling opening at the rear.


It is best to fill the tank via the connections on the control panel.

Total content: 580 l



## 5.15 Hand wash unit

- (1) Hand wash tank (tank content: 22l)
- (2) Filling opening with lid
- (3) Stop tap for clear fresh water
  - o for hand washing or
  - o for cleaning the spray nozzles.
- (4) Soap dispenser



### WARNING

#### Risk of poisoning by contaminated water in the hand wash tank!

Never use the water from the hand wash tank as drinking water! The materials of the hand wash tank are not food safe.



### WARNING

#### Forbidden contamination of the hand wash tank with crop protection products or spray liquid!

Only fill the hand wash tank with clear fresh water, and never with crop protection product or spray liquid.




Ensure that you always carry enough clear fresh water when operating the field sprayer. Check and fill the hand wash tank when you fill the spray liquid tank.

## 5.16 Pump equipment

Spray liquid pump equipment with universal joint shaft drive or hydraulic drive

- (1) Spray liquid pump
- (2) Agitator pump



**Never exceed the maximum permissible pump drive speed of 540 rpm!**

### Hydraulic pump drive

- The maximum pump speed is hydraulically limited to 540 rpm.
- The pump speed is adjusted and displayed via the control terminal.

## 5.17 Filter equipment




- Use all the filters provided with the filter equipment. Clean the filters regularly (refer to the "Cleaning" section, page 188). Fault-free field sprayer operation can only be achieved by correct filtering of the spray liquid. Correct filtering has a significant effect on the success of the crop protection measures.
- Pay attention to the permissible combinations of filters and mesh sizes. The mesh sizes for the self cleaning pressure filter and the nozzle filters must always be smaller than the nozzle opening of the nozzles in question.
- Ensure that the use of pressure filter inserts with 80 or 100 mesh / inch for some crop protection agents can filter out active agents. In individual cases, enquire with crop protection agent manufacturers.

### Sieve against foreign objects

The sieve against foreign objects (1) prevents contamination of the spray liquid tank through the inspection hatch.

Mesh size: 1.00 mm



#### 5.17.1 Suction filter

The suction filter filters

- the spray liquid during spraying operation.
- the water when filling the spray liquid tank via the suction hose.

Mesh size: 0.60 mm



### 5.17.2 Self-cleaning pressure filter

The self cleaning pressure filter

- prevents the nozzle filter upstream of the spraying nozzle from becoming blocked.
- has a greater mesh count/inch than the suction filter.

When the additional agitator is switched on, the inside surface of the pressure filter insert is constantly flushed through, and undissolved particles of spray agent as well as dirt are conveyed back to the spray liquid tank.



#### Overview of the pressure filter inserts


- 50 mesh/inch (standard), blue  
for nozzle size '03' and larger  
Filter area: 216 mm<sup>2</sup>  
Mesh size: 0.35 mm
- 80 mesh/inch, yellow  
for nozzle size '02'  
Filter area: 216 mm<sup>2</sup>  
Mesh size: 0.20 mm
- 100 mesh/inch, green  
for nozzle size '015' and smaller  
Filter area: 216 mm<sup>2</sup>  
Mesh size: 0.15 mm

### 5.17.3 Nozzle filters


The nozzle filters (1) prevent clogging of the spray nozzle.

#### Overview of the nozzle filters

- 24 mesh/inch,  
for nozzle size '06' and larger  
Filter area: 5.00 mm<sup>2</sup>  
Mesh size: 0.50 mm
- 50 mesh/inch (standard),  
for nozzle size '02' to '05'  
Filter area: 5.07 mm<sup>2</sup>  
Mesh size: 0.35 mm
- 100 mesh/inch,  
for nozzle size '015' and smaller  
Filter area: 5.07 mm<sup>2</sup>  
Mesh size: 0.15 mm






## 5.18 Application rate increase with HighFlow

- Optional application rate increase for applying liquid fertiliser.  
The maximum application rate is increased to up to max. 400 l/min.
  - In doing so, the agitator pump is used to increase the application rate. It is then only partially used as an agitator drive, or not at all.
-  When using HighFlow, ensure sufficient agitator capacity.
- The high-performance liquid fertilisation is switched on and off via the control terminal.

The HighFlow valve chest is located on the right of the platform.


- (1) Additional pressure filter
- (2) Switch tap for secondary agitator / draining the residual quantity from the pressure filter

- o  Agitator running at maximum
- o **0** – Agitator off
- o  Drain pressure filter



Control terminal: Multi-function display

- (1) The display of the rate control valve position as a bar diagram provides information as to whether the forward speed / application rate can be increased or the agitator capacity must be reduced.
- The more bars are marked, the greater the quantity that is delivered to the boom.
- (2) The digit (value 1-6) for HighFlow shows the portion that is used by the agitator pump for spraying.

(1)	(2)
	3




## 5.19 Towing device (optional)

The automatic drawbar is used to pull braked trailers

- with a permissible total weight of 12000 kg and pneumatic brake.
- with a permissible total weight of 8000 kg and overrun brake.
- with a total weight that is lower than the permissible total weight of the field sprayer.
- without drawbar load.
- with towing eye 40 DIN 74054.


- (1) Drawbar
- (2) Lighting connection
- (3) Brake connection



To unlock the towing device, pull on the knob (1) and turn until it engages in the upper notch (2). Then swivel the lever (3) up until the pin is unlocked.



The drawbar of the trailer must be long enough to prevent collisions with the boom when driving in curves.



### WARNING

**Risk of crushing when coupling the machine and standing between the machine and the trailer!**

Instruct people to leave the danger area between the machine and the trailer before you approach the trailer.

Coupling the trailer via the automatic drawbar is a one-man operation. Helpers as guides are not necessary.




### WARNING

**When coupling and uncoupling trailers, observe the safety instructions in the section about coupling and uncoupling the implement, page 136.**



## 5.20 Safety device against unauthorised use

Lockable device for the drawbar eye, ball bracket, or lower link crosspiece, prevents unauthorised use of the machine.




## 5.21 Underbody panelling

The underbody panelling ensures a smooth underside of the implement that protect the plants.



## 5.22 Drag hose pre-equipment

700 mm-wide mudguards and deflector plates on the hood, flushing water tank, and mudguards prevent damage to the drag hoses.




## 5.23 Exterior wash down kit (optional)

Exterior wash down kit for cleaning the field sprayer, includes

- (1) Hose coiler,
- (2) 20 m pressure hose,
- (3) Spray gun

Operating pressure: 10 bar

Water output: 18 l/min



### WARNING

**Danger from liquids escaping under pressure and contamination with spray liquid if the spray gun is activated accidentally!**

Secure the spray gun against unintentional spraying using the locking mechanism (1)

- before each pause in spraying.
- before depositing the spray gun in its holder after cleaning work is complete.



## 5.24 Camera system



### WARNING

#### Risk of injury or even death.

If the camera display alone is used for manoeuvring, persons or objects can be overlooked. The camera system is an aid. It does not replace the operator's awareness of the immediate surroundings.


- **Before manoeuvring, ensure that there are no people or objects in the manoeuvring area by taking a direct look**

The implement can be equipped with a camera (1).

Features:

- Viewing angle of 135°
- Heater and lotus coating
- Infrared night-view technology
- Automatic backlight compensation

Super-L boom



## 5.25 Work lights (optional)


2 work floodlights on the sprayer boom and 2 work floodlights on the platform.



LED individual nozzle illumination:



Lighting package for the control panel and storage compartment



2 variants:

- Separate power supply from the tractor is required, operation via the control box.
- Power supply and operation via ISOBUS.

## 5.26 Control terminal

### ISOBUS control terminal in the tractor

The following are performed via the control terminal:

- input of implement-specific data.
- input of job-related data.
- control of the field sprayer to change the application rate used in spraying operation.
- the operation of all functions on the sprayer boom.
- the operation of special functions.
- the monitoring of the field sprayer during spraying operation.

The control terminal controls a job computer. Here, the job computer receives all necessary information and manages the area-based regulation of the application rate [l/ha] depending on the quantity (target quantity) entered and the current operational speed [km/h].



See operating manual for software ISOBUS.

**AmaTron 4**



**AmaPad 2**



## 5.27 Personal protective equipment Safety Kit

The safety kit is the personal protective equipment for handling crop protection products as a handy safety kit case from AMAZONE.



## 6 Layout and function of the sprayer boom



### WARNING

**Risk of injury for people due to impact with the sprayer boom when**

- **the boom sections swivel to the sides when folding**
- **tilting, lifting or lowering**

Instruct people to leave the danger area of the machine before you operate the sprayer boom.

Proper condition of the sprayer boom as well as its suspension significantly affect the distribution accuracy of the spray liquid. When the spraying height of the sprayer boom to the crop is set correctly, complete overlap is achieved. Nozzles are attached to the boom at intervals of 50 cm (alternatively 25 cm).

The sprayer boom is operated using the ISOBUS control terminal.



Depending on the machine equipment, the following functions can be performed via the boom kinematics function group:

Profi-folding consists of the following functions:

- Folding and unfolding the sprayer boom,
- Hydraulic height adjustment,
- Hydraulic tilt adjustment,
- One-sided sprayer boom folding
- One-sided, independent angling up and down of the sprayer boom / boom sections (Profi-folding II only).
- Automatic boom ride.

---

**Folding out and in**

---

**CAUTION**

It is prohibited to fold and unfold the sprayer boom while driving.

**DANGER**

Always maintain an adequate distance from overhead cables when folding and unfolding the sprayer boom! Contact with overhead cables may lead to fatal injuries.

**WARNING**

**Risk of crushing the entire body and impact due to personnel becoming trapped by laterally-swivelling machine parts.**

These dangers can cause extremely serious and potentially fatal injuries.

Maintain an adequate safety distance from moving machine parts while the tractor engine is running.

Ensure that all personnel maintain an adequate safety distance from moving machine parts.

Instruct personnel to leave the swivel range of any moving machine parts before swivelling the parts.

**WARNING**

**Danger for third parties from crushing, being drawn in and/or caught by the moving parts of the boom or impact if they stand in the swivel range of the boom while it is folding out or in.**


- Instruct personnel to leave the swivel range of the boom before you fold the boom out or in.
- Release the control for folding the boom out and in immediately if someone enters the swivel range.

### Outer boom locking


#### Outer boom

The outer boom locking mechanisms protect the boom from damage if the outer boom sections come into contact with solid obstructions. The locking mechanism enables the outer boom section to avoid collision by moving around the articulated axle in and against the direction of travel; it is then automatically returned to its working position.

Boom section locking with compression spring:



Boom section locking with hydraulic cylinder:




#### Centre boom section

##### Flex-folding

The centre boom section locking mechanisms protect the boom from damage when the centre boom section hits solid obstacles. The locking mechanism enables deflection opposite to the direction of travel when driving forward.


To return into position, the sprayer boom must be completely unfolded again.

Before moving off again, check the boom for damage.





## 6.1 Super-L boom



- |  |   |
|--|---|
| (1) Sprayer boom with spray lines                                    | (6) Outer boom locking                  |
| (2) Transport safety bow   | (7) Vibration compensation              |
| (3) Parallelogram frame for adjusting the height of the sprayer boom | (8) Valve and switch tap for DUS system |
| (4) Nozzle protection tube   | (9) Boom equipment                      |
| (5) Spacer   |   |

## Layout and function of the sprayer boom


### Spacer

The spacer prevents collisions of the boom with the ground.

When using certain nozzles, the spacers are within the spray cone.

In this case, attach the spacers horizontally on the carrier.

Use thumb bolts.




### Locking and unlocking the transport locking mechanism

The transport safety bow is used to lock the folded sprayer boom in transport position to prevent unintentional unfolding.

#### Unlocking the transport locking mechanism

Before unfolding the sprayer boom, swivel the transport safety bows upwards, thereby unlocking the sprayer boom (A).



#### Locking the transport locking mechanism

After folding the sprayer boom, swivel the transport safety bows downwards, thereby locking the sprayer boom (B).

## Working with the sprayer boom unfolded on one side



It is permitted to work with the sprayer boom unfolded on one side

Profi-folding:

- only with the vibration compensation locked
- briefly for passing obstacles (trees, electricity pylons, etc.).

Flex-folding:

- Up to a forward speed of 6 km/h

### The sprayer boom is completely unfolded!

1. Raise the sprayer boom to mid-height.
2. Fold the desired boom sections.




It is forbidden to work with the boom folded into transport position on one side.

### After folding, the boom section swivels forward into transport position!

Interrupt the folding procedure in due time for one-sided spraying!

3. Align the sprayer boom horizontally.
4. Set the spraying height of the sprayer boom such that the sprayer boom has a distance of at least 1 m from the ground surface.
5. Switch off the part-width sections of the folded boom sections.
6. During spraying operation, drive with a considerably reduced speed.



## 6.2 Reduction joint on the outer boom (optional)

Using the reduction joint, the outer element of the outer boom can be folded manually to reduce the working width.

Case 1:

Number of nozzles outer part width section	=	Number of nozzles on the foldable outer element
---	---	--

→ When spraying with a reduced working width, keep the outer part width sections switched off.


Case 2:

Number of nozzles outer part width section	≠	Number of nozzles on the foldable outer element
---	---	--

→ Close the outer nozzles manually (triple nozzle head).

→ Perform changes on the control terminal.

- Enter the changed working width.
- Enter the changed number of nozzles on the outer part width sections.



2 bolts lock the folded and unfolded outer element in its respective end positions.



### CAUTION

Before road transport, unfold the outer elements again so that the transport locking mechanism is active when the boom is folded.


### 6.3 Boom width reduction (option)

With the boom width reduction, one or two booms can remain folded in during operation depending on the version.

In addition, switch on the hydraulic accumulator (optional) as a collision protection.



The corresponding part-width sections have to be switched off on the control terminal.



- (1) Boom width reduction
- (2) Hydraulic accumulator (optional)
- (A) Stop tap opened
- (B) Stop tap closed

#### Working with reduced working width

1. Reduce the boom width hydraulically.
2. Close the stop taps for the boom width reduction.
3. Open the stop tap for the boom damping.
4. Switch off the corresponding part-width sections on the control terminal.
5. Perform work with reduced working width.



Close the stop tap for the boom damping.

- For road transport
- For use with full working width

## Layout and function of the sprayer boom


### Sensors on the boom:

When working with reduced working width with automatic boom guidance, a boom section might be interfering with the sensor.

In this case:


- (1) Install the sensor rotated by 180°.
- (2) DistanceControl plus: disconnect the inner sensor.

ContourControl: deactivate the inner sensor (ISOBUS software).



## 6.4 Boom extension (option)

The boom extension increases the working width infinitely up to 1.20 metres.



- (1) Boom extension in transport position
- (2) Boom extension in working position
- (3) Stop tap for the outer nozzle
  - (A) Stop tap opened
  - (B) Stop tap closed
- (4) Wing bolts for securing the boom extension in the transport or working position

## 6.5 Hydraulic tilt adjustment (optional)

The sprayer boom can be aligned parallel to the ground or the target surface using the hydraulic tilt adjustment in event of unfavourable terrain conditions, e.g., with tracks that have different depths or driving in a furrow on one side.

Adjustment using control terminal




Refer to control terminal instruction manual.

## 6.6 DistanceControl (optional)

The sprayer boom regulating device DistanceControl automatically keeps the sprayer boom parallel at the desired distance from the target surface.

Ultrasonic sensors (1) measure the distance to the ground or the crop.

When the sprayer boom is switched off at the headlands, the sprayer boom is automatically lifted by approx. 50 cm. When it is switched on, the sprayer boom is lowered back to the calibrated height.




See operating manual for the ISOBUS software.

- Setting the ultrasound sensors:


→ See figure

## 6.7 Spray lines


### Spray lines with part-width section valves



### Spray lines with part-width section valves and DUS pressure circulation system



### Spray lines with single nozzle control and DUS Pro pressure circulation system



- |  |                            |
|--|----------------------------|
| (1) Flow meter                             | (6) DUS stop tap           |
| (2) Flow meter                             | (7) Pressure control valve |
| (3) Boom part width section valves         | (8) Check valve            |
| (4) Bypass valve for low application rates | (9) Pressure control valve |
| (5) Pressure circulation line              |                            |



## Pressure circulating system (DUS)




- For normal spraying operation, the pressure circulating system should always be switched on.
- When using drag hoses, the pressure circulating system should always be switched off.

### The pressure circulating system

- enables the constant circulation of liquid in the spray line. To do so, a suction port hose (1) is assigned to each part-width section.
- can be operated using spray liquid or flushing water, as desired.
- reduces the undiluted residue for all spray lines to 2 l.

### The constant circulation of liquid


- enables production of a uniform spray pattern right from the start, because spray liquid is available at every spray nozzle immediately after the sprayer boom is switched on, with no delay.
- prevents damage to the spray line.



## Line filter for spray lines (optional)

The line filter (1) is

- installed in the spray lines in each part-width section (part-width section control).
- installed in the spray lines on the left and right (single nozzle control)
- an additional measure to prevent contamination of the spraying nozzles.




### Overview of the filter inserts

- Filter insert with 50 mesh/inch (blue)
- Filter insert with 80 mesh/inch (grey)
- Filter insert with 100 mesh/inch (red)

### 6.8 Nozzles

- (1) Nozzle body with bayonet connection
  - o Spring element version with shutter
  - o Spring element version, bolted
- (2) Diaphragm. If the pressure in the spray line falls below approx. 0.5 bar, the spring element (3) presses the diaphragm onto the diaphragm seat (4) in the nozzle body. This ensures that when the sprayer boom is switched off, the nozzles are deactivated without subsequent dripping.
- (3) Spring element.
- (4) Shutter; holds the entire diaphragm valve in the nozzle body
- (5) Nozzle filter; fitted as standard on machines with 50 mesh/inch, is inserted from below into the nozzle body.
- (6) Rubber seal
- (7) Nozzle with bayonet cap



#### 6.8.1 Multiple nozzles

It is advantageous to use multiple nozzle heads when using different nozzle types.

Turning the multiple nozzle head counterclockwise brings a different nozzle into play.


The multiple nozzle head is switched off in the intermediate positions. This provides the possibility of reducing the working width of the boom.




Flush the spray lines before twisting the multiple nozzle head to another nozzle type.

### Triple nozzles (optional)


The vertically positioned nozzle is supplied.



### Quadruple nozzles (optional)




The arrow indicates the vertical nozzle that is being supplied.



The quadruple nozzle body can be equipped with a 25-cm nozzle holder. This results in a nozzle spacing of 25 cm.


The arrow indicates the label 25 cm when the nozzle spacing is set at 25 cm.



## Layout and function of the sprayer boom

Install the 25 cm nozzle holder.


If the 25 cm nozzle holder is not used, close the supply with plugs.



## 6.8.2 Edge nozzles


### Boundary nozzles, electric or manual

With boundary nozzle switching, the last nozzle can be switched off and a border nozzle, 25 cm further out (right at the edge of the field), can be electrically switched on.




### Electric end nozzle switching (optional)

Using end nozzle switching, up to three of the outer nozzles at the edge of the field close to a water source can be electrically switched off from the tractor).



### Electric additional nozzle switching (optional)

With the additional nozzle switching, another exterior nozzle is cut in, increasing the working width by one metre.




## 6.9 Automatic single nozzle control (optional)

50 cm part width sections can be controlled separately by the electric single nozzle control. In combination with the automatic part width section control "Section Control", overlapping can be reduced to a minimum area.


### 6.9.1 Single nozzle control AmaSwitch

Each nozzle can be switched on and off separately via Section Control.


- (1) Nozzle body
- (2) Union nut with diaphragm seal
- (3) Motor valve




### 6.9.2 4-way AmaSelect single nozzle control



- The sprayer boom is fitted with 4-way nozzle bodies. Each of them is operated by an electric motor.
- The nozzles can be switched on or off as desired (depending on Section Control).
- Due to the 4-way nozzle bodies, several nozzles can be simultaneously active in a nozzle body.
- For boundary treatment, an extra nozzle body can be separately configured.
- LED single nozzle illumination integrated in the nozzle body.



- Nozzle spacing of 25 cm is possible (optional)  
During installation, please note that the two outlets pointing to the front on the implement side must be used for installation.




### Manual nozzle selection:

The control terminal can be used to select the nozzle or the nozzle combination.

### Automatic nozzle selection:

The nozzle or nozzle combination is automatically selected during spraying in accordance with the entered border conditions.



Symbol for nozzle housings - AmaSelect.

The arrow shows the direction of travel.

→ This is important for the assembly of the nozzles in the nozzle bodies!

## 6.10 Special optional equipment for liquid fertiliser

There are currently two main types of liquid fertiliser available:

- Ammonium nitrate / urea solution (AUS) with 28 kg N per 100 kg AUS.
- An NP solution 10-34-0 with 10 kg N and 34 kg P<sub>2</sub>O<sub>5</sub> per 100 kg NP solution.



If the liquid fertiliser is sprayed using flat-fan nozzles, multiply the corresponding values from the spray table for the application rate (l/ha) by 0.88 for AUS and by 0.85 for NP solutions, as the application rates listed (in l/ha) only apply for water.

### As a rule:

Use coarse-dropped application for liquid fertiliser to avoid chemical burns to the plants. Overly large drops roll off the leaf and drops which are too small cause a magnifying glass effect, which burns the leaves. Too much fertiliser may cause burns to appear on the leaves due to the salt concentration in the fertiliser.

As a rule, do not spray more liquid fertiliser than, for example, 40 kg N (see also "Conversion table for spraying liquid fertiliser"). Always discontinue nozzle-based UAN fertilisation at development stage EC-39, because chemical burns on ears have a particularly harmful effect

### 6.10.1 Three-ray nozzles (optional)

The use of three-ray nozzles for applying liquid fertiliser is beneficial if the liquid fertiliser needs to be taken up more by the roots of the plant than through the leaves.

Thanks to its three openings, the dosing aperture, which is integrated into the nozzle, ensures a coarse-dropped, almost depressurised distribution of the liquid fertiliser. This prevents an undesirable spray mist and the formation of smaller drops. The coarse drops produced by the three-ray nozzle hit the plants with little force and roll off their surface. **Although this avoids damage from burns to the greatest extent possible, avoid the use of three-ray nozzles for late top dressing and use drag hoses.**

For all three-ray nozzles listed in the following, only use the black bayonet nut.

#### Different three-ray nozzles and their operational areas (at 8 km/h)

- yellow 50 - 80 l UAN/ha
- red 80 - 126l UAN / ha
- blue 115 - 180l UAN / ha
- white 155 - 267l UAN / ha



### 6.10.2 7-hole nozzles / FD nozzles (optional)


The same conditions apply for using 7-hole nozzles / FD nozzles as for the 3-ray nozzles. In contrast to the three-ray nozzle, in the case of the 7 hole nozzle / FD nozzles, the outlets are not oriented downwards, but instead point to the side. This allows very large drops to be produced on the plants using only slight impact forces.

**The following 7-hole nozzles are available:**

- SJ7-02-CE 74 – 120l UAN (at 8 km/h)
- SJ7-03-CE 110 – 180l AUS
- SJ7-04-CE 148 – 240l AUS
- SJ7-05-CE 184 – 300l AUS
- SJ7-06-CE 222 – 411l AUS
- SJ7-08-CE 295 – 480l AUS

**The following FD nozzles are available:**


- FD 04 150 - 240 l UAN/ha (at 8 km/h)
- FD 05 190 - 300 l AUS/ha
- FD 06 230 - 360 l AUS/ha
- FD 08 300 - 480 l AUS/ha
- FD 10 370 - 600 l UAN/ha\*




### 6.10.3 Drag hose equipment for Super-L boom (optional)

- with metering discs for late top dressing with liquid fertiliser

- (1) Drag hoses at 25 cm intervals, after fitting the 2nd spray line.
- (2) Bayonet connection with dosing discs.
- (3) Metal weights - stabilise the position of the hoses during operation.



- (1) one setting tap for every boom part width section:
  - a Spraying via both spray lines with drag hoses
  - b Spraying via a standard spray line
  - c Spraying via the 2nd spray line only




Remove drag hoses for normal spraying operation.

After removing the drag hoses, seal off the nozzle bodies with blanks

- (1) Transport hooks



When working with drag hoses, the two transport hooks must be screwed on lower down. In transport position, the distance between the nozzle and the mudguard should be 20 cm! For normal spraying operation, the two transport hooks should be screwed back on in the original position!



## 7 Start-up

This section contains information

- on initial operation of your implement
- on checking how you may couple/mount the implement to your tractor.



- Before operating the implement for the first time the operator must have read and understood the operating manual.
- Follow the instructions given in the section "Safety instructions for the operator" from page 30 onwards when
  - Coupling and uncoupling the implement
  - Implement transportation
  - Use of the implement
- Only couple and transport the implement to/with a tractor which is suitable for the task.
- The tractor and implement must meet the national road traffic regulations.
- The operator and the user shall be responsible for compliance with the statutory road traffic regulations.



### WARNING

**Risk of contusions, cutting, catching, drawing in and knocks in the area of hydraulically or electrically actuated components.**

Do not block the operator controls on the tractor which are used for hydraulic and electrical movements of components, e.g. folding, swivelling and pushing movements. The movement must stop automatically when you release the appropriate control. This does not apply to equipment movements that:

- are continuous or
- are automatically locked or
- require a float position or pressure position due to their function

### 7.1 Antifreeze in the spray liquid tank

Depending on the season and marking on the implement, the implement is protected with a biodegradable antifreeze against damage due to freezing temperatures.

The antifreeze can be sprayed out with the spray liquid at first use or pumped out.

Antifreeze that was pumped out can be reused or disposed of properly.

## 7.2 Checking the suitability of the tractor



### WARNING

**Danger of breaking during operation, insufficient stability and insufficient tractor steering and braking power on improper use of the tractor!**

- Check the suitability of your tractor before you attach or hook up the implement.  
You may only connect the implement to tractors suitable for the purpose.
- Carry out a brake test to check whether the tractor achieves the required braking delay with the implement connected.

Requirements for the suitability of a tractor are, in particular:

- The permissible total weight
- The permissible axle loads
- The permissible drawbar load at the tractor coupling point
- The load capacity of the installed tyres
- The permissible trailer load must be sufficient

You can find this data on the rating plate or in the vehicle documentation and in the tractor operating manual.

The front axle of the tractor must always be subjected to at least 20 % of the empty weight of the tractor.

The tractor must achieve the brake delay specified by the tractor manufacturer, even with the implement connected.

### 7.2.1 Calculating the actual values for the total tractor weight, tractor axle loads and load capacities, as well as the minimum ballast



The permissible total tractor weight, specified in the vehicle documentation, must be greater than the sum of the


- tractor empty weight
- ballast weight and
- total weight of the attached implement or drawbar load of the hitched implement.



#### **This notice applies only to Germany:**

If, having tried all possible alternatives, it is not possible to comply with the axle loads and/or the permissible total weight, then a survey by an officially recognised motor traffic expert can, with the approval of the tractor manufacturer, be used as a basis for the responsible authority to issue an exceptional approval according to § 70 of the German Regulations Authorising the Use of Vehicles for Road Traffic and the required approval according to § 29, paragraph 3 of the German Road Traffic Regulations.

### 7.2.1.1 Data required for the calculation



$T_L$	[kg]	Tractor empty weight	See tractor operating manual or vehicle documentation
$T_V$	[kg]	Front axle load of the empty tractor	
$T_H$	[kg]	Rear axle load of the empty tractor	
$G_V$	[kg]	Front weight (if available)	See front weight in technical data, or weigh
$F_H$	KG	Actual drawbar load	determining
$a$	[m]	Distance between the centre of gravity of the front mounting implement or the front weight and the centre of the front axle (total $a_1 + a_2$ )	See technical data of tractor and front implement mounting or front weight or measurement
$a_1$	[m]	Distance from the centre of the front axle to the centre of the lower link connection	See tractor operating manual or measurement
$a_2$	[m]	Distance between the centre of the lower link connection point and the centre of gravity of the front-mounted implement or front ballast (centre of gravity distance)	See technical data of front implement mounting or front weight or measurement
$b$	[m]	Tractor wheel base	See tractor operating manual or vehicle documents or measurement
$c$	[m]	Distance between the centre of the rear axle and the centre of the lower link connection	See tractor operating manual or vehicle documents or measurement

## Start-up

### 7.2.1.2 Calculation of the required minimum ballasting at the front $G_{V \min}$ of the tractor for assurance of the steering capability

$$G_{V \min} = \frac{F_H \cdot c - T_V \cdot b + 0,2 \cdot T_L \cdot b}{a + b}$$

Enter the numeric value for the calculated minimum ballast  $G_{V \min}$ , required on the front side of the tractor, in the table (section 7.1.1.7).

### 7.2.1.3 Calculation of the actual front axle load of the tractor $T_{V \text{tat}}$

$$T_{V \text{tat}} = \frac{G_V \cdot (a + b) + T_V \cdot b - F_H \cdot c}{b}$$

Enter the numeric value for the calculated actual front axle load and the approved tractor front axle load specified in the tractor operating manual in the table (section 7.1.1.7).

### 7.2.1.4 Calculation of the actual total weight of the combined tractor and implement

$$G_{\text{tat}} = G_V + T_L + F_H$$

Enter the numeric value for the calculated actual total weight and the approved total tractor weight specified in the tractor operating manual in the table (section 7.1.1.7).

### 7.2.1.5 Calculation of the actual rear axle load of the tractor $T_{H \text{tat}}$

$$T_{H \text{tat}} = G_{\text{tat}} - T_{V \text{tat}}$$

Enter the numeric value for the calculated actual rear axle load and the approved tractor rear axle load specified in the tractor operating manual in the table (section 7.1.1.7).

### 7.2.1.6 Tyre load capacity

Enter the double value (two tyres) of the approved load capacity (see, for example, tyre manufacturer's documentation) in the table (section 7.1.1.7).

### 7.2.1.7 Table

	Actual value according to calculation	Approved value according to tractor operating manual	Double approved load capacity (two tyres)
Minimum ballast front/rear	<div style="border: 1px solid black; padding: 5px; display: inline-block;">/ kg</div>	--	--
Total weight	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	--
Front axle load	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>
Rear axle load	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>



- You can find the approved values for the total tractor weight, axle loads and load capacities in the tractor registration papers.
- The actual calculated values must be less than or equal to ( $\leq$ ) the permissible values!



#### WARNING

**Risk of contusions, cutting, catching, drawing in and knocks through insufficient stability and insufficient tractor steering and brake power.**

It is forbidden to couple the implement to the tractor used as the basis for calculation, if

- one of the actual, calculated values is greater than the approved value.
- there is no front weight (if required) attached to the tractor for the minimum front ballast ( $G_{V \min}$ ).



- You must use a front weight that is equal to at least the required minimum front ballast ( $G_{V \min}$ )!

## 7.2.2 Requirements for tractor operation with attached implements



### WARNING

**Risk of breakage during operation of components through unapproved combinations of connecting equipment!**

- Ensure that
  - the connection device on the tractor has a sufficient permissible drawbar load for the actual existing drawbar load.
  - the axle loads and weights of the tractor altered by the drawbar load are within the approved limits. If necessary, weigh them.
  - the static actual rear axle load of the tractor does not exceed the permissible rear axle load.
  - the permissible total weight of the tractor is complied with.
  - the approved load capacities of the tractor tyres are not exceeded.



### 7.2.2.1 Combination options of coupling devices

The table shows the permitted combination options of coupling devices for the tractor and implement.

Coupling device			
Tractor		AMAZONE implement	
Upper hitch			
Pin coupling, form A, B, C A not automatically B automatic smooth pin C automatic curved pin (ISO 6489-2)	Drawbar eye	Socket ø 40 mm	(ISO 5692-2)
	Drawbar eye	ø 40 mm	(ISO 8755)
	Drawbar eye	ø 50 mm, only compatible with form A	(ISO 1102)
Upper / lower hitch			
Ball head coupling ø 80 mm	(ISO 24347)	Ball coupling	ø 80 mm (ISO 24347)
Lower hitch			
Towing hooks / hitch hooks	(ISO 6489-19)	Drawbar eye	Centre bore Ø 50 mm Eyelet Ø 30 mm (ISO 5692-1)
		Swivel drawbar eye	compatible only with form Y, hole Ø 50 mm, (ISO 5692-3)
		Drawbar eye	Centre bore Ø 50 mm Eyelet Ø 30 - 41 mm (ISO 20019)
Drawbar - Category 2	(ISO 6489-3)	Drawbar eye	Centre bore ø 50 mm Eyelet ø 30 mm (ISO 5692-1)
			Socket ø 40 mm (ISO 5692-2)
			ø 40 mm (ISO 8755)
			ø 50 mm (ISO 1102)
Drawbar	(ISO 6489-3)		(ISO 21244)
Drawbar / Piton-fix	(ISO 6489-4)	Drawbar eye	Centre bore ø 50 mm Eyelet ø 30 mm (ISO 5692-1)
		Swivel drawbar eye	compatible only with form Y, hole Ø 50 mm (ISO 5692-3)
Yoke that cannot be rotated	(ISO 6489-5)	Swivel drawbar eye	(ISO 5692-3)
Lower link hitch	(ISO 730)	Lower link traverse (ISO 730)	

## 7.2.2.2 Compare the permissible $D_C$ value with actual $D_C$ value



### WARNING


**Danger from breaking the coupling devices between the tractor and the implement when the tractor is not used for its intended purpose!**

1. Calculate the actual  $D_C$  value of your combination, comprising tractor and implement.
2. Compare the actual  $D_C$  value with the following permissible  $D_C$  values:
  - Coupling device of the implement
  - Drawbar of the implement
  - Coupling device of the tractor

The actual  $D_C$  value calculated for the combination must be less than or equal ( $\leq$ ) to the  $D_C$  values specified.

The permissible  $D_C$  values of the implement can be found on the rating plate of the coupling device (1) and the drawbar (2).

The permissible  $D_C$  value of the tractor coupling device can be found directly on the coupling device / in the operating manual of your tractor.



**actually calculated**  
 **$D_C$  value for the combination**

$\text{kN}$
-------------

$\leq$   
 $\leq$   
 $\leq$


**specified  $D_C$  value**

Coupling device on the tractor	kN
Coupling device of the implement	kN
Drawbar of the implement	kN

## Calculate the actual $D_c$ value for the combination to be coupled

The actual  $D_c$  value of a combination to be coupled is calculated as follows:

$$D_c = g \times \frac{T \times C}{T + C}$$



- T:** permissible total weight of your tractor in [t] (See tractor operating manual or vehicle documentation)
- C:** axle load of the implement [t] loaded with the permissible mass without drawbar load (working load).
- g:** Gravity (9.81 m/s<sup>2</sup>)

## 7.3 Adjusting the length of the PTO shaft to the tractor



### WARNING

Danger due to

- **damaged and/or destroyed, flying parts for the operator/third persons may occur if the universal joint shaft is upended or pulls apart while the implement coupled to the tractor is being raised/lowered because the length of the universal joint shaft has not been adjusted properly.**
- **being caught and drawn in if the universal joint shaft is installed incorrectly or if unauthorised structural changes are made.**

Have the length of the universal joint shaft checked by a specialist workshop in all implement situations and, if necessary, adjusted before coupling the universal joint shaft to your tractor for the first time.

When adjusting the universal joint shaft, it is mandatory to observe the operating manual supplied by the universal joint shaft manufacturer.



This adjustment of the PTO shaft applies only for the current tractor type. You may have to readjust the universal joint shaft if you couple the implement to different tractor.



### WARNING

**Danger of being caught and drawn in if the PTO shaft is installed incorrectly or if unauthorised structural changes are made.**

Only a specialist workshop may make structural changes to the universal joint shaft. In doing so, the operating manual from the universal joint shaft manufacturer must be observed.

Adjusting the length of the universal joint shaft is permitted with consideration of the minimum profile overlap.

Structural changes to the universal joint shaft that are not described in the operating manual from the universal joint shaft manufacturer are not permitted.



### WARNING

**Risk of crushing between the rear of the tractor and the machine when raising and lowering the machine to determine the shortest and longest operating position of the PTO shaft.**

Only actuate the operator controls for the tractor's three-point linkage

- from the intended workstation.
- if you are outside of the danger area between the tractor and the machine.



### WARNING

#### Risk of crushing from unintentional:

- **rolling of the tractor and the connected machine.**
- **lowering of the raised machine.**

Secure the tractor and machine from unintentionally starting or rolling and secure the raised machine against unintentional lowering before entering the danger zone between the tractor and raised machine in order to adjust the PTO shaft.



The PTO shaft is at its shortest when it is horizontal. The PTO shaft is at its longest when the machine is fully lifted.

1. Couple the tractor to the machine (do not connect the PTO shaft).
2. Apply the tractor's parking brake.
3. Determine the clearance height of the machine with the shortest and longest operating position for the PTO shaft.
  - 3.1 To do so, raise and lower the machine via the tractor's three-point hydraulic system.  
While doing so, actuate the manual controls for the tractor's three-point hydraulic system on the rear of the tractor, from the provided workstation.
4. Secure the machine, lifted in the measured clearance height, against unintentional lowering (for example, by supporting it or hooking it to a crane).
5. Secure the tractor from unintentional starting before entering the danger area between the tractor and machine.
6. When measuring the length and shortening the PTO shaft, read and follow the operating manual from the PTO shaft manufacturer.
7. Put the shortened halves of the PTO shaft back together.
8. Grease the universal joint shaft of the tractor and the gearbox input shaft before connecting the PTO shaft.  
The tractor symbol on the protective tube of the PTO shaft identifies the tractor-side connection of the PTO shaft.

## 7.4 Securing the tractor / implement against unintentional start-up and rolling away



### WARNING

**Risk of crushing, shearing, cutting, being caught and/or drawn in, or impact when making interventions in the implement, through**

- **unintentional lowering of the unsecured implement when it is raised via the three-point hydraulic system of the tractor.**
- **unintentional falling of raised, unsecured machine parts.**
- **unintentional start-up and rolling of the tractor-implement combination.**
- Secure the tractor and the implement against unintentional start-up and rolling before any intervention in the machine.
- It is forbidden to make any intervention in the machine, such as installation, adjustment, troubleshooting, cleaning, maintenance and repairs
  - while the implement is being driven.
  - as long as the tractor engine is running with a connected universal joint shaft / hydraulic system.
  - If the ignition key is inserted in the tractor and the tractor engine can be started unintentionally with the PTO shaft / hydraulic system connected
  - if the tractor and implement are not each secured with their parking brakes and / or wheel chocks against accidentally rolling away.
  - If moving parts are not blocked against unintentional movement

When carrying out such work, there is a high risk of contact with unsecured components.


1. Lower any raised, unsecured implement/raised, unsecured implement parts.
- This prevents parts from being lowered unintentionally.
2. Shut down the tractor engine.
3. Remove the ignition key.
4. Apply the tractor parking brake.
5. Secure the implement against unintentional rolling away (only if the implement is hitched)
  - On level terrain, by using the parking brake (if fitted) or wheel chocks.
  - On uneven terrain or on slopes, by using the parking brake and wheel chocks.

## 7.5 Installing the wheels



To assemble the wheels, use:

- (1) conical rings in front of the wheel nuts.
- (2) only rims with a fitting countersink for the conical ring.



If the implement is equipped with emergency wheels, the running wheels must be installed before initial operation.



### WARNING

The wheel rims that fit on the tyres must have a rim that has been fully welded all the way round!



A extension for the hydraulic jack and ladder must be installed when tyres with a diameter greater than 1860 mm are used.

1. Lift the implement slightly using a lifting crane.



### DANGER

Use the marked attachment points for the slings.

See also "Loading" section, page 41.

2. Loosen the wheel nuts of the emergency wheels.
3. Remove the emergency wheels.



### CAUTION

Be careful when removing the emergency wheels and putting on the running wheels!



Required tightening torque for wheel nuts: 510 Nm.

4. Put the running wheels onto the stud bolts.
5. Tighten the wheel nuts.
6. Lower the implement and remove the slings.
7. Retighten the wheel nuts after 10 operating hours.


## Steering axle



The steering angle of the steering axle must be limited depending on the wheels.

Otherwise, the wheel can collide with the implement.

- (1) Adjust using the stop screw and lock nut.
- (2) Make adjustments using the spacers.



## 7.6 Initial operation of service brake system



Perform a braking test for the trailed sprayer in an empty and loaded state to test the braking behaviour of the tractor and coupled trailed sprayer.

We recommend that you have a specialist workshop coordinate the brakes on the tractor and trailed sprayer in order to attain optimum braking and minimum wear to brake linings (see "Maintenance" section, page 201).



## 7.7 Adjusting the hydraulic system




The hydraulic block is located at the front right on the implement behind the cover plate.




- Be sure to match the hydraulic systems of the tractor and the implement.
- The implement hydraulic system is adjusted using the system setting screw on the hydraulic block of the implement.
- Elevated hydraulic oil temperatures are the result of incorrect adjustment of the system setting screw, caused by persistent strain on the pressure relief valve of the tractor hydraulic system.
- Adjustments may only be made in a pressureless state!
- If there are hydraulic malfunctions between the tractor and the implement during start-up, please contact your service partner.

- (1) Setting tap can be set to Position A and B
- (2) LS connection for the load sensing control line



Implement-side connections:

- (1) P – feed line, pressure line, plug standard width 20
- (2) LS – control line, plug standard width 10
- (3) T - return line, socket standard width 20



## Start-up

- (1) Open-Center hydraulic system with constant flow pump (gear pump) or setting pump.

→ Select setting A wählen.



Setting pump: Set the maximum required oil quantity on the tractor control unit. If the oil quantity is insufficient, correct functioning of the implement cannot be ensured.

- (2) Load-Sensing hydraulic system (pressure- and flow-regulated setting pump) with direct load sensing pump connection and LS setting pump.

→ Select setting B wählen.

- (3) Load-Sensing hydraulic system with constant flow pump (gear pump).


→ Select setting B wählen.

- (4) Closed-Center hydraulic system with pressure-regulated setting pump.

→ Select setting B wählen.



Risk of overheating of the hydraulic system: the Closed-Center hydraulic system is less suitable for the operation of hydraulic motors.




## 7.8 Installing the sensor for the steering axle

- 1 To install the sensor in the cab or external area, use a rigid and vibration-free mechanical connection of the sensor to the basic frame or a bearing element in the cabin.
2. Mount the sensor horizontally.
3. Connect the sensor to the implement's wiring harness.



- Protect the sensor against dirt deposits.
- The sensor must not be painted.
- Do not use a power wrench for the installation.
- Maintain a minimum distance of 20 cm from mobile radio devices.



## 8 Coupling and uncoupling the implement



When coupling and uncoupling machines, follow the instructions given in the section "Safety instructions for the operator" page 30.



### WARNING

**Risk of contusions from unintentional starting and rolling of the tractor and implement when coupling or uncoupling the implement!**

Secure the tractor and implement against unintentional start-up and rolling away before entering the danger area between the tractor and implement to couple or uncouple the implement, see page 130 for more information.

### 8.1 Coupling the implement



### WARNING

**Danger of breaking during operation, insufficient stability and insufficient tractor steering and braking power on improper use of the tractor!**

You may only connect the implement to tractors suitable for the purpose. See section "Checking tractor suitability", page 120.



### WARNING

**Risk of contusions when coupling the implement and standing between the tractor and the implement!**

Instruct people to leave the danger area between the tractor and the implement before you approach the implement.

Any helpers may only act as guides standing next to the tractor and the implement, and may only move between the vehicles when both are at a standstill.



### WARNING

**Risk of crushing, catching, drawing in and impacts when the implement unexpectedly releases from the tractor!**

- Use the intended equipment to connect the tractor and the implement in the proper way.



### WARNING

#### **Risk of energy supply failure between the tractor and the implement through damaged power lines!**

During coupling, check the course of the power lines. The supply lines

- must give slightly without tension, bending or rubbing on all movements of the connected implement.
- must not chafe against other parts.

1. Instruct people to stay out of the danger area between the tractor and the implement before you drive up to the implement.




First couple the supply lines before coupling the implement to the tractor.

2. Drive tractor up to the implement such that a free space (approx. 25 cm) remains between tractor and implement.
3. Secure the tractor against unintentional start-up and unintentional rolling.
4. Check whether the PTO shaft of the tractor is switched off.
5. Couple the universal joint shaft.



Couple the hydraulic hose lines in the specified sequence.

6. Close the stop tap (1).
7. To depressurise the oil return flow T, open the stop tap (2) for 3 seconds.
8. Couple the oil return flow T.
9. Open the stop tap (1).
10. Couple the pressure line P and control line LS.
11. Couple the other supply lines.



12. Drive the tractor in reverse towards the implement so that the coupling device can be coupled.
13. Couple the coupling device.
14. Lift the jack into transport position.
15. Remove the wheel chocks, release the parking brake.



When taking a corner with the implement hooked up for the first time, please make sure that no attachment on the tractor collide with the implement.

## 8.2 Uncoupling the implement



### WARNING

**Danger of being crushed, cut, caught, drawn in or struck through insufficient stability and possible tilting of the uncoupled implement!**

Park the empty implement on a level parking surface with solid ground.



**Parking of a partially filled implement causes damage to the jack.**

Only park the implement when it is empty.



When uncoupling the implement, there must always be enough free space in front of the implement that the tractor can be aligned with the implement again during recoupling.

1. Place the empty implement on a level parking surface with solid ground.
2. Uncouple the implement from the tractor.
  - 2.1 Secure the implement against unintentionally rolling away. See page 130.
  - 2.1 Lower the jack into parking position.
  - 2.2 **Uncouple** the connection device.
  - 2.3 Drive the tractor approx. 25 cm forwards.
    - This will allow more room between tractor and implement and give better access for uncoupling the universal joint shaft and supply lines.
  - 2.4 Secure the tractor and implement against unintentional start-up and rolling.
  - 2.5 Uncouple the universal joint shaft.
  - 2.6 Place the universal joint shaft in the holder.
  - 2.7 Uncouple the supply lines and protect them against soiling with protective caps.
  - 2.8 Fasten the supply lines in their respective parking sockets.
  - 2.9 Hydraulic brake: Release the ripcord for the parking brake from the tractor.

### 8.2.1 Manoeuvring the uncoupled implement



#### DANGER

You must be particularly careful when manoeuvring with the service brake system released, since only the manoeuvring vehicle is now braking the trailed sprayer.

The implement must be connected to the manoeuvring vehicle before you actuate the release valve on the trailer brake valve.

The brakes on the manoeuvring vehicle must be applied.



The service brake system cannot be released using the release valve if the air pressure in the air reservoir drops below 3 bar (e.g. if the release valve has been actuated several times or if there are leaks in the brake system).

Release the service brake as follows:

- Fill the air reservoir.
- Completely vent the brake system using the drain valve on the air reservoir.

1. Connect the implement to the manoeuvring vehicle.
2. Apply the brakes on the manoeuvring vehicle.
3. Remove the wheel chocks and release the parking brake.
4. Only **pneumatic brake system**:
  - 4.1 Press in the actuator button on the release valve as far as it will go (see page 72).

→ This releases the service brake system so that the implement can be manoeuvred.

  - 4.2 When manoeuvring is finished, pull out the actuator button on the release valve as far as it will go.

→ The pressure from the air reservoir brakes the trailed sprayer again.
5. Actuate the brakes on the manoeuvring vehicle again once you have finished manoeuvring the implement.
6. Apply the parking brake again and secure the implement against rolling away with the wheel chocks.
7. Uncouple the implement from the manoeuvring vehicle.

## 9 Road transport



- During transportation, follow the instructions given in the section "Safety instructions for the operator", page 32.
- Before moving off, check:
  - the correct connection of the supply lines.
  - the lighting system for damage, proper operation and cleanliness,
  - the braking and hydraulic systems for obvious defects.
  - that the parking brake is completely released.
  - the function of the brake system.



### WARNING

**Risk of contusions, cutting, catching, drawing in and knocks when making interventions in the implement through unintentional implement movements.**

- On folding implements, check that the transport locks are locked correctly.
- Secure the implement against unintentional movements before starting transportation.



### WARNING

**Risk of crushing, cutting, being caught and/or drawn in, or impact from tipping and insufficient stability.**

- Drive in such a way that you always have full control over the tractor with the attached machine.  
In so doing, take your personal abilities into account, as well as the road, traffic, visibility and weather conditions, the driving characteristics of the tractor and the connected or coupled implement.



### WARNING

**Danger of breaking during operation, insufficient stability and insufficient tractor steering and braking power on improper use of the tractor!**

These risks pose serious injuries or death.

Comply with the maximum load of the connected implement and the approved axle and drawbar loads of the tractor. If necessary, drive only with a partially filled hopper.



**WARNING****Risk of falling when riding on the implement, contrary to instructions.**

It is forbidden to ride on the implement and/or climb the implement while it is running.

Instruct people to leave the loading site before approaching the implement.



**CAUTION**

- During transportation, follow the instructions given in the section "Safety instructions for the operator", page 32.
- It is forbidden to transport the implement with AutoTrail switched on.  
Put the steering axle into the transport position!
- It is forbidden to transport the implement when the tractor control unit is locked. During road transport, always set the tractor control unit on the tractor to neutral position.
- Move the sprayer boom to the transport position and secure mechanically.
- If a working width reduction of the outer elements is mounted, unfold it for transporting purposes.
- Use the transport locking mechanism to secure the swivelled-up induction bowl in transport position against unintentional swivelling down.
- Use the transport locking mechanism to lock the raised ladder against unintentional folding down.
- If a boom extension (option) is mounted, move it into the transport position
- Switch the work lights off during transport to avoid blinding other motorists.

## 10 TwinTerminal for Comfort Package on the control panel


The TwinTerminal can be used to perform various functions from the control panel of the implement. Among other things, the suction side multi-way valve can be electrically switched.

Standard screen of the TwinTerminal:

- 
 Display of the spray liquid tank fill level and agitation level
- 
 Display of the flushing water tank fill level.


4 buttons are available for operation.

When switching on the implement, per default the suction side is in position:


- 
 Suction from the spray liquid tank  
 → Spraying operation





Functions of the TwinTerminal:

- Filling via suction connection or pressure connection
- Suction from flushing water tank (cleaning and dilution)
- Adjusting the agitator
- Circulation cleaning
- XtremeClean high-pressure cleaning
- 
 The complete XtremeClean cleaning procedure can only be started through the ISOBUS control terminal)  
 On the TwinTerminal only for winterising
- Cleaning the pressure filter when the spray liquid tank is full.
- Running the pumps


## TwinTerminal diagram



## Buttons in the Main menu





 Select functions in the Main menu


 Start function


 Go to the start screen




## Buttons in the Setting menu



 Increase / reduce values


 Confirm entry


 Back



## 11 Use of the implement



When using the implement, observe the information in the following sections:

- "Warning symbols and other labels on the machine" starting on page 19 and
- "Safety information for the user", starting on page 30 ff.

Observing this information is important for your safety.



Observe the separate operating manual for the control terminal and the implement control software.



### WARNING

**Risk of injury due to accidental movement of the sprayer boom in automatic mode when entering the radiation area of the ultrasound sensor.**



Lock the sprayer boom

- Before leaving the tractor.
- If unauthorised persons are standing in the area of the sprayer boom.



### WARNING

**Danger of breaking during operation, insufficient stability and insufficient tractor steering and braking power on improper use of the tractor!**

Comply with the maximum load of the connected implement and the approved axle and drawbar loads of the tractor. If necessary, drive only with a partially filled hopper.



### WARNING

**Risk of contusions, cutting, catching, drawing in and knocks through insufficient stability and tipping of the tractor and/or the connected implement.**

Drive in such a way that you always have full control over the tractor with the mounted or trailed implement.

In so doing, take your personal abilities into account, as well as the road, traffic, visibility and weather conditions, the driving characteristics of the tractor and the connected or coupled implement.



### WARNING

**Danger of crushing, shearing, cutting, being caught or drawn in, winding and knocks through:**

- **unintentional lowering of raised, unsecured implement parts.**
- **unintentional start-up and rolling of the tractor-implement combination.**

Secure the tractor and the machine against unintentional start-up and rolling before eliminating faults on the machine. See page 130.

Wait for the implement to stop, before entering the implement danger area.



### WARNING

**There can be danger for the operator / third persons caused by flying damaged parts due to unauthorised high drive speeds of the tractor PTO shaft!**

Observe the permissible implement drive speed before switching on the tractor PTO shaft.



### WARNING

**Danger of being entangled and drawn in and danger from foreign objects being caught and thrown in the danger area of the driven PTO shaft!**

- Whenever the machine is used, first check to ensure that the safety devices and guards of the PTO shaft are fully intact and functional.  
Have damaged safety and protective devices for the universal joint shaft immediately replaced by a specialist workshop.
- Check that the universal joint shaft guard is secured against rotation by the supporting chain.
- Maintain a sufficient safety clearance between you and the driven universal joint shaft.
- Direct people out of the danger area of the driven universal joint shaft.
- Shut down the tractor engine immediately in case of danger.

**WARNING****Risk of accidental contact with crop protection agents / spray liquid!**

- Wear personal protective equipment,
  - when preparing the spray liquid.
  - when cleaning / replacing the spraying nozzles during spraying operation.
  - for all cleaning work carried out on the field sprayer after spraying operation.
- When wearing the required protective clothing, always observe the manufacturer's instructions, the product information, the instructions for use, the safety datasheet or the operating manual for the crop protection agent to be used. You must use e.g.:
  - Chemical-resistant gloves
  - Chemical-resistant overalls
  - Water-resistant footwear
  - Face mask
  - Breathing protection
  - Safety glasses
  - Skin protection agents, etc.

**WARNING****Health risks due to accidental contact with crop protection agents or spray liquid!**

- Put on protective gloves before
  - using crop protection agent,
  - carrying out work on a contaminated field sprayer or
  - cleaning the field sprayer.
- Wash the protective gloves with clear fresh water from the hand wash tank,
  - immediately after contact with crop protection agent.
  - before removing the gloves.

## 11.1 Preparing for spraying operation



- The field sprayer must be operating properly in order to guarantee correct application of the crop protection agent. Have the field sprayer tested regularly on a test rig. Rectify any deficiencies immediately.
- Observe the correct filter equipment.
- Clean the field sprayer thoroughly before applying a different crop protection agent.
- Flush the nozzle line before
  - each time changing a nozzle.
  - before rotating the multiple nozzle head to another nozzle.See the section on "Cleaning", page 188
- Fill the flushing water tank and the hand wash tank.



Ensure that you always carry enough clear fresh water when operating the field sprayer. Check and fill the fresh water tank when you fill the spray liquid tank.



## 11.2 Preparing the spray liquid



Prepare the spray liquid with the TwinTerminal on the control panel.



### WARNING

#### Risks due to accidental contact with crop protection agents and / or spray liquid!

- Always flush the crop protection agent into the spray liquid tank through the induction bowl.
- Swivel the induction bowl into the filling position before you fill the crop protection agent into the induction bowl.
- Observe the safety regulations on personal protective equipment in the instructions for use of the crop protection agent when handling crop protection agents and preparing the spray liquid.
- Do not prepare the spray liquid in the vicinity of wells or surface water.
- Avoid leaks and contamination with crop protection agent and/or spray liquid through appropriate conduct and wearing appropriate physical protection equipment.
- To avert risks to third parties, do not leave the prepared spray liquid, unused crop protection agent or used crop protection agent canisters and the uncleaned field sprayer unattended.
- Protect contaminated crop protection agent canisters and the contaminated field sprayer from precipitation.
- During and after preparation of the spray liquid, ensure sufficient cleanliness to keep risks as low as possible (e.g. thoroughly wash used gloves before removing them and properly dispose of the washing water and cleaning fluid).



- The prescribed water and agent rates can be found in the directions for use of the crop protection agent.
- Please carefully read the directions for use of the agent and observe the specified precautions!



### WARNING

#### **Danger for persons / animals due to accidental contact with spray liquid when filling the spray liquid tank!**

- Wear personal protective equipment when working with crop protection agents / draining spray liquid from the spray liquid tank. The required personal protective equipment depends on the information provided by the manufacturer, the product information, the instructions for use, the safety data sheet or the instruction manual for the crop protection agent to be used.
- Never leave the field sprayer unattended when filling it.
  - Never fill the spray liquid tank beyond the nominal volume.
  - Never exceed the permissible payload for the field sprayer when filling the spray liquid tank. Always pay attention to the respective specific weight of the liquid to be filled.
  - When filling, continuously watch the fill level indicator to prevent overfilling the spray liquid tank.
  - When filling the spray liquid tank on a paved surface, make sure that no spray liquid gets into the waste water system.
- Before filling, check the field sprayer for damage, such as leaky containers and hoses and make sure all the control elements are in the correct position.



While filling, pay attention to the permissible load capacity of your field sprayer. Always take the differing specific weights [kg/l] for the individual liquids into account while filling your field sprayer.

### Specific weights of different liquids

Liquid	Water	Urea	AUS	NP solution
Density [kg/l]	1	1.11	1.28	1.38



#### **TwinTerminal:**

Operations on the control panel are performed through the TwinTerminal.

#### **ISOBUS control terminal:**

Operations on the field are performed through the control terminal in the tractor.



- As it is difficult to dispose of residues in an environmentally-friendly manner, carefully calculate the required filling quantity or refill quantity to avoid leaving any residue at the end of the spraying operation.
  - To calculate the required refill quantity for the last filling of the spray liquid tank, use the "Filling table for remaining spray area". To do this, subtract the technical, undiluted residue in the sprayer boom from the calculated refill quantity!

Refer to the section "Filling table for remaining areas".

### Implementation

1. Determine the required water and agent application rate by consulting the directions for use of the crop protection agent.
2. Calculate the filling quantity or refill quantity for the area to be treated.
3. Fill the machine and blend in the agent.
4. Agitate the spray liquid before commencing spraying operations in accordance with the instructions of the spraying agent manufacturer.



Fill the machine preferably using a suction hose and blend in the agent while filling.

The induction area is thereby flushed with water constantly.



- During the filling process, start blending in the agent once the tank filling level has reached more than 20%.
- When using more than one agent:
  - Clean the canister immediately after each induction of an agent.
  - Rinse the induction bowl after each time an agent is flushed in.



- While filling, foam may not be allowed to escape from the spray liquid tank.

The addition of a froth-inhibiting agent also prevents the spray liquid tank from frothing over.



The agitators normally remain switched on from the initial filling to the end of the spraying operation. On this account, the instructions of the agent manufacturer are decisive.

## Use of the implement



- With the agitator running, add the water-soluble plastic bag directly into the spray liquid tank.
- Before spraying, fully dissolve the urea by circulating the liquid. When dissolving large quantities of urea, the temperature of the spray liquid drops more sharply; the urea consequently dissolves more slowly. The warmer the water, the faster and more completely the urea can dissolve.



- Carefully wash the empty agent canisters, render them unusable, collect and dispose of them in a proper manner. Do not re-use them for other purposes.
- If only spray liquid is available for washing the agent tanks, first use this to carry out preliminary cleaning. Then wash them thoroughly when clear fresh water is available, e.g. before preparing the next load for the spray liquid tank or when diluting the residue from the last load.
- Carefully wash out the empty agent canisters (e.g. using canister flushing) and add the flushing water to the spray liquid!



High degrees of water hardness above 15° dH (German degrees of hardness) can lead to lime deposits, which may impede the functioning of the implement and must be removed at regular intervals. See Maintenance section

### 11.2.1 Calculating the filling and re-fill quantity



To calculate the required refill quantity for the last filling of the spray liquid tank, use the "Filling table for remaining spray area", page 53.

#### Example 1:

##### The following are given:

Tank nominal volume	1000 l
Residue in the tank	0 l
Water consumption	400 l/ha
Agent required per ha	
Agent A	1.5 kg
Agent B	1.0 l

##### Question:

How many litres of water, how many kg of Agent A and how many litres of Agent B must be used to treat a surface of 2.5 ha in area?

##### Answer:

Water:	400 l/ha	x	2.5 ha	=	1000 l
Agent A	1.5 kg/ha	x	2.5 ha	=	3.75 kg
Agent B	1.0 l/ha	x	2.5 ha	=	2.5 l

#### Example 2:

##### The following are given:

Tank nominal volume	1000 l
Residue in the tank	200 l
Water consumption	500 l/ha
Recommended concentration	0.15 %

##### Question 1:

How many litres or kg of agent are needed to fill the tank?

##### Question 2:

How large is the area to be treated in ha if a residue of 20 l remains in the tank after spraying?

#### Formula and answer to Question 1:

$$\frac{\text{Refill amount of water [l]} \times \text{Concentration [\%]}}{100} = \text{Addition of agent [l or kg]}$$

$$\frac{(1000 - 200) \text{ [l]} \times 0.15 \text{ [\%]}}{100} = 1.2 \text{ [l or kg]}$$

## Use of the implement

### Formula and answer to Question 2:

$$\frac{\text{Available spray liquid quantity [l]} - \text{remaining quantity [l]}}{\text{Water consumption [l/ha]}} = \text{Area to be treated [ha]}$$

$$\frac{1000 \text{ [l]} (\text{tank nominal volume}) - 20 \text{ [l]} (\text{residue})}{500 \text{ [l/ha]} \text{ Water consumption}} = 1.96 \text{ [ha]}$$

### 11.2.2 Filling table for remaining spray area




To calculate the required refill quantity for the last filling of the spray liquid tank use the "Filling table for remaining spray area".



The specified re-fill quantities apply for a application rate of 100 l/ha. For other application rates, the re-fill quantity increases by a multiple.

Travel distance [m]	Working width [m]													
	15	16	18	20	21	24	27	28	30	32	33	36	39	40
	Refill quantity [l]													
10	2	2	2	2	2	2	3	3	3	3	3	4	4	4
20	3	3	4	4	4	5	5	6	6	6	7	7	8	8
30	5	5	5	6	6	7	8	8	9	10	10	11	11	12
40	6	7	7	8	8	10	11	11	12	13	13	14	15	16
50	8	8	9	10	11	12	14	14	15	16	17	18	19	20
60	9	10	11	12	13	14	16	17	18	19	20	22	23	24
70	11	11	13	14	15	17	19	20	21	22	23	25	27	28
80	12	13	14	16	17	19	22	22	24	26	26	29	30	32
90	14	15	16	18	19	22	24	25	27	29	30	32	34	36
100	15	16	18	20	21	24	27	28	30	32	33	36	38	40
200	30	32	36	40	42	48	54	56	60	64	66	72	74	80
300	45	48	54	60	63	72	81	84	90	96	99	108	114	120
400	60	64	72	80	84	96	108	112	120	128	132	144	152	160
500	75	80	90	100	105	120	135	140	150	160	165	180	190	200

### 11.2.3 TwinTerminal filling diagram



## 11.2.4 Filling the spray liquid tank and flushing water tank through the suction connection



Preferably perform the filling from a suitable container and not from an open water access point.

Follow regulations closely when filling the spray liquid tank from an open water access point using a suction hose.



To prevent pump damage during suction filling:

Ensure a continuous minimum diameter of the suction hoses / taps of 3 inches.



### WARNING

#### Contamination of the flushing water tank with spray agent when filling through the suction hose with the spraying pump.

You must observe the following safety measures:

- Before filling the flushing water tank with the spraying pump, the spray liquid tank must be filled with at least 500 l of water (cleaning the valve chest).
- Before filling the flushing water tank with the spraying pump, clean the implement thoroughly.
- The flushing water tank must be filled before filling of the spray liquid tank is finished. Otherwise, the flushing water tank will be contaminated.
- When filling the flushing water tank with the agitator switched on, the spray liquid tank will still be filled via the agitator

Procedure:

- Spray liquid tank partial filling 500 l
- Flushing water filling up to the target fill level (max. up to the nominal volume)
- Fill the rest of the spray liquid tank up to the target fill level and simultaneously
- Flush in the agents



### WARNING

#### Damage to crops and soils due to critical agents during suction filling of the flushing water tank:

- Clean the implement thoroughly beforehand.
- Suction filling is forbidden if contamination of the flushing water tank with critical agents is to be expected.
- It is better to fill the flushing water tank through the pressure connection.





### WARNING

**Forbidden contamination of the flushing water tank with crop protection agents or spray liquid!**

**Only fill the flushing water tank with clear fresh water, and never with crop protection product or spray liquid.**



### WARNING

**Damage to the suction valve chest caused by pressure filling via the suction connection!**

The suction connection is not suitable for pressure filling. This also applies for filling from a higher-elevation source.

1. Couple the suction hose with the suction connection and the water point.

2. Pressure valve chest **DA** in position


3. TwinTerminal:  
(see TwinTerminal diagram)

- 4.1 Drive the pump (at least 400 rpm)

- 3.2 Select suction filling

- 3.3 Enter the target fill level and confirm.



→ Suction valve chest **SA** moves into



→ The spray liquid tank must first be filled with at least 500 l to clean the valve chest)

4. Pressure valve chest **DA** in position


→ Filling of the flushing water tank starts.



### WARNING

**Contamination of the flushing water tank with spray liquid!**

Filling of the flushing water tank may never be interrupted using the Twin-

Terminal . Spray liquid is pumped into the flushing water tank.

## Use of the implement

5. Control terminal:  Switch off the agitator.

→ Otherwise, the spray liquid tank will continue to be filled via the agitator.

As soon as the flushing water tank is full (observe the fill level):

6. Pressure valve chest **DA**: Select position



→ Continue filling the spray liquid tank.

7. Control terminal: Switch the agitator back on.  
8. While filling, flush in the agents through the induction bowl.




To increase the filling capacity:



Switch tap **IJ** in position

9. Interrupt the filling process if flushing is not possible before the nominal fill level is reached.

→ Lock the pressure valve chest.



**Filling is automatically stopped when the target fill level has been reached.**

10. Uncouple the hose from the filling connection.



The hose is still filled with water.

11. Pressure valve chest **DA** in position



**WARNING**  
**Contamination of the flushing water tank with spray liquid!**

Filling of the flushing water tank must be finished before filling of the spray liquid tank is terminated by the automatic fill stop.

### 11.2.5 Filling the spray liquid tank and flushing water tank through the pressure connection



- The spray liquid tank and flushing water tank can be filled simultaneously.
- It is better to fill the flushing water tank through the pressure connection to prevent contamination of the flushing water tank with spray agent residues.



#### CAUTION

- Maximum permitted water pressure: 8 bar
- At a filling capacity greater than 1000 l/min, keep the lid of the spray liquid tank open during the filling procedure.

Otherwise, the spray liquid tank can be damaged.




#### CAUTION

**Implement damage, contamination of the flushing water tank and treatment damage on the field.**

Only use the pressure connection for water.

1. Couple the pressure hose with the pressure connection and the hydrant.

2. Select pressure filling  (see TwinTerminal diagram).

3. Filling the spray liquid tank

- 3.1 Select the spray liquid tank.

- 3.1 Enter the nominal fill level and confirm.

→ The spray liquid tank will be filled up to the target fill level.

4. Filling the flushing water tank


- 4.1 Select the flushing water tank.

- 4.2 Enter the target fill level and confirm.

→ The spray liquid tank will be filled up to the target fill level.

5. While filling, flush in the agents through the induction bowl.

6. After the filling process, close the supply-side stop tap, relieve the pressure hose, and uncouple the hose from the filling connection.




The hose is still filled with water.

## 11.2.6 Adjusting the agitator

Adjust the agitator before induction.

1. TwinTerminal: Select the agitator



2. Select the desired agitation level and confirm.



→ The agitation level will be displayed on the TwinTerminal.



## 11.2.7 Flushing agents via the induction bowl



### DANGER

Risk of injury due to contact with spray agents and spray liquid.

Wear personal protective equipment.

During the filling process, flush the agents into the spray liquid tank through the induction bowl.

#### During the suction filling:

- Pressure valve chest **DA** in position



- Switch tap **QU** in position



#### During the pressure filling:

- Suction valve chest **SA** in position



- Pressure valve chest **DA** in position



- Switch tap **QU** in position (overfilling of the spray liquid tank possible via the induction bowl. Also for fill stop and switch tap FS at **0**).



#### After filling:




- Suction valve chest **SA** in position



- Pressure valve chest **DA** in position




- Switch tap **QU** in position





## Use of the implement

Flush in the agents during the filling procedure.


1. Drive the pump (at least 400 rpm).
2. Lower the induction bowl.
3. Open the induction bowl cover.

4. Switch tap **EB** in position  for liquid agents.

Switch tap **EA** in position  for powder-form agents.

5. Pressure valve chest **DA** in position 



6. Injector switch tap **IJ** in position (adjustable suction intensity) 




7. Pour the quantity of agent calculated and measured for filling the tank into the induction bowl.

→ The contents of the induction bowl will be drawn out.

8. Close the cover of the induction bowl.
9. Close switch tap **EA / EB**.



To increase user protection, for example when handling powder agents, first pour the agent into the induction bowl (maximum 60 l), close the cover and only then apply suction.







Use clear, fresh water for flushing the canisters and cleaning the induction bowl.


Drawn water is automatically used during suction filling.

Otherwise, use flushing water.



→ TwinTerminal:  Select (Flushing water suction), see TwinTerminal diagram.

→ Suction valve chest **SA** moves into position .


### Flush the canister:

1. Switch tap **EB** in position .
2. Wash the canister or other containers using the canister flushing equipment. First position 1, then position 2.
3. Press the canister down for at least 30 secs.




→ The canister is rinsed with water.

 Pressure valve chest **DA** in position to increase the capacity of the canister rinsing. .



### Cleaning the induction bowl:


4. Switch tap **EA** in position .
5. Clean the surrounding area with the spray pistol.
6. Close switch tap **EA**.
7. Close the cover of the induction bowl.
8. Start the internal cleaning for the induction bowl using the button.
9. Close switch tap **EA**.
10. Switch off the injector switch tap **IJ** for suction from the induction bowl (0%).
11. Lift the induction bowl.

12. TwinTerminal:  Select (Spray liquid suction).







### 11.2.8 Spray agent suction from containers (closed transfer system)

1. Run the pump.
2. Couple the spray agent container with a drip-free plug coupling.
3. Couple the flushing connection.
4. TwinTerminal:  select (Spray liquid suction).  
Alternative: suction during the suction filling.
5. Pressure valve chest **DA** in position .
6. Start suction using switch tap **GA**, adjust the intensity (0-100%).
7. Stop the suction using switch tap **GA** when the desired quantity has been drawn from the container.



#### Cleaning contaminated components:

1. TwinTerminal:  select (Flushing water suction).
2. Start suction using switch tap **GA**, adjust the intensity (0-100%).
3. Pressure valve chest **DA** in position .
4. Pressure valve chest **DA** in position  to stop the cleaning.
5. Switch tap **GA** in position 0.





## 11.3 Spraying operation

### Special instructions for spraying operation



- Test the field sprayer by metering
  - before the start of the season.
  - in the case of deviations between the actual indicated spray pressure and the spray pressure prescribed in the spray table.
- Before starting spraying, determine the exact application rate required, referring to the instructions of the crop protection agent manufacturer.
- Before you start spraying, enter the required application rate (target rate) on control terminal.
- During spraying operation, precisely adhere to the required application rate [l/ha]
  - in order to achieve the best possible results from your crop protection measure.
  - to avoid unnecessary pollution of the environment.
- Select the required nozzle type from the spray table before spraying starts, taking account of
  - the intended forward speed,
  - the required application rate and
  - the required atomisation characteristic (fine, medium or coarse-dropped) of the crop protection agent used for the crop protection measure.

Refer to the section "Spray tables for flat-fan, anti-drift, injector and airmix nozzles", Seite 246.
- Select the required nozzle size from the spray table before spraying starts, taking account of
  - the intended forward speed,
  - the required application rate and
  - the target spray pressure.

Refer to the section "Spray tables for flat-fan, anti-drift, injector and airmix nozzles", Seite 246.
- Select a low forward speed and a low spray pressure to prevent drift losses!
 

Refer to the section "Spray tables for flat-fan, anti-drift, injector and airmix nozzles", Seite 246.
- At wind speeds of 3 m/s, take additional drift reduction measures (refer to the section "Measures for drift reduction")!



- Do not perform treatments if the average wind speed is higher than 5 m/s (leaves and thin twigs move).
- Only switch the sprayer boom on and off while driving to avoid the application of excessive doses.
- Avoid the application of excessive doses through overlapping caused by imprecise connection of the next bout from one spray path to the next and/or when cornering on the headlands with the sprayer boom switched on!
- When increasing the forward speed, make sure that the maximum permissible pump drive speed of 540 rpm is not exceeded!
- During spraying operation, constantly check actual spray liquid consumption with reference to the area treated.
- Calibrate the flow meter if there are any differences between the actual and displayed application rate.
- Calibrate the distance sensor (pulses per 100 m) if there are any differences between the actual and displayed travelled distance.
- If spraying operation is interrupted due to bad weather, be sure to clean the suction filter, the pump, the valve chest and the spray lines.



- The spray pressure and nozzle size influence drop size and the volume of liquid sprayed. The higher the spray pressure, the smaller the droplet diameter of the spray liquid. The smaller droplets are subject to increased, undesirable drifting.
- If the spray pressure is increased, the application rate also increases.
- If the spray pressure is decreased, the application rate also decreases.
- If the forward speed is increased while the nozzle size and spray pressure remain constant, the application rate decreases.
- If the forward speed is decreased while the nozzle size and spray pressure remain constant, the application rate increases.
- The forward speed and pump drive speed can be freely selected within a wide range thanks to the automatic area-related rate regulation.



- The pump delivery capacity is dependent on the pump drive speed. Select the pump speed (between 400 and 540 rpm) such that the flow rate to the sprayer boom and for the agitator is always sufficient. In doing so, be sure to consider that at higher forward speeds and higher application rates, more spray liquid must be conveyed.
- The agitator normally remains switched on from filling to the end of spraying operation. On this account, the instructions of the agent manufacturer are decisive.
- The spray liquid tank is empty when the spraying pressure suddenly drops considerably.
- Residual quantities in the spray liquid tank can still be properly applied up to a pressure drop of 25%.
- If the spray pressure drops off while conditions remain otherwise unaltered, the suction or pressure filter are blocked.

### Special instructions for boom load






The permitted boom load may not be exceeded, as it can cause damage to the boom.

For low-stress driving, please observe the following instructions:

- Reduce the forward speed significantly before the headlands and drive in the curve at a constant speed.
- Drive tight curves at slow speeds (below 6 km/h).
- Avoid jerky steering or changes in directions when steering (e.g. track correction).
- Do not fold the boom while driving.
- Always put the individual boom elements in the completely folded end position (folded or unfolded). Do not drive with a partially folded boom.
- Avoid rapid and abrupt changes in direction.

## 11.3.1 Applying the spray liquid



1. Prepare and stir the spray liquid correctly in accordance with the instructions from the crop protection product manufacturer.
  2. Pressure valve chest **DA** in position  

  3. Check: Suction valve chest **SA** in position  

  4. Switch on the control terminal and check the settings.
- Operate the field sprayer through the Work menu.
5. Unfold the sprayer boom.
  6. Switch on the boom guidance:




-  DistanceControl


-  ContourControl



Or actuate the boom manually:

-  Boom height,  tilt adjustment


7. Drive the pump at the pump operating speed.

 At low application rates, the pump speed can be reduced to save energy.

8.  Switch on spraying operation through the control terminal.



### Driving to the field with the agitator switched on

1. Switch on the pump drive.
2. Twin Terminal:  To prevent deposits: start circulation cleaning.



### 11.3.2 Drift reduction measures

- Reschedule treatment for the early morning or the evening hours (there is generally less wind).
- Choose larger nozzles and a higher water application rate.
- Reduce the spray pressure.
- Precisely maintain the working height of the boom, because the risk of drifting rises very sharply as the distance between the nozzles increases.
- Reduce forward speed (to less than 8 km/h).
- Use so-called anti-drift (AD) nozzles or injector (ID) nozzles (nozzles which produce a high proportion of coarse drops).
- Observe the distance requirements of the respective crop protection agent

### 11.3.3 Diluting the spray liquid with flushing water

1. Run the pump.

Control terminal, Cleaning menu:

2.  Dilute the spray liquid with flushing water.
3.  End dilution.



Observe the display for the required quantity of flushing water.



The spray agent can be diluted for 2 reasons:

- To get rid of excess residual quantities.  
Excess residual quantities in the spray liquid tank are initially diluted with 10 times the quantity of flushing water to then spray them out on the field that has already been treated.
- Increasing the spray liquid volume to treat a remaining area.



The spray line is flushed on machines with nozzle control. When re-starting the spraying, two to five minutes will elapse until concentrated spray liquid can be applied.

### 11.3.4 Residual amounts

There are three types of residue:

- Excess residue remaining in the spray liquid tank when the spraying operation is finished.
- This excessive residue is discharged diluted or pumped-out and disposed of.
- Technical residue that remains in the spray liquid tank, the suction valve chest and the spray line when the spray pressure drops by 25%.
- The suction chest is composed of the suction filter, pump and pressure controller sub-assemblies. Observe the values for the technical residues given on page 108.
- This technical residue is discharged diluted onto the field while cleaning the field sprayer.
- Final residue that remains in the spray liquid tank, the suction valve chest and the spray line after being cleaned and air is discharged from the nozzles.
- This final diluted residue is drained off after cleaning.

### Disposing of the residues



- Make sure that the residue in the spray line continues to be sprayed in an undiluted concentration. Always spray this residue on an untreated area. The distance needed to use up this undiluted residue can be found in the section "Technical Data - spray lines", page 108. The residue contained in the spray line is dependent on the sprayer boom working width.
- To spray out the spray liquid tank until it is empty, switch off the agitator when the residue in the spray liquid tank is only 5% of the nominal volume. When the agitator is switched on, the technical residue is higher than the specified values.
- **Measures intended for the user's protection apply when emptying residues. Observe the instructions of the crop protection product manufacturer and wear suitable personal protective equipment.**

Formula for calculating the required distance in [m] for spraying out the undiluted residue in the spray line:

$$\text{Required distance [m]} = \frac{\text{Undilutable residue [l]} \times 10,000 \text{ [m}^2\text{/ha]}}{\text{Application rate [l/ha]} \times \text{working width [m]}}$$




### 11.3.5 Diluting the excess residue in the spray liquid tank and spraying out the diluted residue remaining at the end of spraying operations


1. Switch off sprayers on the control terminal.
2. Drive the pump with pump operating speed.
3. Dilute the residual quantity with 10 times the amount of flushing water.
4. Switch of the agitators.
5. Switch on sprayers on the control terminal.
- If possible, first spray out the undiluted spray liquid from the spray line on an untreated remaining area.
- Spray out the diluted residual quantity on the treated area.
- Keep flushing the diluted residues until air escapes from the nozzles.
6. Switch off sprayers on the control terminal.
7. Cleaning the field sprayer.



When spreading residue, observe the maximum permissible application quantity of the agent on areas already treated.

### 11.3.6 Emptying the spray liquid tank using the pump


1. Couple a suitable emptying hose from the external tank to the implement-side emptying connection.
2. TwinTerminal:  select (Spray liquid suction).
3. Pressure valve chest **DA** in position .
4. Run the pump.  
→ Emptying procedure starts.
5. After emptying, pressure valve chest **DA** in position .
6. Interrupt the pump drive.
7. Uncouple the hose.



The hose is still filled with spray liquid.



The stop tap DE (drain pressure filter) must be in Position 0.



## 12 Cleaning the implement after operation



- Keep the exposure time as short as possible, for example by daily cleaning of the utensils after the spraying operation is completed. Do not leave the spray liquid in the spray liquid tank for an unnecessarily long period, e.g. overnight.

The service life and reliability of the field sprayer mainly depend on how long the materials of the field sprayer are exposed to the crop protection agent.

- Clean the field sprayer thoroughly before applying a different crop protection agent.
  - Carry out the cleaning process on the field where you last carried out the treatment.
  - Carry out the cleaning procedure using water from the flushing water tank.
  - You can carry out the cleaning process in the courtyard if you have a collecting facility installed (e.g. a Biobed).
- Observe all national regulations involved.
- When spreading residual quantities on treated areas, observe the maximum permissible application rate for the agents.




- Perform a quick cleaning daily.
- Perform an intensive cleaning:
  - before a critical agent change,
  - before taking out of operation for a longer period.
- Perform the cleaning on the field while driving, since cleaning water is applied intermittently.
- The fill level of the flushing water tank must be sufficient.
- Prerequisite: tank fill level < 1 % (tank as empty as possible).



## 12.1 Quick cleaning of the empty field sprayer

1. Run the pump.
2. Check the pressure valve chest: Position



Control terminal, Cleaning menu:



3. The conditions must be fulfilled. Compare the setpoints and actual values.

QUICK CLEANING			
The following conditions must be fulfilled:			
✗	Maximalfüllstand Spritzflüssigkeitstank :	2303	l
		42	l
✗	Mindest-Füllstand Spülwassertank :	0	l
		450	l
✓	Gestänge ausgeklappt		
✗	Drehzahl Spritzflüssigkeitspumpe :	123	1/min
		> 500	1/min

4. > Start the quick cleaning.
5. Enter the desired quantity of flushing water for cleaning (minimum 200 litres, maximum 580 litres)

→ Main and secondary agitator are flushed, tank internal cleaning switched on.


Implements with DUS: the spray line is cleaned.


6. > Confirm and start driving at the same time.

→ Cleaning water is sprayed out.

Spraying is switched on and off several times.

AmaSelect: The nozzle body is completely flushed.



 If necessary, also switch the boundary nozzles.

7. > Residue will be drained.  
✗ Do not drain residue (residue will be drained and collected later).
8. Clean the suction filter and pressure filter, see section on cleaning the suction filter / pressure filter.

## 12.2 Intensive cleaning of the empty field sprayer

1. Run the pump.

Control terminal, Cleaning menu:



2. The conditions must be fulfilled. Compare the setpoints and actual values.

INTENSIVE CLEANING			
The following conditions must be fulfilled:			
✗	Maximalfüllstand Spritzflüssigkeitstank:	2303	l
		42	l
✗	Mindest-Füllstand Spülwassertank:	0	l
		450	l
✓	Gestänge ausgeklappt		
✗	Drehzahl Spritzflüssigkeitspumpe:	123	1/min
		> 500	1/min

3. > Start the intensive cleaning.

4. Enter the desired quantity of flushing water for cleaning (minimum 400 litres, maximum 580 litres)

→ Main and secondary agitator are flushed, tank internal cleaning switched on.


Implements with DUS: the spray line is cleaned.

5. > Confirm and start driving at the same time

→ Cleaning water is sprayed out.

Spraying is switched on and off several times.

AmaSelect: The nozzle body is completely flushed.



**i** If necessary, also switch the boundary nozzles.

6. > Residue will be drained.  
✗ Do not drain residue (residue will be drained and collected later).

**!** During the intensive cleaning:

- Spraying out the cleaning water three times while driving on the field.
- Draining the residue two times.

**!** The intensive cleaning procedure takes up to 15 minutes.

7. Drain the final residual quantity.
8. Clean the suction filter and pressure filter.
9. If necessary, clean the nozzle filter and line filter in the boom.

### 12.3 Draining the final residues




- On the field: Spread the final residues over the field.
- At the farm:
  - Place a suitable collecting container under the drain opening of the suction chest and the drain hose for the pressure filter and collect the final residues.
  - Dispose of the collected spray liquid residual quantity in accordance with the corresponding legal guidelines.
  - Collect the spray liquid residual quantities in suitable tanks.

1. Place a suitable collecting container under the outlet opening on the suction side.

2. TwinTerminal:  select (Spray liquid suction).

3. Open the stop tap **EW** under the implement.
- Drain the residual quantity.
4. Close the stop tap again.



## 12.4 XtremeClean high-pressure cleaning

- Execute XtremeClean via the ISOBUS control terminal.
- XtremeClean is high-pressure cleaning of the spray liquid tank.
- XtremeClean serves to loosen deposits on the tank interior wall and must be used particularly before a critical agent change.
- Execute XtremeClean after intensive cleaning.
- Perform XtremeClean on the farmyard.
- During the procedure, the cleaning water must be applied in several steps.




Duration of the entire procedure: 25 minutes

Duration of high-pressure cleaning of the spray liquid tank: at least 15 minutes / until it is stopped manually.

Water consumption: 560 litres

1. Run the pump.
2. Control terminal: Select XtremeClean.




3. > Start cleaning when the conditions are fulfilled.


The following conditions must be fulfilled:

- ☒ Maximum fill level of the spray liquid tank is lower than 1%
- ☒ Minimum fill level of the spray liquid tank
- ☒ Boom is unfolded
- ☒ Spray liquid pump speed > 500 rpm

The cleaning steps are shown in the diagram!



4. Apply the cleaning water in an environmentally friendly manner.
- Cleaning phase 1
5. Apply the cleaning water in an environmentally friendly manner.
  - ✓ Start application
- Cleaning phase 2
6. Flush in cleaning agent if necessary, see page 169
7. High-pressure cleaning starts.
  - ✓ Stop high-pressure cleaning.  
The high-pressure cleaning takes at least 15 minutes.
  - ✗ Abort the high-pressure cleaning prematurely, the spray liquid tank is filled with cleaning water.
8. Apply the cleaning water in an environmentally friendly manner.
  - ✓ Start application.
- Cleaning phase 3
9. Apply the cleaning water in an environmentally friendly manner.
  - ✓ Start application.
10. ✓ Cleaning is complete.



## 12.5 Performing chemical cleaning



- Chemical cleaning is recommended before critical agent changes and before the implement is decommissioned for a longer period of time.
- Perform the chemical cleaning after the intensive cleaning.

1. Clean the implement.
2. Fill the spray liquid tank with 100 l of water and add the cleaning agent according to the instructions provided by the manufacturer.



To flush in the cleaning agent, the spray liquid tank must be filled with at least 200 l of water.

3. Run the pump.
4. Pressure valve chest **DA** in position



5. TwinTerminal:




Switch on the circulation cleaning (at least 10 minutes, observe the instructions from the cleaning agent manufacturer).

6. TwinTerminal: Select agitator and operate at maximum intensity for one minute.



stop the circulation cleaning.

7. Spray out the mixture on the previously treated field.



### List of available cleaning agents

Product	Manufacturer
Agro-Quick	Adama
JET CLEAR	Sudau agro
Proagro Spritzenreiniger	proagro GmbH

## 12.6 Cleaning the suction filter and pressure filter




- Clean the suction filter on a daily basis after cleaning the field sprayer.
- Grease the O-rings.  
Make sure that the O-ring seals are correctly fitted.
- Ensure that there are no leaks after installation
- HighFlow: Also clean the separate HighFlow pressure filter

### Cleaning the suction filter when tank is full

1. Run the pumps.
2. Attach the sealing cap to the suction coupling.

3. TwinTerminal:  Select suction filling.

→ Enter a target quantity that is increased by at least 200 litres.


4. Pressure valve chest **DA** in position .
5. Bleed the suction filter through the venting valve (20 seconds).

→ The contents of the filter cup are sucked out.


6. Remove the suction filter, clean and re-install.
7. Interrupt the pump drive.



The injector is contaminated with spray liquid.



- (1) Suction filter
- (2) Venting valve



## Cleaning the pressure filter when the spray liquid tank is full



**WARNING**  
Unwanted emptying of the spray liquid tank via quick emptying!

Never run the pump.





HighFlow: Do not clean the separate HighFlow pressure filter when the spray liquid tank is full.





Single nozzle control:  
Close the return flow stop tap on the sprayer boom (Position 0).

1. TwinTerminal: Select the pressure filter





2.   Switch off the pump and confirm.


3. Pressure valve chest **DA**: block the liquid circulation.



4. Place a collecting bucket under the outlet.
5. Drain the filter using the stop tap **DE**.
6. Undo the union nut.

7.   Remove the pressure filter, confirm.

8.   Reinstall the cleaned pressure filter, confirm.





## 12.7 Flushing the sprayer boom when the spray liquid tank is full


### (work interruption )

1. Control terminal: Flush the boom while driving on the field.
  - ✓ Mark the application of spray liquid.

> Start flushing the boom.

X Stop flushing the boom.

2. TwinTerminal: Clean the suction filter, see section on cleaning the suction filter.
3. Interrupt the pump drive.



Without nozzle control:

Flush the boom and apply at least 50 litres of flushing water while driving on an untreated area.


With nozzle control:

Only flush the boom with 50 litres of water, and then flush the nozzles and apply the flushing water on an untreated area.






The spray liquid tank and agitators are not cleaned!



### Continuing the spraying operation

1. Run the pump.
2. Control terminal:  switch on maximum agitation for at least 5 minutes.



## 12.8 External cleaning

1. Unfold and lower the boom.
2. Run the pumps.
3. TwinTerminal:  (suction from flushing water tank).
4. If internal cleaning was not previously performed:  
Switch tap **DA** in position  for 30 seconds until flushing water is available.
5. Pressure valve chest **DA** in Position .
6. Clean the field sprayer and the sprayer boom with the spray gun.
7. Afterwards, put the control elements back to their initial position.



## 13 Faults



### WARNING

**Danger of crushing, shearing, cutting, being caught or drawn in, winding and knocks through:**

- **unintentional falling of the implement raised using the tractor's three-point hydraulic system.**
- **unintentional lowering of raised, unsecured implement parts.**
- **unintentional start-up and rolling of the tractor-implement combination.**

Secure the tractor and the machine against unintentional start-up and rolling before eliminating faults on the machine. See page 130.


Wait for the implement to stop, before entering the implement danger area.

<b>Malfunction</b>	<b>Cause</b>	<b>Remedy</b>
<b>Liquid does not emerge from the nozzles.</b>	The nozzles are clogged.	Eliminate the blockage, see page 229.
<b>Boom is too low in transport position</b>	Boom has been lowered	Lift the boom and move into transport position, see 185.
<b>AmaSelect: Nozzles do not close completely</b>	Limescale in the nozzle body	Eliminate limescale in the system, refer to the Maintenance section
<b>There is no suction from the pump</b>	Blockage on the suction side (suction filter, filter insert, suction hose).	Remove the blockage.
	Pump is sucking in air.	Check the hose connection of the suction hose (optional) on the suction port for leak tightness.
<b>The pump does not have any power</b>	Suction filter and filter insert dirty.	Clean suction filter and filter insert.
	The valves are jammed or damaged.	Change the valves.
	The pump draws air, can be seen by air bubbles in the spray liquid tank.	Check the hose connections on the suction hose for leak tightness.
<b>The spray cone vibrates</b>	Irregular delivery flow from the pump.	Check, and if necessary replace, the suction and pressure-side valves (see Seite 222).
<b>Oil/spray liquid mixture in the oil filler neck or clearly visible oil consumption</b>	Pump diaphragm defective.	Change all six piston diaphragms (see 223).
<b>The required application rate entered is not achieved</b>	High forward speed; low pump drive speed;	Reduce the operational speed and increase the pump drive speed until the fault message disappears and the audible alarm signal stops
<b>There has been a deviation from the permissible spray pressure range for the nozzle fitted to the sprayer boom</b>	Deviation from the prescribed operational speed, which has an effect on the spray pressure	Alter your operational speed to return to the prescribed operational speed range set for spraying operation
<b>In some cases, liquid does not come out of the nozzles when spraying out during the cleaning procedure.</b>	The spray liquid tank was emptied too much the last time it was sprayed out, so that it now contains no or too little cleaning water.	Reduce the forward speed and/or the target application rate to ensure controlled spraying out during the cleaning procedure.

### Emergency actuation of the suction tap in case of motor failure

In case of suction top motor failure, the suction tap can be switched manually.

Before doing so, release the motor from the actuation lever.




### 13.1 Boom too low in transport position


If the boom continues to lower from the transport position, the boom suspension is not active.

F15222

Boom is too low in transport position

1. Stop the tractor and implement.

2.  Lift the boom.

3.  Lower the boom into transport position.

## 14 Cleaning, maintenance and repairs



### WARNING

**Danger of crushing, shearing, cutting, being caught or drawn in, winding and knocks through:**

- unintentional falling of the implement raised using the tractor's three-point hydraulic system.
- unintentional lowering of raised, unsecured implement parts.
- unintentional start-up and rolling of the tractor-implement combination.

Secure the tractor and implement against unintentional starting and unintentional rolling away before you perform any cleaning, servicing or maintenance work on the implement. See page 130.



### WARNING

**Risk of crushing, shearing, cutting, being caught and/or drawn in, or impact through unprotected danger points.**

- Mount protective equipment, which you removed when cleaning, maintaining and repairing the implement.
- Replace defective protective equipment with new equipment.



### DANGER

- When carrying out maintenance and repair, observe the safety instructions, particularly "Field sprayer operation" section, Seite 38.
- You may only carry out maintenance or repair work under moving machine parts that are in a raised position if such parts are secured with suitable, positive-fit locking devices against accidental lowering.

### Before each start-up

1. Check the hoses/tubes and connecting pieces for visible defects/leaky connections.
2. Repair any areas of chafing on hoses and tubes.
3. Replace any worn or damaged hose and tubes immediately.
4. Fix leaky connections immediately.



- Regular and proper maintenance will keep your trailed sprayer in good condition for a long time, and will prevent early signs of wear. Regular and proper maintenance is a requirement of our warranty conditions.
- Use only genuine AMAZONE spare parts (see "Spare and wear parts and aids" section, page 18).
- Use only genuine AMAZONE replacement hoses, and hose clamps made of V2A for assembly.
- Specialist knowledge is the requirement for carrying out testing and maintenance operations. This specialist knowledge is not given here in this operating manual.
- Observe environmental protection measures when carrying out cleaning and maintenance work.
- Observe legal requirements when disposing of lubricants, e.g. oils and grease. Also affected by these legal requirements are parts that come into contact with these lubricants.
- Do not exceed a greasing pressure of 400 bar when greasing with high pressure grease guns.
- The following are prohibited
  - drilling the running gear.
  - drilling through pre-existing holes on the transport frame.
  - welding on load-bearing components.
- Protective measures are necessary, such as covering lines or removing lines in particularly critical locations
  - during welding, drilling and grinding work.
  - when working with cutting discs near plastic lines and electric lines.
- Clean the field sprayer thoroughly with water before carrying out repair work.
- Always carry out repair work on the field sprayer with the pump switched off.
- Repair work can only be performed inside the spray liquid tank when it has been thoroughly cleaned! Do not climb into the spray liquid tank!
- Always disconnect the implement cable as well as the power supply from the on-board computer when performing any maintenance and repair work. This applies particularly to welding work on the implement.

## 14.1 Cleaning



- Pay particular attention to the brake, air and hydraulic hose lines
- Never treat hose lines with petrol, benzene, petroleum or mineral oils. This applies for
  - Brake, air, and hydraulic hoses
  - Spray liquid, seed, fertiliser, and water hoses
- After cleaning, grease the field sprayer, in particular after cleaning with a high pressure cleaner/steam jet or liposoluble agents.
- Observe the legal regulations for handing and disposing of cleaning agents.

### Cleaning with a high pressure cleaner/steam jet



- Always observe the following points when using a pressure washer/steam jet for cleaning:
  - Do not clean any electrical components.
  - Do not clean any chrome-plated components.
  - Never aim the cleaning jet of the cleaning nozzle of the high pressure cleaner/steam jet directly at lubrication points, bearings, rating plates, warning signs, and stickers.
  - Always maintain a minimum nozzle distance of 300 mm between the high pressure or steam jet cleaning nozzle and the implement.
  - The set pressure of the high-pressure cleaner/steam jet must not exceed 120 bar.
  - Comply with safety regulations when working with pressure washers.



## 14.2 Winter storage and long periods out of operation



For winter storage, the remaining water / spray liquid is diluted in the entire liquid circuit with a sufficient amount of antifreeze to prevent frost damage.

80 l of antifreeze are required.


AMAZONE recommends wintering with a propylene glycol-based antifreeze (e.g. Glysofor L).

Liquid fertiliser is not suitable as frost protection and can damage the implement.

1. Clean the implement and empty it completely.
2. Drain the flushing water tank through the hose connection at the bottom of the tank, and reinstall correctly later on.
3. Start the spraying pump.

### Drawing antifreeze into the flushing water tank:

Alternative: fill in the antifreeze directly through the tank opening of the flushing water tank

4. Switch tap **QU** in position 
5. Connect the suction hose to the suction connection.


6. Pressure valve chest **DA** in position 


7. TwinTerminal:  fill the flushing water tank.


### Pumping antifreeze into the spray liquid tank:

8. TwinTerminal:  suction from flushing water tank.

9. When filling through the tank opening of the flushing water tank: pressure valve chest

**DA** in position  (10 seconds).

10. Pressure valve chest **DA** in position .






## Distributing the antifreeze:

11. TwinTerminal:  suction from the spray liquid tank.

12. Recirculate antifreeze in the entire liquid circuit.


To do so, put the pressure tap **DA** in the following position:

-  internal cleaning (30 seconds)
-  spray the external cleaning into the induction bowl (10 seconds).
-  and change positions on switch tap **IJ**.

Then switch tap **IJ** in position .


Switch tap **QU** in position .

Change the positions of switch taps **EA**, **EB** on the induction bowl, actuate the corresponding functions for 10 seconds and evacuate the content.

-  and switch the agitator on and off at maximum.
- DUS: allow the antifreeze to circulate (one minute).

13. TwinTerminal:  activate the circulation cleaning.

14. Implement with HighFlow: activate the HighFlow. To do so, increase the application rate.



### Applying the antifreeze through the nozzles:

15. Unfold the boom.

16. TwinTerminal:  select (Spray liquid suction).

17. Switch on spraying until the antifreeze emerges from the nozzles.

- Part-width section control: Switch on and off several times
- AmaSelect: switch through all of the nozzle positions

18. Switch the boundary nozzles / edge nozzles.



Collect the sprayed liquid!



Check the sprayed liquid for sufficient frost protection! If necessary, add more antifreeze and repeat the procedure.

19. TwinTerminal:  Select (Xtreme-Clean) (one minute).

### Pumping out the antifreeze:

20. Empty the spray liquid tank using the pump.



Pressure valve chest **DA** in Position  .

→ Pump the antifreeze and spray liquid mixture into a suitable tank, re-use or dispose of properly.


21. Drain the suction filter insert and pressure filter insert.

### General information:

22. Implement with HighFlow: drain the HighFlow:

switch tap under the Highflow pressure filter




in position  and allow the spray line to run completely empty.


Remove the HighFlow pressure filter and clean it.

23. Remove the hose from the pressure sensor to drain the pressure sensor.


Super-L boom pressure sensor on the boom valve chest



Agitator pressure sensor on the control panel



24. Empty the water remaining in the line filter drain with the drain tap.



25. Drain the hand wash facility and leave the tap open.
26. Lubricate the cardan joints of the universal joint shaft and grease the profile tubes for longer periods out of operation.
27. Store the pressure gauge and any other electronic accessories in a place where they are safe from frost!
28. Perform an oil change on the pumps before recommissioning.

### 14.3 Lubrication specifications




Grease all lubricating nipples (keep seals clean).

Lubricate / grease the implement at the specified intervals.

Lubrication points on the machine are indicated with a sticker.

Carefully clean the lubrication points and grease gun before lubrication so that no dirt is pressed into the bearings. Press the dirty grease completely out of the bearings and replace with new grease!




#### Lubricants





For lubrication work use a lithium saponified multipurpose grease with EP additives:


Company	Lubricant designation
ARAL	Aralub HL 2
FINA	Marson L2
ESSO	Beacon 2
SHELL	Retinax A



### 14.3.1 Lubrication point overview



	Lubrication point	Interval [h]	Number of lubrication points	Type of lubrication
				
1	Hydraulic cylinder for jack	100	2	Grease nipple
2	Drawbar bearing	50	2	Grease nipple
3	Parking brake	100	1	Grease the rope and pulleys. Grease the spindle via the grease nipple.
4	Drawbar eye	50	1	Grease




				
1	Lifting cylinder	100	4	Grease nipple

				
1	Hydraulic cylinder for the hydro-pneumatic Suspension	100	4	Grease nipple

	Lubrication point	Interval [h]	Number of lubrication points	Type of lubrication
				
	Universal joint shaft		5	Grease nipple

				
				
1	Steering pin bearing, top and bottom	40		Grease nipple
2	Steering cylinder heads on steering axles	200		Grease nipple
3	Brake shaft bearing, outer and inner	200		Grease nipple
4	Slack adjuster	1000		Grease nipple
5	Automatic boom positioner ECO-Master	1000		Grease nipple
6	Replace grease on wheel hub bearing, check taper roller bearing for wear	1000		Grease nipple

				
	Outer boom locking Super S, Super L1, Super L2	100	2	Grease nipple
				
	Super L3	100	2	Grease nipple

C	Lubrication point	Interval [h]	Number of lubrication points	Type of lubrication
				
	ContourControl	100	2	Grease nipple
				
1-3	Super L3 / Flex 2 / > 38 m	100	16	Grease nipple
				
1		250	2	Grease nipple



- For winter operation, grease the protective tubes to prevent them from freezing.
- Also observe the installation and service instructions from the universal joint shaft manufacturer, which are fastened to the universal joint shaft.

### Steering cylinder heads on steering axles

In addition to this lubrication work, it must be ensured that the steering cylinders and the supply line are always vented.

### Brake shaft bearing, outer and inner

Caution! Grease and oil must not get into the brake. Depending on the series, the cam bearing for the brakes is not sealed.

Use only lithium saponified grease with a drop point above 190° C.



### Automatic boom positioner ECO-Master

Each time the brake linings are changed:

1. Remove the rubber sealing cap.
2. Lubricate (80g) until sufficient fresh grease emerges at the adjusting screw.
3. Turn the adjusting screw approx. one turn back with a ring spanner. Actuate the brake lever several times by hand.
4. In doing so, the automatic readjustment must take place smoothly. Repeat several times if necessary.
5. Put on the sealing cap. Grease again.

### Renew the wheel bearing grease

1. Jack up the vehicle safely and release the brakes.
2. Remove the wheels and dust caps.
3. Remove the cotter pin and unscrew the axle nut.
4. Use a suitable puller tool to pull off the wheel hub with brake drum, tapered roller bearing and sealing elements from the stub axle.
5. Label removed wheel hubs and bearing cages, so that they are not mixed up when installed.
6. Clean the brake, check it for wear, make sure it is intact and functions and replace worn parts.  
The inside of the brake must be kept free of lubrication and impurities.
7. Thoroughly clean the inside and outside of the wheel hubs. Remove old grease completely. Thoroughly clean bearings and seals (diesel oil) and check for reusability.  
Before installing the bearings, lightly grease the bearing seats and install all parts in the reverse order. Carefully drive parts on to press fits with tube bushings without jamming or damaging them.  
Grease the bearings, the wheel hub cavity between the bearings and the dust cap before installing them. The grease quantity should fill approx. a quarter to a third of the space in the installed hub.
8. Install the axle nut and adjust the bearings and brakes. Then perform a functional check and an appropriate test run, and eliminate any observed faults.



To lubricate the wheel hub bearing, use only BPW Special long-life grease with a drop point above 190°C.

Using the wrong grease or too much grease can cause damage.

Mixing lithium-saponified grease with sodium-saponified grease can result in damage caused by incompatibility.

## 14.4 Maintenance schedule – overview



- Execute maintenance tasks after the first scheduled maintenance period has been reached.
- The times, running hours or maintenance intervals of any third party documentation shall have priority.

### After the first working run

Component	Servicing work	see page	Workshop work
<b>Wheels</b>	• Check the wheel nuts	210	
<b>Trailer hitch</b>	• Check the bolts for tight fit	213	
<b>Hydraulic system</b>	• Check leak tightness	214	
<b>Spraying pump</b>	• Check the oil level	219	

### Daily

Component	Servicing work	see page	Workshop work
<b>Whole implement</b>	• Check for visible defects		
<b>Oil filter (for Profi-folding)</b>	• Check the contamination indicator	217	
	Replace if necessary		X
<b>Spraying pump</b>	• Clean, flush	219	
<b>Spray liquid tank</b>		172	
<b>Line filters in the nozzle lines (if equipped)</b>		230	
<b>Spraying nozzles</b>		227	
<b>Brake</b>	• Draining the air reservoir	204	
<b>Spraying pump</b>	• Check the oil level • Check the oil (the oil must not be cloudy)	219	

### Weekly / 50 operating hours

Component	Servicing work	see page	Workshop work
<b>Hydraulic system</b>	• Check leak tightness	214	X
<b>Wheels</b>	• Check the tyre inflation pressure • Check the tyres for firm seating • Check for damage	210	
<b>Coupling device</b>	• Check for damage, deformation and cracks	212	

## Every three months / 200 operating hours

Component	Servicing work	see page	Workshop work
<b>Brake</b>	<ul style="list-style-type: none"> <li>• Check for leaks</li> <li>• Check the pressure in the air reservoir</li> <li>• Check the brake cylinder pressure</li> <li>• Visual inspection of the brake cylinder</li> <li>• Joints on brake valves, brake cylinders and brake linkages</li> </ul>	207	<b>X</b>
	<ul style="list-style-type: none"> <li>• Brake adjustments on the slack adjuster</li> </ul>	203	<b>X</b>
	<ul style="list-style-type: none"> <li>• Brake pad check</li> </ul>		
	<ul style="list-style-type: none"> <li>• Automatic load-dependent braking force regulator (ALB)</li> </ul>	208	<b>X</b>
<b>Wheels</b>	<ul style="list-style-type: none"> <li>• Check the bearing clearance on the wheel hubs</li> </ul>	202	<b>X</b>
<b>Line filter</b>	<ul style="list-style-type: none"> <li>• Clean</li> <li>• Replace damaged filter inserts</li> </ul>	230	
<b>Hydropneumatic sprung suspension</b>	<ul style="list-style-type: none"> <li>• Check the bolts for tight fit.</li> </ul>	213	
<b>Parking brake</b>	<ul style="list-style-type: none"> <li>• Check the braking effect when the parking brake is applied</li> </ul>	209	
<b>Booms</b>	<ul style="list-style-type: none"> <li>• Check the boom sections for cracks or initial crack formation</li> </ul>		
<b>Coupling device</b>	<ul style="list-style-type: none"> <li>• Check the fastening bolts for wear and tight fit</li> </ul>	212	

Annually / 1000 operating hours

Component	Servicing work	see page	Workshop work
Spraying pump	• Oil change	221	X
	• Check valves, replace as necessary	221	X
	• Check the piston diaphragm and replace if necessary	221	X
Flow meter and return flow meter	• Calibrate flow meters • Calibrate the return flow meter	224	
Nozzles	• Meter the field sprayer and check the lateral distribution; if necessary, replace worn nozzles	227	
Brake drum	• Check for soiling	202	X
Wheels	• Check the wheel nuts	210	
Brake	Automatic slack adjuster: • Functional check • Brake settings	203	X
Pneumatic brake	• Clean the compressed air line filter on the coupling head	205	X
	• Clean the compressed air line filter in the brake line	205	X

As required

Component	Servicing work	see page	Workshop work
Super-L boom	• Correct the settings	217	X
Hydraulic throttle valves	• Adjust the actuation speed	217	
Hydraulic brakes	• Check all brake hoses for wear • check all screw unions for seal tightness • renew any worn or damaged parts.	208	
Spray liquid circuit and nozzles	• Eliminate scale deposits	225	
Electro hydraulic boom	• Functional check	219	X

## 14.5 Axle and brake



For optimum brake performance with a minimum of wear, we recommend that the brakes on the tractor are synchronised with those on the trailed sprayer. After the service braking system has been run in for a suitable period, arrange for the brakes to be synchronised by a specialist workshop.

Have the brakes synchronised before these empirical values are reached if you observe excessive wear of the brake linings.

To avoid problems with the brakes, adjust all vehicles in accordance with EC Guideline 71/320 EEC.



### WARNING!

- Repair and adjustment work on the service braking system should only be carried out by trained specialist personnel.
- Special care is required for welding, torch cutting and drilling work in the vicinity of brake lines.
- Always perform a braking test after any adjusting or repair work on the braking system.

### General visual inspection



### WARNING

Carry out a general visual check of the brake system. Observe and check the following criteria:

- Tubes, hose lines and coupling heads must not be externally damaged or corroded.
- Connecting rods, e.g. on fork heads, must be properly secured, easy to move, and not worn out.
- Ropes and cables
  - Must be properly run.
  - May not have any visible cracks.
  - may not be knotted.
- Check the piston stroke on the brake cylinders, and adjust as necessary.
- The air reservoir must not
  - move around in the tensioning belts.
  - be damaged.
  - show any outward signs of corrosion damage.

## Checking the brake drum for soiling (workshop work)

1. Unscrew the two cover plates (1) on the inside of the brake drum.
2. Remove any dirt and plant residue.
3. Refit the cover plates.




### CAUTION

Penetrating dirt may clog the brake linings (2), which considerably reduces the braking power.

### Danger of accident!

If there is dirt in the brake drum, the brake linings must be checked by a specialist workshop.

For this purpose, the wheel and brake drum must be detached.





## Check bearing clearance on wheel hubs (workshop work)

To check the bearing clearance on the wheel hubs, lift the axle until the wheels are free. Release the brake. Place a lever between the tyre and the ground and check the bearing clearance.

If there is noticeable bearing clearance:

### Adjusting the bearing clearance

- Remove the dust cup or hub cap.
- Remove the cotter pin from the axle nut.
- Tighten the wheel nut by simultaneously turning the wheel until the run of the wheel hub is lightly braked.
- Turn the axle nut back to the next possible cotter pin hole. If there is congruence, to the next hole (max. 30°).
- Insert the cotter pin and bend it up slightly.
- Replenish the dust cap with some long-life grease and pound or screw it into the wheel hub.




## Brake pad check

To check the brake pad thickness, open the inspection hole (1) by opening the rubber tab.

Changing the brake pads → Workshop work

Criterion for changing the brake pads:


- Minimum pad thickness of 5 mm was reached.
- Wear edge (2) was reached.



## Adjustment on the slack adjuster (workshop work)

Manually actuate the slack adjuster in the push direction. If the free travel of the long-stroke diaphragm cylinder pressure rod is max. 35 mm, the wheel brake must be readjusted.

The setting is carried out on the hexagonal adjusting screw of the slack adjuster. Set the free travel "a" to 10-12 % of the connected brake lever length "B",  
e.g. lever length 150 mm = free travel 15 - 18 mm.




## Checking the function of the automatic slack adjuster

1. Secure the machine against rolling away and release the service brake and parking brake.
2. Manually actuate the slack adjuster.

The free travel (a) may be a maximum of 10-15% of the connected brake lever length (B) (e.g. brake lever length 150 mm = free travel 15 - 22 mm).

Readjust the slack adjuster if the free travel is outside of the tolerance. → Workshop work




## Air reservoir



**Drain the air reservoir every day.**

- (1) Air reservoir
- (2) Tensioning belts
- (3) Drainage valve
- (4) Test connection for pressure gauge



1. Pull the drainage valve in a sideways direction using the ring until no more water escapes from the air reservoir.  
→ Water flows out of the drainage valve.
2. Unscrew the drainage valve from the air reservoir and clean the air reservoir if there are signs of dirt.



### 14.5.1 Cleaning the compressed air line filter on the coupling head

**!** Perform work in an unpressurized state.  
Secure the implement against rolling away.


1. Remove the bolt locking compound by hammering and remove the bolts (1).
2. Unscrew the bolts (2) by a few turns.
3. Lift the plate (3) over the rubber seal (4) and turn to the side.

**i** The unit is under spring tension.

4. Remove the rubber seal.

5. Clean and grease the sealing surfaces, O-ring and compressed air line filter.


→ Replace the rubber seal if necessary.



**!** Correctly position the O-ring on the plastic ring.


6. Reassemble in the reverse sequence.

- Bolt tightening torque (1): 2.5 Nm
- Bolt tightening torque (2): 7 Nm



### 14.5.2 Cleaning the compressed air line filter in the brake line

1. Press in the cover (1).
2. Take out the snap ring (2).
3. Take out the cover and compressed air line filter with 2 springs.
4. Clean or replace the compressed air line filter.
5. Grease the sealing ring.
6. Reassemble in the reverse sequence.



---

**Test instructions for dual circuit service brake system (workshop work)****1. Leak tightness check**

---

1. Check all connections, pipe lines, hose lines and screw connections are tight.
2. Remedy any leaks.
3. Repair any areas of chafing on pipes and hoses.
4. Replace porous and defective hoses.
5. The dual-circuit service brake system may be considered tight if within 10 minutes the pressure does not drop any more than 0.15 bar.
6. Seal any leaking areas or replace leaking valves.

**2. Checking the pressure in the air reservoir**

---

1. Connect a pressure gauge to the test connection on the air reservoir.

Target value 6.0 to 8.1 + 0.2 bar

**3. Checking the brake cylinder pressure**

---

1. Connect a pressure gauge to the test connection on the brake cylinder.

Target value: with brake not applied 0.0 bar

**4. Visual inspection of brake cylinder**

---

1. Check the dust collars or bellows (5) for damage.
2. Replace damaged parts.

**5. Joints on brake valves, brake cylinders and brake linkages**

---

Joints on brake valve, brake cylinders and brake linkages must slide smoothly, lubricate or grease lightly if necessary.


### 14.5.3 Automatic load-dependent braking force regulator (ALB)

Check the brake pressure:

connect a pressure gauge to the test connection on the brake cylinder.

if the brake pressure deviates from the required values, set the brake pressure on the ALB via the eye bolts.

1. **Container empty: set dimension X until the brake pressure of 3.5 bar is reached.**
  - Unscrew the eye bolt.
  - The test pressure reduces
  - Screw in the eye bolt.
  - The test pressure increases
2. **Container at nominal volume minus 10 to 15 %: set dimension Y until the brake pressure of 6.5 bar is reached.**
  - Unscrew the eye bolt
  - The test pressure increases
  - Screw the eye bolt in
  - The test pressure reduces



### 14.5.4 Hydraulic brakes


#### Check of the hydraulic brake

- Check all brake hoses for wear
- check all screw unions for seal tightness
- renew any worn or damaged parts.

#### Venting the brake system (workshop work)

After each brake repair, for which the system has been opened, bleed the brake system, because air may have entered the pressure hoses.

1. Slightly loosen the vent valve.
2. Actuate the tractor brake.
3. Close the vent valve as soon as oil escapes.
- Collect the escaping oil.
4. Perform a brake check.



## 14.6 Parking brake



On new implements, the brake cables for the parking brake can stretch.

Readjust the parking brake

- if three-quarters of the spindle tensioning distance is required to firmly apply the parking brake.
- if you have just fitted new brake linings.

### Readjusting the parking brake




When the parking brake is released, the brake cable must be slightly slack. In doing so, the brake cable may not rest or rub against other vehicle parts.

1. Loosen the cable clips.
2. Shorten the brake cable accordingly and then tighten the cable clips again.
3. Check for the proper braking effect when the parking brake is applied.

## 14.7 Axle fastening

Check the bolts for tight fit.



### 14.7.1 Tyres / wheels

1. Check the bolted connections.
2. Check and adjust the tyre inflation pressure according to the specifications on the sticker on the rim.
3. Check the tyres for damage and firm seating on the rim.




- **Required tightening torque for wheel nuts or bolts: 510 Nm**



To assemble the wheels, use:

- (1) conical rings in front of the wheel nuts.
- (2) only rims with a fitting countersink for the conical ring.



- Only use the tyres and rims that we have specified.
- Repair work on tyres must only be carried out by specialists using suitable assembly tools.
- Tyre fitting requires sufficient skills and proper assembly tools.
- Use the jack only at the marked jacking points!

### 14.7.2 Mounting tyres (workshop work)

---



- Remove any instances of corrosion from the wheel rim seating surfaces before fitting a new / another tyre. Corrosion can cause damage to the wheel rims when the vehicle is in operation.
- When fitting new tyres, always use new valves for tubeless tyres or new inner tubes.
- Always fit the valves with valve caps which have a gasket insert.

## 14.8 Check the coupling device



### DANGER!

- Replace a damaged drawbar with a new one immediately - for road traffic safety reasons.
- Repairs may only be carried out by the manufacturer factory.
- For safety reasons, it is forbidden to weld on and drill holes in the drawbar.

Check the coupling device (drawbar, lower link traverse, ball coupling, drawbar eye) for the following:

- damage, deformation, cracks
- wear
- tight fit of the fastening bolts


Coupling device	Wear dimension	Fixing bolts	Number	Tightening torque
<b>Lower link traverse</b>	Cat. 3: 34.5 mm Cat. 4: 48.0 mm Cat. 5: 56.0 mm	M20 8.8	8	410 Nm
<b>Ball coupling</b>				
K80 (LI009)	82 mm	M16 10.9	8	300 Nm
K80 (LI040)	82 mm	M20 10.9	8	560 Nm
K80 (LI015)	82 mm	M20 10.9	12	560 Nm
<b>Drawbar eye</b>				
D35 (LI038)	36,5 mm	M16 12.9	6	340 Nm
D40 (LI017)	41,5 mm	M16 10.9	6	300 Nm
D40 (LI006)	42,5 mm	M20 8.8	8	395 Nm
D46(LI034)	48 mm	M20 10.9	12	550 Nm
D50 (LI037)	51,5 mm	M16 12.9	4	340 Nm
D50 (LI010)	51,5 mm	M16 10.9	8	300 Nm
D50 (LI059)	51,5 mm	M20 10.9	4	560 Nm
D50 (LI011)	51,5 mm	M20 8.8	8	410 Nm
D50 LI060)	52,5 mm	M20 10.9	8	560 Nm
D51 (LI039)	53 mm	M20 10.9	12	600 Nm
D51 (LI069)	53 mm	M16 10.9	6	290 Nm
D58 (LI031)	60 mm	M20 10.9	12	550 Nm
D62 (LI007)	63,5 mm	M20 10.9	8	590 Nm
D79 (LI021)	81 mm	M20 10.9	12	550 Nm



## 14.9 Towing device

Check the bolts for tight fit.

Observe the specified tightening torques.



## 14.10 Hydraulic system



### WARNING

**Risk of infection through the high pressure hydraulic fluid of the hydraulic system entering the body.**

- Only a specialist workshop may carry out work on the hydraulic system.
- Depressurise the hydraulic system before carrying out work on the hydraulic system.
- When searching for leak points, always use suitable aids.
- Never attempt to plug leaks in hydraulic hose lines using your hand or fingers.

Escaping high pressure fluid (hydraulic fluid) may pass through the skin and ingress into the body, causing serious injuries!

If you are injured by hydraulic fluid, contact a doctor immediately. Risk of infection!




- When connecting the hydraulic hose lines to the hydraulic system of connected implements, ensure that the hydraulic system is depressurised on both the drawing vehicle and the trailer.
- Ensure that the hydraulic hose lines are connected correctly.
- Regularly check all the hydraulic hose lines and couplings for damage and impurities.
- Have the hydraulic hose lines checked at least once a year by a specialist for proper functioning.
- Replace the hydraulic hose lines if they are damaged or worn. Only use genuine AMAZONE hydraulic hose lines!
- The hydraulic hose lines should not be used for longer than six years, including any storage time of maximum two years. Even with proper storage and approved use, hoses and hose connections are subject to natural aging, thus limiting the length of use. However, it may be possible to specify the length of use from experience values, in particular when taking the risk potential into account. In the case of hoses and hose lines made of thermoplastics, other guide values may be decisive.
- Dispose of old oil in compliance with regulations. If you have problems with disposal, contact your oil supplier.
- Keep hydraulic fluid out of the reach of children!
- Ensure that no hydraulic fluid enters the soil or waterways.

### 14.10.1 Labelling of hydraulic hose lines

The valve chest identification provides the following information:

- (1) Manufacturer's marking on the hydraulic hose line (A1HF)
- (2) Date of manufacture of the hydraulic hose line (02 04 = February 2004)
- (3) Maximum approved operating pressure (210 BAR).



### 14.10.2 Maintenance intervals

**After the first 10 operating hours, and then every 50 operating hours**

1. Check all the components of the hydraulic system for tightness.
2. If necessary, tighten screw unions.

**Before each start-up:**

1. Check hydraulic hose lines for visible damage.
2. Eliminate any scouring points on hydraulic hose lines and pipes.
3. Replace any worn or damaged hydraulic hose lines immediately.

### 14.10.3 Inspection criteria for hydraulic hose lines



For your own safety and to reduce environmental pollution, comply with the following inspection criteria!

Replace hoses if the respective hose fulfils at least one of the following criteria:

- Damage to the outer layer up to the ply (e.g. scouring points, cuts, cracks).
- Brittleness of the outer layer (crack formation of the hose material).
- Deformations that do not match the natural shape of the hose. Both in a depressurized and pressurised state or when bent (e.g. layer separation, bubble formation, pinching, bends).
- Leak points.
- Installation requirements not complied with.

- Life span of 6 years has been exceeded.

The date of manufacture of the hydraulic hose line on the valve chest plus six years is decisive. If the date of manufacture on the assembly is "2004", then the hose should not be used beyond February 2010. For more information, see "Labelling of hydraulic hose lines".



Common causes for leaking hoses / pipes and connection pieces include:

- missing O-rings or gaskets
- damaged or badly fitting O-rings
- brittle or deformed O-rings or gaskets
- foreign bodies
- badly fitting hose clamps

### 14.10.4 Installation and removal of hydraulic hose lines



You must

- only use genuine AMAZONE replacement hoses. These replacement hoses withstand the chemical, mechanical and thermal strains.
- always use hose clamps made from V2A for fitting hoses.



When installing and removing hydraulic hose lines, always observe the following information:

- Ensure cleanliness. • Always install the hydraulic hose lines to ensure the following in all operating positions
  - There is no tension, apart from the hose's own weight.
  - There is no possibility of jolting on short lengths.
  - Outer mechanical influences on the hydraulic hose lines are avoided.

Use appropriate arrangements and fixing to prevent any scouring of the hoses on components or on each other. If necessary, secure hydraulic hose lines using protective covers. Cover sharp-edged components.

  - The approved bending radii may not be exceeded.



- When connecting a hydraulic hose line to moving parts, the hose length must be appropriate so that the smallest approved bending radius is not undershot over the whole area of movement and/or the hydraulic hose line is not over-tensioned.
- Fasten the hydraulic hose lines at the specified fixing points. There, avoid hose clips, which impair the natural movement and length changes of the hose.
- It is forbidden to apply paint on the hydraulic hose lines!

### 14.10.5 Oil filter

- Oil filter for Profi-folding
- Oil filter for hydraulic pump drive

Hydraulic oil filter (1) with contamination indicator (2).

- GreenFilter is working
- Red Replace filter

#### Checking the oil filter for contamination

The hydraulic oil must have reached operating temperature.

1. Press in the contamination indicator.
2. Continue working with the implement.
3. Observe the contamination indicator.

#### Replacing the oil filter


To dismantle the filter, unscrew the filter lid and remove the filter.



#### CAUTION

**Depressurise the hydraulic system beforehand.**

Otherwise, there is danger of injuries from escaping hydraulic oil at high pressure.



After replacing the oil filter, press the contamination indicator back down.

→ **Green ring is visible again.**

### 14.10.6 Adjusting the hydraulic throttle valve

**The operating speeds for the individual hydraulic functions are set at the factory using the respective hydraulic throttle valves on the valve block** (fold/unfold sprayer boom, lock/unlock the vibration compensation, etc.). However, depending on the type of tractor, it may be necessary to correct these speed settings.

The operating speed for a hydraulic function associated with a particular throttle pair can be adjusted by screwing the hexagon socket head screw on the corresponding throttle in or out.

- Reduce operating speed = screw in hexagon socket head screw.
- Increase operating speed = screw out hexagon socket head screw.



Always adjust the two throttles in a throttle pair equally when correcting the operating speed of a hydraulic function.

## 14.11 Hydro-pneumatic pressure reservoir



### WARNING

**Risk of injury when working on the hydraulic system with pressure reservoir.**


Work on the hydraulic block and hydraulic hoses with the pressure reservoir connected may only be performed by specialist personnel.

## 14.12 Settings on the unfolded sprayer boom

### Alignment parallel to the ground

When the sprayer boom is unfolded and correctly adjusted, all of the spraying nozzles must have the same parallel distance from the ground.

If this is not the case, align the unfolded sprayer boom using counterweights (1) with the vibration compensation **unlocked**. Attach the counterweights accordingly on the boom.




### Horizontal alignment

In the direction of travel, all of the boom sections of the sprayer boom must be aligned. Horizontal alignment can be necessary

- after long periods of operation
- or rough ground contact of the sprayer boom.

#### inner boom

1. Loosen the lock nut of the adjusting screw (5).
2. Turn the adjusting screw against the stops until the inner boom section is aligned with the centre part of the boom.
3. Tighten the lock nut.



#### Outer boom section

1. Loosen the bolts (2) for the fastening lug (3). Alignment is carried out right on the plastic jaw (4) using the elongated slots of the fastening lug.
2. Align the boom section.
3. Tighten the bolts (2).

## 14.13 Electro hydraulic boom




### WARNING

Risk of injury due to accidental movement of the sprayer boom in automatic mode when entering the radiation area of the ultrasound sensor.



Lock the sprayer boom

- Before leaving the tractor.
- If unauthorised persons are standing in the area of the sprayer boom.



- (1) Ultrasound sensors for boom tilt
- (2) Yaw rate sensor for boom tilt
- (3) Potentiometer for boom tilt
- (4) Potentiometer for boom folding
- (5) Hydraulic block with manual emergency folding function

### Emergency folding function for the outer boom sections

In case of defective wiring harness, the boom sections can be hydraulically folded by manual actuation of the hydraulic block (5a, b, c).

→ Control terminal is switched on, oil circulation is active.

- Press the button on both solenoids 5a: outer boom section is folded.
- Press the button on both solenoids 5b: 2nd boom section from the outside is folded.
- Press the button on both solenoids 5c: 3rd boom section from the outside is folded.



Emergency folding with intact electronics:

See ISOBUS operating manual / settings / implement.

## 14.14 Pump



### WARNING


#### Risks due to accidental contact with spray liquid!

Clean the implement with flushing water before you remove the spraying pump or other components that come into contact with spray agent or spray liquid.

### 14.14.1 Check the oil level



- Only use branded oil 20W30 or multi-purpose oil 15W40!
- Check that the oil level is correct! Damage may be caused both by the oil level being too low or too high.
- As the pump is not in a horizontal position at the hitch drawbar, average the oil level read.
- Foam generation and cloudy oil are signs of a faulty pump membrane.  
Do not run a defective pump.



1. Check whether the oil level is visible at the mark with the pump not running and standing on a level surface.
2. Check whether the oil is clear.
3. If the oil level is not visible at the mark, remove the lid and top up with oil.



### 14.14.2 Changing the oil



- After a few operating hours, check the oil level; top up if necessary.

1. Remove the pump.
2. Remove the cover.
3. Drain the oil.
  - 3.1 Turn the pump on its head.
  - 3.2 Rotate the drive shaft by hand until the used oil has all run out.

The option also exists to drain the oil from the drain plug. However, with this procedure a slight oil residue remains in the pump; we therefore recommend the first approach.
4. Place the pump on an even surface.
5. Turn the drive shaft left and right alternately and slowly fill with new oil. The right quantity of oil has been reached when the oil is visible at the mark.

### 14.14.3 Cleaning




**Thoroughly clean the pump after each operation by pumping clear fresh water for a few minutes.**

#### 14.14.4 Checking and replacing the suction and pressure-side valves (workshop work)



- Pay attention to the respective installation position of the valves on the suction and pressure sides before removing the valve group (5).
- When reassembling, ensure that the valve guide (9) is not damaged. Damage may cause the valves to jam.
- Always tighten the nuts (1,2) crosswise using the specified torque. Improper tightening of the nuts causes warping, which results in leaks.




1. If necessary, remove the pump.
2. Remove the nuts (1,2).
3. Remove the suction and pressure port (3 and 4).
4. Remove the valve groups (5).
5. Check the valve seat (6), valve (7), valve spring (8) and valve guide (9) for damage or wear.
6. Remove the O-ring (10).
7. Replace defective parts.
8. Fit the valve groups (5) after testing and cleaning.
9. Insert new O-rings (10).
10. Mount the suction (3) and pressure port (4) on the pump housing.
11. Tighten the nuts (1,2) crosswise using a torque of **25 Nm (BP 160-185) / 20 Nm (AR 250-280)**.

### 14.14.5 Checking and replacing the piston diaphragm (workshop work)



- At least once a year, check that the piston diaphragm (8) is in perfect condition by removing it.
- Pay attention to the respective installation position of the valves on the suction and pressure sides before removing the valve group (5).
- Check and replace the piston diaphragm for each piston individually. Only remove the next piston in sequence after the currently removed piston has been completely checked and refitted.
- Always swivel the piston to be checked upwards so that the oil in the pump housing does not run out.
- As a rule, replace all piston diaphragms (8) even if only one piston diaphragm is distorted, punctured or porous.



#### Checking the piston diaphragm

1. If necessary, remove the pump.
2. Unscrew the nuts (1, 2).
3. Remove the suction and pressure port (3 and 4).
4. Remove the valve groups (5).
5. Remove the bolts (6).
6. Remove the cylinder head (7).
7. Check the piston diaphragm (8).
8. Replace the damaged piston diaphragm.

## Replacing the piston diaphragm



- Ensure the correct position for the recesses and/or holes on the hydraulic cylinders.
- Secure the piston diaphragm (8) with a washer disc and a bolt (11) on the piston (9), so that the rim shows on the cylinder head side (7).
- Always tighten the nuts (1,2) crosswise using the specified torque. Improper tightening of the nuts causes warping, which results in leaks.

1. Loosen the bolt (11) and remove the piston diaphragm (8) together with the holding washer from the piston (9).
2. If the piston diaphragm has been punctured, drain the oil/spray liquid mixture from the pump housing.
3. Remove the hydraulic cylinder (10) from the pump housing.
4. Clean the pump housing by flushing it thoroughly with diesel oil or paraffin.
5. Clean all sealing faces.
6. Insert the cylinder (10) back into the pump housing.
7. Fit the piston diaphragm (8).
8. Align the cylinder head (7) on the pump housing and tighten the bolts (6) evenly in a crosswise fashion.  
Use thread lock for medium-fixed connections!
9. Fit the valve groups (5) after testing and cleaning.
10. Insert new O-rings.
11. Mount the suction (3) and pressure port (4) on the pump housing.
12. Tighten the nuts (1,2) crosswise using a torque of **25 Nm (BP 160-185) / 20 Nm (AR 250-280)**.

## 14.15 Calibrate the flow meter



Refer to the ISOBUS software operating manual; section "Pulses per litre".

## 14.16 Eliminating limescale in the system

Indications that there may be lime deposits:


- The nozzle body does not open or close.
- Error messages on the control terminal
- Limescale deposits in the tank and suction filter



### **DANGER**

**Health risk due to contact with acidification agents.**

**Observe the instructions for use on the packaging!**

1. Completely clean the empty sprayer.
  2. Fill 20 to 50 litres of flushing water into the spray liquid tank.
  3. Start the spraying pump.
  4. Pour the acidification agent (3 l) into the spray liquid tank through the inspection hatch.
- Target pH-value for descaling: 2 - 3
5. Allow the mixture to circulate in the spray line for 10-15 minutes.
  6. Interrupt the pump drive.
- 
7. **AmaSelect:** Without pump drive, use the manual nozzle selection to switch through all nozzle positions several times.
  8. Start the spraying pump.
  9. Allow the mixture to circulate in the spray line for a few more minutes.
  10. Dilute the mixture with water until the target pH-value of 6 - 7 has been reached.
- The diluted mixture is harmless and can be used to prepare the spray liquid.

**Basic information about water hardness and pH-value**

Especially for treatments with trace elements and fertiliser additions, attention must be paid to the water hardness and the pH-value to ensure clean surfaces and smooth functioning of all valves.

At a water hardness greater than 15° dH (German water hardness), we recommend the use of polyphosphate-based hardness stabilisers. When complying with the manufacturer specifications, the products are safe for health and the environment.

Product example: Folmar P30 from Aquakorin.

Particularly with crop protection product mixtures with trace elements such as boron, which increase the pH-value, the pH-value of the ready-to-use spray liquid should be kept below  $\leq 7$ .

Product example:

- Citric acid
- Acidifying agents, such as:
  - pH-Fix from Sudau
  - Spray Plus from Belchim Crop Protection
  - X-Change from De Sangosse



Commercial sprayer cleaning agents are strongly alkaline and therefore neutralise crop protection product residues such as sulphonylurea in the sprayer. In case of limescale in the implement, however, they increase the pH-value and are therefore counterproductive for descaling.

## 14.17 Metering the field sprayer

### Test the field sprayer by metering


- before the start of the season.
- each time the nozzles are changed.
- to check the setting information in the spray tables.
- in the case of deviations between the actual and required application rate [l/ha].

Observed deviations between the actual and required application rate [l/ha] can be caused by:

- the difference between the actual forward speed and that indicated on the tractor meter and/or
- natural wear to the spraying nozzles.

Accessories required for metering:

- (1) Quick-check cup
- (2) Stopwatch



### Determining the actual application rate while stationary via the individual nozzle output

Determine the nozzle output on at least 3 different nozzles. To do so, check one nozzle on the left and right boom section respectively, and one in the middle of the sprayer boom, as follows.

#### 1. Control terminal:

- 1.1 Enter the value for the required application rate on the control terminal.
- 1.4 Enter simulated speed.

#### 2. Fill the spray liquid tank with water (approx. 1000 l).

#### 3. Switch on the agitator.

#### 4. Switch on the sprayer and check that all of the nozzles work properly.

#### 5. Determine the individual nozzle output [l/min] on several nozzles.

To do so, hold the quick-check cup for exactly 30 seconds under a nozzle.

#### 6. Switch off the spraying.


#### 7. Determine the average individual nozzle output [l/ha].

- Using the table on the quick-check cup.
- By calculation.
- Using the spray table.

**Example:**

Noz. size '06'  
 Intended forward speed 7 km/h  
 Nozzle output on the left boom section: 0.85 l/30s  
 Nozzle output in the middle 0.84 l/30s  
 Nozzle output on the right boom section: 0.86 l/30s  
 Calculated average value: **0.85 l/30s → 1.7 l/min**

**1. Determining the individual nozzle output [l/ha] with the quick-check cup**



- (1) → Determined application rate 290 l/ha  
 (2) → Determined spray pressure 1.6 bar

**2. Calculating the individual nozzle output [l/ha]**

$$\frac{d \text{ [l/min]} \times 1200}{e \text{ [km/h]}} = \text{Application rate [l/ha]}$$

- o d: Nozzle output (calculated average value) [l/min]
- o e: Forward speed [km/h]

$$\frac{1.7 \text{ [l/min]} \times 1200}{7 \text{ [km/h]}} = 291 \text{ [l/ha]}$$

**3. Reading the individual nozzle output [l/ha] from the spray table**

From the spray table (see page 249):

- Application rate 291 l/ha
- Spray pressure 1.6 bar



If the determined values for the application rate and application pressure do not match the set values:

- Calibrate the flow meter (see control terminal ISOBUS operating manual)
- Check all nozzles for wear and blockages.



## 14.18 Nozzles




### WARNING


#### Risks due to accidental contact with spray liquid!

Flush the nozzles with flushing water before you remove the nozzles or diaphragm valves.

### Fitting the nozzle

 Different nozzle sizes are marked with bayonet nuts of different colours.

1. Insert the nozzle filter (5) into the nozzle body from below.

 The nozzle is located in the bayonet nut

2. Press a rubber seal (6) above the nozzle into the seat for the bayonet nut.
3. Turn the bayonet nut on the bayonet connection up to the stop.

### Removing the diaphragm valve if the nozzle is dripping

Deposits on the diaphragm seat in the nozzle body cause dripping after the nozzle has been switched off.


1. Remove the spring element (3).
2. Take out the diaphragm (2).
3. Clean the diaphragm seat.
4. Check the diaphragm for cracks.
5. Reinstall the diaphragm and spring element.

### Checking the nozzle shutter

From time to time, check the seating of the shutter (4).

To do this, insert the shutter into the nozzle body as far as possible using moderate thumb pressure.


Do not insert the shutter up to the stop when in a new condition under any circumstances.



## 14.19 Line filter

---

- Clean the line filters (1) every 3 - 4 months depending on operating conditions.
- Change damaged filter inserts.



## 14.20 Instructions on testing the field sprayer




- Only authorised centres are permitted to carry out spray tests.
- According to law, a spray test must be carried out:
  - 6 months after commissioning (if not performed at time of purchase) at the latest, then
  - every two years thereafter.

### Field sprayer test set (optional), order no.: 114586


#### Pressure gauge test

- (1) Push-on cap (order no.: 913954) and connector (order no.: ZF195)
- (2) Blind hose (order no.: 116059)
- (3) Pressure gauge connection (order no.: 7107000)




#### Flow meter test

- (1) O-ring (order no.: FC122)
- (2) Hose connection (order no.: GE095)
- (3) Union nut (order no.: GE021)




#### Pump test

- (1) O-ring (order no.: FC149)
- (2) Hose connection (order no.: GE052)
- (3) Union nut (order no.: GE022)
- (4) O-ring (order no.: FC468)
- (5) Hose connection (order no.: ZF1395)



## Pump test - testing pump performance (delivery capacity, pressure)


1. Loosen the union nut (1).
2. Put on the hose connection.
3. Tighten the union nut.



## Flow meter test


### and boom part width section chest

1. Loosen the union nut (1) behind the flow meter.
2. Fasten the plug-in socket (order no. 919345) with the union nut and connect it to the testing device.
3. Switch on spraying.



### DUS pro single nozzle control

1. Loosen the union nut (1) behind the flow meter.
2. Fasten the plug-in socket (order no. 919345) with the union nut and connect it to the testing device.
3. Switch on spraying.




## Pressure gauge test

### and boom part width section chest



1. Remove one spray line from a part-width section valve and seal it with the blind hose (order no. 1166060).
2. Connect the pressure gauge connection to a part width section valve with the help of the turned socket.
3. Screw the check gauge 1/4 of an inch into the inside thread.
4. Switch on spraying

### DUS pro single nozzle control



1. Disconnect the return line (1) beside the pressure sensor and seal it with the blind hose (order no. 1166060).
2. Connect the pressure gauge connection (order no. 7107000) to the spray line (2).
3. Screw the check gauge 1/4 of an inch into the inside thread.
4. Switch on spraying.



## 14.21 Bolt tightening torques

<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;"> <b>8.8</b>  <b>10.9</b>  <b>12.9</b> </div>  </div>												
		 Nm										
M	S	8.8	10.9	12.9								
M 8	13	25	35	41								
M 8x1		27	38	41								
M 10	16 (17)	49	69	83								
M 10x1		52	73	88								
M 12	18 (19)	86	120	145								
M 12x1.5		90	125	150								
M 14	22	135	190	230								
M 14x1,5		150	210	250								
M 16	24	210	300	355								
M 16x1,5		225	315	380								
M 18	27	290	405	485								
M 18x1,5		325	460	550								
M 20	30	410	580	690								
M 20x1,5		460	640	770								
M 22	32	550	780	930								
M 22x1,5		610	860	1050								
M 24	36	710	1000	1200								
M 24x2		780	1100	1300								
M 27	41	1050	1500	1800								
M 27x2		1150	1600	1950								
M 30	46	1450	2000	2400								
M 30x2		1600	2250	2700								

<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;"> <b>A2-70</b>  <b>A4-70</b> </div>  </div>												
M	M4	M5	M6	M8	M10	M12	M14	M16	M18	M20	M22	M24
 Nm	2.4	4.9	8.4	20.6	40.7	70.5	112	174	242	342	470	589



Coated bolts have different tightening torques.

Observe the specific data for tightening torques in the maintenance section.

## 14.22 Disposing of the field sprayer



Clean the entire field sprayer thoroughly (from the inside and outside) before disposing of the field sprayer.

The following components can be used for energy recovery\*: spray liquid tank, induction bowl, flushing water tank, hand wash tank, hoses and plastic fittings.

Metal parts can be scrapped.

Observe the applicable legal regulations when disposing of the individual recyclable materials.

\* Energy recovery

is the recovery of energy contained in plastic parts through combustion and using this energy to produce electricity and/or steam or to supply process heat. Energy recovery is suitable for mixed and for soiled plastics, especially for plastic fractions contaminated with harmful substances.


## 15 Diagrams and overviews

### 15.1 Liquid circuit


<b>1X Hopper</b>	<b>5X Cleaning &amp; agitators</b>
10 Spray liquid tank	50 Main agitator
11 Flushing water tank	51 Main agitator check valve
12 Hand wash tank	52 Secondary agitator
13 Induction bowl	53 Check valve - secondary agitator
BEL082 Injector potentiometer	54 External wash-down device
BEL092 Induction bowl sensor	55 Internal cleaning
BWA090 Fill level potentiometer	KWA040 Auxiliary agitator motor valve
BWA091 Flushing water tank fill level sensor	KWA045 Main agitator motor valve
<b>2X Suction side</b>	BWA045 Pressure sensor - main agitator
20	Motor valve, internal cleaning with spray liquid
21 External suction connection (3" camlock)	KWA106
22 Suction tap	<b>6X Spraying operation</b>
23 Drain main tank / quick emptying	60 Pressure stage 0.8 bar
24 Spray liquid tank shut-off function	KWA010 Spraying operation motor valve
25 Suction filter	KWA011 Pressure control valve
25 Overpressure protection check valve	KWA020 Return flow control valve
KWA060 Suction tap linear motor	<b>7X Booms</b>
KWA072 Drain main tank linear motor	70 Part width valves
GWA001 Spraying pump	71 Pressure relief channel
GWA002 Agitator pump	72 Bypass valve
BEL001 Water pumps speed sensor	73 Spray line
<b>3X Pressure side</b>	74 DUS tap
30 Pressure filter	75 DUS pressure valve
31 Pressure relief valve	76 DUS check valve
32 Pressure filling connection (C-coupling / fire brigade)	BWA010 Spraying pressure sensor
33 Filling connection hand wash tank with tap	BWA011 Flow meter 1
34 Filling connection flushing water tank with tap	BWA020 Flow meter 2
35 Pressure filling check valve flushing water tank	BWA030 Flow meter 3
36 Pressure filling check valve spray liquid tank	
37 7-way pressure tap	
38 Pressure filter drain tap	
KWA073 Quick emptying motor valve	
KWA075 Pressure filling motor valve spray liquid tank	
KWA076 Pressure filling motor valve flushing water tank	
KWA077 Motor valve induction bowl supply with spray liquid	
<b>4X Induction bowl (ESB) &amp; Injector</b>	<b>1XX HighFlow+</b>
40 Induction bowl supply tap via spraying pump / pressure filling	100 Pressure relief valve
41 Induction bowl jet nozzle tap / spray gun	101 Pressure filter
42 Ring line tap / canister cleaning	102 Secondary agitator tap / drain pressure filter
43 Canister cleaning	103 Spray line check valves
44 Induction bowl cleaning nozzle	KWA030 HighFlow+ motor valve
45 Powder jet nozzle	
46 Spray gun	<b>3XX AmaSelect / AmaSwitch</b>
47 Injector	300 Nozzle body
48 Injector suction line check valve	301 Boom stop tap
48 Injector supply via induction bowl tap / suction connection (additional injector)	302 Return flow stop tap
49 Closed transfer system suction connection	303 Pressure side stop tap
49a Closed transfer system flushing connection	304 Line filter
49b Injector operation on/off motor valve	305 AmaSwitch pressure stage
KWA070	
Injector supply via induction bowl motor valve / suction connection (additional injector)	
KWA071	
KWA078 ECO-Fill suction motor valve	



## 15.2 Liquid circuit Part-width section control:








## 15.3 Liquid circuit AmaSelect single nozzle control / HighFlow+ / XTreme-Clean



This schematic diagram illustrates the layout of a water treatment plant. The central feature is a large circular tank (10) containing water (H<sub>2</sub>O) and equipped with multiple internal mixing or aeration devices (50, 52, 55). To the left of this tank is a rectangular storage tank (11) also labeled H<sub>2</sub>O. The system is interconnected with numerous pipes, valves, and pumps. Key components include:
 


- Pumps and Motors:** Various pumps are labeled with codes like KWA (e.g., KWA 011, KWA 012, KWA 045, KWA 046, KWA 060, KWA 075, KWA 080, KWA 091, KWA 092), GWA (GWA 001, GWA 002), BWA (BWA 045, BWA 091, BWA 092), and UX (UX01).
- Storage and Distribution:** A large rectangular tank (30) is located at the bottom left, and a smaller one (24) is in the center. A long horizontal pipe (300) with multiple valves runs across the middle left.
- Valves and Controls:** Numerous valves are marked with numbers (e.g., 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 49a, 49b, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60) and symbols indicating their function.
- Other Equipment:** A green circular device (54) is connected to a red pipe (37). A red pipe (38) is also shown. A red pipe (39) is connected to a red pipe (40). A red pipe (41) is connected to a red pipe (42). A red pipe (43) is connected to a red pipe (44). A red pipe (45) is connected to a red pipe (46). A red pipe (47) is connected to a red pipe (48). A red pipe (49) is connected to a red pipe (50).

## 15.5 Actuators and sensors




## 15.6 Hydraulic diagram


### Basic implement




## Profi-folding:




## ContourControl and SwingStop



## Hydraulic folding



## Electro hydraulic folding




## 15.7 Fuses and relays

The fuse box is located under the cover at the front left.



### 15.7.1 Fuses for the boom functions



Number	Amperage	Function
F1	10 A	OV_E
F2	5 A	12V-L-S Tilting cylinder pressure, right-side
F3	20 A	12V_M
F4	30 A	Spare
F5	30 A	12V_L_MRS1
F6	30 A	12V_L_MRS2
F7	30 A	12V_C_CP
F8	10 A	K1 Boom work floodlights, left-side / surroundings on right-side
F9	10 A	K2
F10	10 A	K3
F11	10 A	K4


### Relays for the boom functions

Number	Function
K1	Boom work floodlights, left-side / surroundings on right-side
K2	XTremeClean valve / drive
K3	spare
K4	spare



### 15.7.2 AmaSelect fuses on the boom

The fuses are located under the cover hood on the centre section of the boom.



Number	Am- perage	Function
---	15 A	AmaSelect motor
---	15 A	AmaSelect lighting

## 16 Spray table

### 16.1 Spray tables for flat-fan, anti-drift, injector and airmix nozzles, spraying height 50 cm



- The application rates [l/ha] listed in the spray tables are only valid for water. To convert the application rates given into AUS, multiply these by 0.88 and, for NP solutions, by 0.85.
- Table 1 is used to select the right nozzle type. The nozzle type is determined by
  - the intended forward speed,
  - the required application rate and
  - the required atomisation characteristic (fine, medium or coarse-dropped) of the crop protection agent used for the crop protection measure.
- Table 2 is used to
  - determine the nozzle size.
  - determine the required spray pressure.
  - determine the required individual nozzle output for calibrating the field sprayer.

#### Permissible pressure ranges for different nozzle types and sizes

Nozzle type	Manufacturer	Permissible pressure range [bar]	
		min. pressure	max. pressure
XRC	TeeJet	1	5
AD	Lechler	1.5	5
Air Mix	agrotop	1	6
Air Mix OC		2	4
IDK / IDKN	Lechler	1	6
ID3 01 - 015		3	8
ID3 02 - 08		2	8
AI	TeeJet	2	8
TTI		1	7
AVI Twin	agrotop	2	8
TD Hi Speed		2	10



For further information about the nozzle characteristics, see the nozzle manufacturer's website.

[www.agrotop.com](http://www.agrotop.com) / [www.lechler-agri.de](http://www.lechler-agri.de) / [www.teejet.com](http://www.teejet.com)

## Selecting the nozzle type




Table 1






### Example:

Required application rate:	200 l/ha
Intended operational speed:	8 km/h
Required atomisation characteristic for the crop protection measure:	<b>coarse-dropped</b> (fine drift-ing)
Required nozzle type:	?
Required nozzle size:	?
Required spray pressure:	? bar
Required individual nozzle output for calibrating the field sprayer:	? l/min

## Determining the nozzle type, nozzle size, spray pressure and individual nozzle output

1. Determine the working point for the required application rate (**200 l/ha**) and the intended operational speed (**8 km/h**).
  2. At the working point, trace a line down the table. Depending on the position of the working point, this line will run through the cells for various nozzle types.
  3. Select the best nozzle type for the crop protection measure in question, with reference to the required atomisation characteristic (fine, medium or coarse-dropped).
- Nozzle choice for the example given above:
- Nozzle type: **AI or ID**
4. Switch to the spray table (Table 2).
  5. In the column with the intended operational speed (**8 km/h**), find the required application rate (**200 l/ha**) or a figure which is as close as possible to the required application rate (in this case, for example, **195 l/ha**).
  6. In the line with the required application rate (**195 l/ha**),
    - o read the nozzle sizes in question. Select a suitable nozzle size (e.g. **'03'**).
    - o where the nozzle size column intersects with the selected nozzle size, read the required spray pressure (e.g. **3.7 bar**).
    - o read the required individual nozzle output (**1.3 l/min**) for calibrating the field sprayer.

Required nozzle type:	<b>AI / ID</b>
Required nozzle size:	<b>'03'</b>
Required spray pressure:	<b>3.7 bar</b>
Required individual nozzle output for calibrating the field sprayer:	<b>1.3 l/min</b>

 50 cm H <sub>2</sub> O												 l/ha		 bar								
6	6,5	7	7,5	8	8,5	9	10	11	12	14	16	 km/h		l/min	015	02	025	03	04	05	06	08
80	74	69	64	60	56	53							0,4	1,4								
100	92	86	80	75	71	67	60	55					0,5	2,2	1,2							
120	111	103	96	90	85	80	72	65	60	51			0,6	3,1	1,8	1,1						
140	129	120	112	105	99	93	84	76	70	60	53		0,7	4,2	2,4	1,5	1,1					
160	148	137	128	120	113	107	96	87	80	69	60		0,8	5,5	3,1	2,0	1,4					
180	166	154	144	135	127	120	108	98	90	77	68		0,9	7,0	4,0	2,5	1,8	1,0				
200	185	171	160	150	141	133	120	109	100	86	75		1,0		4,9	3,1	2,2	1,2				
220	203	189	176	165	155	147	132	120	110	94	83		1,1		5,9	3,7	2,7	1,5	1,0			
240	222	206	192	180	169	160	144	131	120	103	90		1,2		7,0	4,4	3,2	1,8	1,1			
260	240	223	208	195	184	173	156	142	130	111	98		1,3			5,2	3,7	2,1	1,3	1,0		
280	259	240	224	210	198	187	168	153	140	120	105		1,4			6,0	4,3	2,4	1,6	1,1		
300	277	257	240	225	212	200	180	164	150	129	113		1,5			6,9	5,0	2,8	1,8	1,2		
320	295	274	256	240	226	213	192	175	160	137	120		1,6				5,7	3,2	2,0	1,4		
340	314	291	272	255	240	227	204	185	170	146	128		1,7				6,4	3,6	2,3	1,6		
360	332	309	288	270	254	240	216	196	180	154	135		1,8				7,2	4,0	2,6	1,8	1,0	
380	351	326	304	285	268	253	228	207	190	163	143		1,9					4,5	2,9	2,0	1,1	
400	369	343	320	300	282	267	240	218	200	171	150		2,0					4,9	3,2	2,2	1,2	
420	388	360	336	315	297	280	252	229	210	180	158		2,1					5,4	3,5	2,4	1,4	
440	406	377	352	330	311	293	264	240	220	189	165		2,2					6,0	3,8	2,7	1,5	
460	425	394	368	345	325	307	276	251	230	197	173		2,3					6,5	4,2	2,9	1,6	
480	443	411	384	360	339	320	288	262	240	206	180		2,4					7,1	4,6	3,2	1,8	
500	462	429	400	375	353	333	300	273	250	214	188		2,5						5,0	3,4	1,9	
520	480	446	416	390	367	347	312	284	260	223	195		2,6						5,4	3,7	2,1	
540	499	463	432	405	381	360	324	295	270	231	203		2,7						5,8	4,0	2,3	
560	517	480	448	420	395	373	336	305	280	240	210		2,8						6,2	4,3	2,4	
580	535	497	464	435	409	387	348	316	290	249	218		2,9						6,7	4,6	2,6	
600	554	514	480	450	424	400	360	327	300	257	225		3,0						7,1	5,0	2,8	
620	572	531	496	465	438	413	372	338	310	266	233		3,1								3,0	
640	591	549	512	480	452	427	384	349	320	274	240		3,2								3,2	
660	609	566	528	495	466	440	396	360	330	283	248		3,3								3,4	
680	628	583	544	510	480	453	408	371	340	291	255		3,4								3,6	
700	646	600	560	525	494	467	420	382	350	300	263		3,5								3,8	
720	665	617	576	540	508	480	432	393	360	309	270		3,6								4,0	
740	683	634	592	555	522	493	444	404	370	318	278		3,7								4,3	
x 0,88		608	570	537	507	456	415	380	326	285	3,8										4,5	
H <sub>2</sub> O ↔ AHL		624	585	551	520	468	425	390	335	293	3,9										4,7	
x 1,14		640	600	565	533	480	436	400	343	300	4,0										5,0	

LU / XR: 1 – 5 bar  
AD: 1,5 – 6 bar  
ID / AI: 2 – 8 bar  
IDK / Air Mix: 1 – 6 bar  
TTI: 1 – 7 bar

ME 735

ME 735

## 16.2 Spraying nozzles for liquid fertiliser

Nozzle type	Manufacturer	Permissible pressure range [bar]	
		min. pressure	max. pressure
3- jet	agrotop	2	8
7- hole	TeeJet	1.5	4
FD	Lechler	1.5	4
Drag hose	AMAZONE	1	4

### 16.2.1 Spray table for three-ray nozzles, spraying height 120 cm

#### AMAZONE - Spray table for three-ray nozzles (yellow)

Pres- sure  (bar)	Nozzle output		AUS spray rate (l/ha) /								
	Water  (l/min)	AUS	6	7	8	9	10	11	12	14	16
			km/h								
1,0	0,36	0,32	64	55	48	43	39	35	32	28	24
1,2	0,39	0,35	69	60	52	47	42	38	35	30	26
1,5	0,44	0,39	78	67	59	53	47	43	39	34	30
1,8	0,48	0,42	85	73	64	57	51	47	43	37	32
2,0	0,50	0,44	88	75	66	59	53	48	44	38	33
2,2	0,52	0,46	92	78	69	62	55	50	46	39	35
2,5	0,55	0,49	98	84	74	66	57	54	49	52	37
2,8	0,58	0,52	103	88	77	69	62	56	52	44	39
3,0	0,60	0,53	106	91	80	71	64	58	53	46	40

#### AMAZONE - Spray table for three-ray nozzles (red)

Pres- sure  (bar)	Nozzle output		AUS spray rate (l/ha) /								
	Water  (l/min)	AUS	6	7	8	9	10	11	12	14	16
			km/h								
1.0	0.61	0.54	108	93	81	72	65	59	54	47	41
1.2	0.67	0.59	118	101	88	78	70	64	59	51	44
1.5	0.75	0.66	132	114	99	88	79	72	66	57	50
1.8	0.79	0.69	138	119	104	92	83	76	69	60	52
2.0	0.81	0.71	142	122	107	95	85	78	71	61	54
2.2	0.84	0.74	147	126	111	98	88	80	74	63	56
2.5	0.89	0.78	155	133	117	104	93	84	78	67	59
2.8	0.93	0.82	163	140	122	109	98	87	82	70	61
3.0	0.96	0.84	168	144	126	112	101	92	84	72	63

**AMAZONE - Spray table for three-ray nozzles (blue)**

Pres- sure  (bar)	Nozzle output		AUS spray rate (l/ha) /								
	Water	AUS									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1.0	0.86	0.76	152	130	114	101	91	83	76	65	57
1.2	0.94	0.83	166	142	124	110	99	91	83	71	62
1.5	1.05	0.93	186	159	140	124	112	102	93	80	70
1.8	1.11	0.98	196	167	147	131	117	107	98	84	74
2.0	1.15	1.01	202	173	152	135	121	110	101	87	76
2.2	1.20	1.06	212	182	159	141	127	116	106	91	80
2.5	1.26	1.12	224	192	168	149	135	122	112	96	84
2.8	1.32	1.17	234	201	176	156	141	128	117	101	88
3.0	1.36	1.20	240	206	180	160	144	131	120	103	90

**AMAZONE - Spray table for three-ray nozzles (white)**

Pres- sure  (bar)	Nozzle output		AUS spray rate (l/ha) /								
	Water	AUS									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1.0	1.16	1.03	206	177	155	137	124	213	103	89	78
1.2	1.27	1.12	224	192	168	149	134	222	112	96	84
1.5	1.42	1.26	252	217	190	168	151	138	126	109	95
1.8	1.56	1.38	277	237	207	184	166	151	139	119	104
2.0	1.64	1.45	290	249	217	193	174	158	145	125	109
2.2	1.73	1.54	307	263	230	204	185	168	154	132	115
2.5	1.84	1.62	325	279	244	216	195	178	163	140	122
2.8	1.93	1.71	342	293	256	228	205	187	171	147	128
3.0	2.01	1.78	356	305	267	237	214	194	178	153	134

**16.2.2 Spray table for 7-hole nozzles**
**AMAZONE Spray table for 7-hole nozzle SJ7-02VP (yellow)**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Wasser	AHL									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,5	0,55	0,49	98	84	74	65	59	53	49	42	37
2,0	0,64	0,57	114	98	86	76	68	62	57	49	43
2,5	0,72	0,64	128	110	96	85	77	70	64	55	48
3,0	0,80	0,71	142	122	107	95	85	77	71	61	53
3,5	0,85	0,75	150	129	113	100	90	82	75	64	56
4,0	0,93	0,82	164	141	123	109	98	89	82	70	62



## Spray table

### AMAZONE Spray table for 7-hole nozzle SJ7-03VP (blue)

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Wasser	AHL	6	7	8	9	10	11	12	14	16
	(l/min)		km/h								
1,5	0,87	0,77	154	132	116	103	92	84	77	66	58
2,0	1,00	0,88	176	151	132	117	106	96	88	75	66
2,5	1,10	0,97	194	166	146	129	116	106	97	83	73
3,0	1,18	1,04	208	178	156	139	125	113	104	89	78
3,5	1,27	1,12	224	192	168	149	134	122	112	96	84
4.0	1.31	1.16	232	199	174	155	139	127	116	99	87

### AMAZONE Spray table for 7-hole nozzle SJ7-04VP (red)

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Wasser	AHL	6	7	8	9	10	11	12	14	16
	(l/min)		km/h								
1,5	1,17	1,04	208	178	156	139	125	113	104	89	78
2,0	1,33	1,18	236	202	177	157	142	129	118	101	89
2,5	1,45	1,28	256	219	192	171	154	140	128	110	96
3,0	1,55	1,37	274	235	206	183	164	149	137	117	103
3,5	1,66	1,47	295	253	221	196	177	161	147	126	110
4.0	1.72	1.52	304	261	228	203	182	166	152	130	114

### AMAZONE Spray table for 7-hole nozzle SJ7-05VP (brown)

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Wasser	AHL	6	7	8	9	10	11	12	14	16
	(l/min)		km/h								
1,5	1,49	1,32	264	226	198	176	158	144	132	113	99
2,0	1,68	1,49	298	255	224	199	179	163	149	128	112
2,5	1,83	1,62	324	278	243	216	194	177	162	139	122
3,0	1,95	1,73	346	297	260	231	208	189	173	148	130
3,5	2,11	1,87	374	321	281	249	224	204	187	160	140
4.0	2.16	1.91	382	327	287	255	229	208	191	164	143

### AMAZONE Spray table for 7-hole nozzle SJ7-06VP (grey)

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Wasser	AHL	6	7	8	9	10	11	12	14	16
	(l/min)		km/h								
1,5	1,77	1,57	314	269	236	209	188	171	157	135	118
2,0	2,01	1,78	356	305	267	237	214	194	178	153	134
2,5	2,19	1,94	388	333	291	259	233	212	194	166	146
3,0	2,35	2,08	416	357	312	277	250	227	208	178	156
4.0	2.61	2.31	562	396	347	308	277	252	231	198	173



**AMAZONE Spray table for 7-hole nozzle SJ7-08VP (white)**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Wasser	AHL									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,5	2,28	2,02	404	346	303	269	242	220	202	173	152
2,0	2,66	2,35	470	403	353	313	282	256	235	201	176
2,5	2,94	2,60	520	446	390	347	312	284	260	223	195
3,0	3,15	2,79	558	478	419	372	335	304	279	239	209
4,0	3,46	3,06	612	525	459	408	367	334	306	262	230

**16.2.3 Spray table for FD- nozzles**
**AMAZONE Spray table for FD-04- nozzle**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Water	AHL									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,5	1,13	1,00	200	171	150	133	120	109	100	86	75
2,0	1,31	1,15	230	197	173	153	138	125	115	99	86
2,5	1,46	1,29	258	221	194	172	155	141	129	111	97
3,0	1,60	1,41	282	241	211	188	169	154	141	121	106
4,0	1,85	1,63	326	279	245	217	196	178	163	140	122

**AMAZONE Spray table for FD-05- nozzle**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Water	AHL									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,5	1,41	1,24	248	213	186	165	149	135	124	106	93
2,0	1,63	1,44	288	247	216	192	173	157	144	123	108
2,5	1,83	1,61	322	276	242	215	193	176	161	138	121
3,0	2,00	1,76	352	302	264	235	211	192	176	151	132
4,0	2,31	2,03	406	348	305	271	244	221	203	174	152

**AMAZONE Spray table for FD-06- nozzle**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Water	AHL									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,5	1,70	1,49	298	255	224	199	179	163	149	128	112
2,0	1,96	1,72	344	295	258	229	206	188	172	147	129
2,5	2,19	1,93	386	331	290	257	232	211	193	165	145
3,0	2,40	2,11	422	362	317	282	253	230	211	181	158
4,0	2,77	2,44	488	418	366	325	293	266	244	209	183

## Spray table

### AMAZONE Spray table for FD-08- nozzle

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Water	AHL	6	7	8	9	10	11	12	14	16
	(l/min)		km/h								
1,5	2,26	1,99	398	341	299	265	239	217	199	171	149
2,0	2,61	2,30	460	394	345	307	276	251	230	197	173
2,5	2,92	2,57	514	441	386	343	308	280	257	220	193
3,0	3,20	2,82	563	483	422	375	338	307	282	241	211
4.0	3.70	3.25	650	557	488	433	390	355	325	279	244

### AMAZONE Spray table for FD-10- nozzle

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate AHL (l/ha) /								
	Water	AHL	6	7	8	9	10	11	12	14	16
	(l/min)		km/h								
1,5	2,83	2,49	498	427	374	332	299	272	249	214	187
2,0	3,27	2,88	576	494	432	384	345	314	288	246	216
2,5	3,65	3,21	642	551	482	429	385	350	321	275	241
3,0	4,00	3,52	704	604	528	469	422	384	352	302	264
4.0	4.62	4.07	813	697	610	542	488	444	407	348	305

### 16.2.4 Spray table for drag hose unit

#### AMAZONE Spray table for dosing disc 4916-26, (dia. 0.65 mm)

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate (l/ha) /								
	Water  (l/min)	AUS	6	7	8	9	10	11	12	14	16
			km/h								
1,0	0,20	0,18	71	61	53	47	43	37	36	31	27
1,2	0,22	0,19	78	67	58	52	47	43	39	34	29
1,5	0,24	0,21	85	73	64	57	51	47	43	37	32
1,8	0,26	0,23	92	79	69	61	55	50	46	40	35
2,0	0,28	0,25	99	85	74	66	60	54	50	43	37
2,2	0,29	0,26	103	88	77	68	62	56	52	44	39
2,5	0,31	0,27	110	94	82	73	66	60	55	47	41
2,8	0,32	0,28	113	97	85	76	68	62	57	49	43
3,0	0,34	0,30	120	103	90	80	72	66	60	52	45
3,5	0,36	0,32	127	109	96	85	77	70	64	55	48
4,0	0,39	0,35	138	118	104	92	83	76	69	59	52

**AMAZONE Spray table with dosing disc 4916-32, (dia. 0.8 mm)**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate (l/ha) /								
	Water	AUS									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,0	0,31	0,27	110	94	82	73	66	60	55	47	41
1,2	0,34	0,30	120	103	90	80	72	66	60	52	45
1,5	0,38	0,34	135	115	101	90	81	74	68	58	51
1,8	0,41	0,36	145	124	109	97	87	79	73	62	55
2,0	0,43	0,38	152	130	114	101	92	83	76	65	57
2,2	0,45	0,40	159	137	119	106	96	87	80	69	60
2,5	0,48	0,42	170	146	127	113	102	93	85	73	64
2,8	0,51	0,45	181	155	135	120	109	98	91	78	68
3,0	0,53	0,47	188	161	141	125	113	103	94	81	71
3,5	0,57	0,50	202	173	151	135	121	110	101	87	76
4,0	0,61	0,54	216	185	162	144	130	118	108	93	81

**AMAZONE Spray table for dosing disc 4916-39, (dia. 1.0 mm) (standard)**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate (l/ha) /								
	Water	AUS									
	(l/min)		6	7	8	9	10	11	12	14	16
			km/h								
1,0	0,43	0,38	153	131	114	101	92	84	77	66	57
1,2	0,47	0,41	167	143	124	110	100	91	84	72	62
1,5	0,53	0,47	187	160	141	126	112	102	94	80	71
1,8	0,58	0,51	204	175	154	137	122	112	102	88	77
2,0	0,61	0,53	216	185	162	144	130	118	108	93	81
2,2	0,64	0,56	227	194	170	151	136	124	114	97	85
2,5	0,68	0,59	240	206	180	160	142	132	120	103	90
2,8	0,71	0,62	251	215	189	168	151	137	126	108	95
3,0	0,74	0,64	262	224	197	175	158	143	131	112	99
3,5	0,79	0,69	280	236	210	186	168	153	140	118	105
4,0	0,85	0,74	302	259	226	201	181	165	151	130	113

## Spray table

**AMAZONE Spray table for dosing disc 4916-45, (dia. 1.2 mm)**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate (l/ha) /								
	Water  (l/min)	AUS	6	7	8	9	10	11	12	14	16
			km/h								
1,0	0,57	0,50	202	173	151	135	121	110	101	87	76
1,2	0,62	0,55	219	188	165	146	132	120	110	94	83
1,5	0,70	0,62	248	212	186	165	149	135	124	106	93
1,8	0,77	0,68	273	234	204	182	164	148	137	117	102
2,0	0,81	0,72	287	246	215	192	172	157	144	123	108
2,2	0,86	0,76	304	261	228	203	183	166	152	131	114
2,5	0,92	0,81	326	279	244	217	196	178	163	140	122
2,8	0,96	0,85	340	291	255	227	204	186	170	146	128
3,0	1,00	0,89	354	303	266	236	213	193	177	152	133
3,5	1,10	0,97	389	334	292	260	234	213	195	167	146
4,0	1,16	1,03	411	352	308	274	246	224	206	176	154

**AMAZONE Spray table for dosing disc 4916-55, (dia. 1.4 mm)**

Pres- sure  (bar)	Nozzle output per dosing disc		AUS spray rate (l/ha) /								
	Water  (l/min)	AUS	6	7	8	9	10	11	12	14	16
			km/h								
1,0	0,86	0,76	304	261	228	203	183	166	152	131	114
1,2	0,93	0,82	329	282	247	219	198	180	165	141	124
1,5	1,05	0,93	372	319	278	248	223	203	186	160	139
1,8	1,15	1,02	407	349	305	271	245	222	204	175	153
2,0	1,22	1,08	432	370	324	288	259	236	216	185	162
2,2	1,27	1,12	450	385	337	300	270	245	225	163	168
2,5	1,35	1,19	478	410	358	319	287	261	239	205	179
2,8	1,43	1,27	506	434	380	337	304	276	253	217	190
3,0	1,47	1,30	520	446	390	347	312	284	260	223	195
3,5	1,59	1,41	563	482	422	375	338	307	282	241	211
4,0	1,69	1,50	598	513	449	399	359	327	299	257	225

### 16.3 Conversion table for spraying ammonium nitrate / urea solution (AUS) liquid fertiliser

(Density 1.28 kg/l, i.e. approx. 28 kg N for 100 kg of liquid fertiliser or 36 kg N for 100 litres of liquid fertiliser at 5 - 10 °C)

N kg	Sol. N l	Sol. N kg	N kg	Sol. N l	Sol. N kg	N kg	Sol. N l	Sol. N kg	N kg	Sol. N l	Sol. N kg	N kg	Sol. N l	Sol. N kg
10	27.8	35.8	52	144.6	186.0	94	261.2	335.8	136	378.0	485.0			
12	33.3	42.9	54	150.0	193.0	96	266.7	342.7	138	384.0	493.0			
14	38.9	50.0	56	155.7	200.0	98	272.0	350.0	140	389.0	500.0			
16	44.5	57.1	58	161.1	207.3	100	278.0	357.4	142	394.0	507.0			
18	50.0	64.3	60	166.7	214.2	102	283.7	364.2	144	400.0	515.0			
20	55.5	71.5	62	172.3	221.7	104	285.5	371.8	146	406.0	521.0			
22	61.6	78.5	64	177.9	228.3	106	294.2	378.3	148	411.0	529.0			
24	66.7	85.6	66	183.4	235.9	108	300.0	386.0	150	417.0	535.0			
26	75.0	92.9	68	188.9	243.0	110	305.6	393.0	155	431.0	554.0			
28	77.8	100.0	70	194.5	250.0	112	311.1	400.0	160	445.0	572.0			
30	83.4	107.1	72	200.0	257.2	114	316.5	407.5	165	458.0	589.0			
32	89.0	114.2	74	204.9	264.2	116	322.1	414.3	170	472.0	607.0			
34	94.5	121.4	76	211.6	271.8	118	328.0	421.0	175	486.0	625.0			
36	100.0	128.7	78	216.5	278.3	120	333.0	428.0	180	500.0	643.0			
38	105.6	135.9	80	222.1	285.8	122	339.0	436.0	185	514.0	660.0			
40	111.0	143.0	82	227.9	292.8	124	344.0	443.0	190	527.0	679.0			
42	116.8	150.0	84	233.3	300.0	126	350.0	450.0	195	541.0	696.0			
44	122.2	157.1	86	238.6	307.5	128	356.0	457.0	200	556.0	714.0			
46	127.9	164.3	88	242.2	314.1	130	361.0	465.0						
48	133.3	171.5	90	250.0	321.7	132	367.0	471.0						
50	139.0	178.6	92	255.7	328.3	134	372.0	478.0						



# **AMAZONEN-WERKE**

## **H. DREYER SE & Co. KG**

Postfach 51  
D-49202 Hasbergen-Gaste  
Germany

Tel.: + 49 (0) 5405 501-0  
e-mail: [amazone@amazone.de](mailto:amazone@amazone.de)  
<http://www.amazone.de>

---