



Technical data: Groundkeeper/HorseHopper

Model	Working width	Tractor mounting			Col-lection hopper (l)	Empty weight (kg)	Permissible total weight* (kg)	Dimensions L x W x H (m)
		Recommended tractor power requirement (hp)		Category				
	(m)	Min.	Max.					
GH 1350	1.35	30	60	Cat. I N, I	1,350	570	910	1.80 x 1.75 x 1.48
GH 1500/HH 1500	1.50	40	80	Cat. I, II	1,500	600	970	1.80 x 1.90 x 1.48
GH 1800 Super/HH 1800 Super	1.80	60	120	Cat. I, II	1,800	690	1,140	1.80 x 2.20 x 1.48
GH 2100 Super/HH 2100 Super	2.10	70	130	Cat. I, II	2,100	760	1,290	1.80 x 2.50 x 1.48

With ground level discharge

GHL-T 1350	1.35	30	60	Cat. I N, I	1400	750	1,100	1.94 x 1.75 x 1.58
GHL-T 1500	1.50	40	80	Cat. I, II	1,550	780	1,160	1.94 x 1.90 x 1.58

Discharge height approx. 1.80 m

GHS 1500	1.50	50	100	Cat. I, II	2,500	970	1,600	2.60 x 1.90 x 1.65
GHS 1800	1.80	60	120	Cat. I, II	3,000	1,000	1,750	2.60 x 2.20 x 1.65
GHS 2100	2.10	70	130	Cat. I, II	3,500	1,040	1,915	2.60 x 2.50 x 1.65

Discharge height approx. 2.20 m

GHS Drive 1500	1.50	50	100	–	2,500	1,030	1,660	3.55 x 1.90 x 1.70
GHS Drive 1800	1.80	60	120	–	3,000	1,130	1,880	3.55 x 2.20 x 1.70
GHS Drive 2100	2.10	70	130	–	3,500	1,240	2,100	3.55 x 2.50 x 1.70

Discharge height approx. 2.30 m

* Value used for testing the lift capacity and permissible total weight of the tractor (mounted implements) and the permissible total weight of the tractor in operation (mounted implements).



Illustrations, content and technical data are not binding and may differ depending on the level of equipment. Country-specific road traffic regulations apply and must be complied with, meaning that special approval may be required. The permissible axle loads and total weights of the tractor should be checked. Not all the listed combination options are possible with all tractor manufacturers.



AMAZONE S.A. Forbach

B.P. 90106 · 17, rue de la Verrerie · F-57602 Forbach Cedex

Phone +33 (0)3 87 84 65 70 · Fax +33 (0)3 87 84 65 71

www.amazone.fr · forbach@amazone.fr